



# Operator's Manual

## Serial number range

**GTH-4013 SX**

From serial n.: 20782  
To serial n.: 24600

**GTH-4017 SX**

From serial n.: 20695  
To serial n.: 25043

**GTH-4013 EX**

From serial n.: 20615  
To serial n.: 24991

**GTH-4017 EX**

From serial n.: 20795  
To serial n.: 24704

With Maintenance  
Information

First Edition  
Second Printing  
Part No. 57.0009.0540

---

## Important

Read, understand and obey these safety rules and operating instructions before operating the machine. Only trained and qualified personnel shall be authorised to operate the machine. This manual shall be kept with the machine at all times.

For any further information, please call Terexlift.

---

## Contact us:

ZONA INDUSTRIALE I-06019 UMBERTIDE  
(PG) - ITALY

Telephone +39 075 941811

Telefax +39 075 9415382

### Technical Assistance Service

Telephone: +39 075 9418129

+39 075 9418175

**e-mail: [UMB.Service@terex.com](mailto:UMB.Service@terex.com)**

### *Original Instructions*

First Edition: Second Printing, April 2012

For the electronic version of this manual visit  
[www.genielift.com/operator\\_manuals.asp](http://www.genielift.com/operator_manuals.asp)

© Copyright 2011 **TEREXLIFT srl** - All rights reserved

Produced by:

TEREXLIFT Technical Literature Dept.

Umbertide (PG) Italy


## Contents

<b>Machine Identification</b> .....	9	Control Levers For Sx .....	54
Designation .....	9	<b>Function Selection</b> .....	<b>55</b>
Model .....	9	<b>Boom Lifting/Lowering</b> .....	<b>56</b>
Manufacturer: .....	9	<b>Boom Extension/Retraction</b> .....	<b>57</b>
Applicable Standards .....	9	<b>Attachment Holding Frame Pitching</b> .....	<b>58</b>
Machine Identification Plates .....	9	<b>Attachments Quick-Coupling (Optional)</b> .....	<b>59</b>
CE Marking .....	10	<b>Machine Sway Control</b> .....	<b>60</b>
Chassis Serial Number .....	10	<b>Outriggers Movement</b> .....	<b>60</b>
Identification Plates Of The Main Parts .....	10	Control Lever For Ex .....	61
<b>Symbols Used On The Machine</b> .....	11	<b>Function Selection</b> .....	<b>62</b>
Hazard Pictorial Descriptions .....	12	<b>Boom Lifting/Lowering</b> .....	<b>63</b>
<b>Labels And Plates Applied On The Machine</b> .....	13	<b>Boom Extension/Retraction</b> .....	<b>64</b>
GTH-4013SX - GTH-4017SX .....	13	<b>Attachment Holding Frame Pitching</b> .....	<b>65</b>
GTH-4013EX - GTH-4017EX .....	19	<b>Attachments Quick-Coupling</b> .....	<b>66</b>
<b>Safety Precautions</b> .....	27	<b>Outriggers Movements</b> .....	<b>67</b>
Damaged Machine Hazards.....	27	<b>Machine Sway Control</b> .....	<b>67</b>
Personal Injury Hazards.....	27	Manual Controls - GTH-4013EX & GTH-4017EX .....	68
Safety Devices .....	27	<b>Inspections</b> .....	69
Moment Limiting System (Llmi/Llmc) .....	27	Pre-Operation Inspection Fundamentals .....	69
Seat Switch .....	27	Pre-Operation Inspection .....	70
General Remarks .....	28	Fundamental Function Tests.....	71
Requisites Of The Personnel In Charge .....	29	<b>Tests</b> .....	<b>71</b>
<b>Requisites Of The Machine Operators</b> .....	<b>29</b>	<b>Test The Control Lever (For Sx)</b> .....	<b>71</b>
<b>Requisites Of The Servicemen</b> .....	<b>29</b>	<b>Test The Control Lever (For Ex)</b> .....	<b>71</b>
Working Clothes .....	30	<b>Test The Steering</b> .....	<b>72</b>
Personal Protective Equipment.....	30	<b>Test The Transmission And Brakes</b> .....	<b>72</b>
Hazards On The Jobsite .....	30	<b>Test Outriggers And Sway Control (For Sx)</b> .....	<b>72</b>
Operation Or Maintenance Hazards .....	31	<b>Test Outriggers And Sway Control (For Ex)</b> .....	<b>72</b>
Machine Operation Hazards .....	33	<b>Test The Road Lights</b> .....	<b>73</b>
Explosion Or Fire Hazards .....	33	Workplace Inspection .....	73
Damaged Component Hazards.....	33	<b>Operating Instructions</b> .....	75
Personal Injury Hazards.....	33	Entering The Machine .....	76
Suspended Load Hazards.....	34	Entering The Cab .....	76
Llmi/ Llmc Hazards.....	34	<b>Leaving The Cab In An Emergency</b> .....	<b>76</b>
<b>Description Of The Machine</b> .....	35	<b>Adjusting The Seat</b> .....	<b>77</b>
GTH-4013SX General Description .....	36	<b>Fastening The Seat Belts</b> .....	<b>77</b>
GTH-4017SX General Description.....	38	<b>Adjusting The Steering Column</b> .....	<b>78</b>
GTH-4013EX General Description .....	40	<b>Switching On The Cab Interior Lamp</b> .....	<b>78</b>
GTH-4017EX General Description .....	42	Adjusting The Mirrors .....	79
Allowed Use .....	44	Starting The Engine .....	80
Improper Use .....	44	Jump-Starting The Engine .....	80
<b>Controls And Instruments</b> .....	45	Low Temperature Starting.....	81
Ignition Switch .....	47	Disconnecting The Battery .....	82
Forward/Reverse Gear Selector .....	47	Starting The Machine .....	82
Horn Function.....	47	Stopping And Parking The Machine.....	82
Turn Signals - Windscreen Wiper - Lights.....	48	Using The Load Charts .....	83
Brakes .....	49	Load Limiter .....	84
Accelerator Control .....	49	<b>Description Of The Controls</b> .....	<b>84</b>
Safety And Emergency Devices.....	49	<b>Operation</b> .....	<b>84</b>
Job-Site/Road/Platform Selection .....	50	<b>Alarm Codes And Resetting</b> .....	<b>85</b>
Steering Mode Selection .....	50	Adjusting The Forks .....	85
Auxiliary Drive Controls .....	51	Working Phases .....	86
Warning Lights And Instruments .....	52	<b>Loading Phase</b> .....	<b>86</b>

<b>Transfer Phase</b> .....	<b>87</b>	Checking The Machine Start Control .....	121
<b>Unloading Phase</b> .....	<b>87</b>	Checking The State Of The Structure .....	121
Changing The Attachment .....	88	Seat Switch .....	121
<b>Version With Mechanical Locking</b> .....	<b>88</b>	Electrical System .....	122
<b>Version With Hydraulic Locking (Optional)</b> .....	<b>89</b>	Fuses And Relays .....	123
Road Or Site Transfer .....	90	<b>GTH-4013SX &amp; GTH-4017SX</b> .....	<b>123</b>
Use Of The Man-Platform (Only For Ex).....	91	<b>GTH-4013EX &amp; GTH-4017EX</b> .....	<b>124</b>
<b>Transporting The Machine</b> .....	<b>93</b>	<b>Engine Compartment Fuses And Relays</b> .....	<b>125</b>
Moving A Disabled Machine.....	93	12V Dc Lamps.....	125
Unlocking The Negative Brake.....	93	Battery .....	126
Lifting The Machine.....	94	Refuelling .....	127
Transporting The Machine On Other Vehicles.....	94	Product Specifications.....	127
Parking And Storage .....	95	<b>Engine Oil</b> .....	<b>127</b>
<b>Short Inactivity</b> .....	<b>95</b>	<b>Lubrication Oils</b> .....	<b>127</b>
<b>Machine Storage</b> .....	<b>95</b>	<b>Refill The Machine With Following Lubricants:</b> ....	<b>127</b>
Cleaning And Washing The Machine.....	96	<b>Oils For Hydraulic System:</b> .....	<b>127</b>
<b>External Washing</b> .....	<b>96</b>	<b>Fuel</b> .....	<b>128</b>
<b>Internal Washing</b> .....	<b>96</b>	<b>Grease</b> .....	<b>128</b>
<b>Washing The Engine</b> .....	<b>96</b>	<b>Engine Coolant</b> .....	<b>128</b>
Machine Disposal.....	96	<b>Faults And Troubleshooting</b> .....	<b>129</b>
<b>Battery Disposal</b> .....	<b>96</b>	Faults And Troubleshooting .....	129
<b>Maintenance</b> .....	<b>97</b>	Load Limiting System Alarm Codes .....	130
Introduction .....	97	MC2M Alarm Codes.....	132
Spare Parts .....	98	Torque Wrench Settings .....	134
Lubricants - Health And Safety Precautions .....	98	<b>Optional Attachments</b> .....	<b>135</b>
Ordinary Maintenance .....	99	Introduction .....	135
Oil Change Schedule .....	101	Floating Forks .....	136
Maintenance Interventions .....	102	Fem 3 Forks On Plate .....	137
Access To The Engine Compartment .....	103	Fem 3 Forks With Hydraulic Side-Shift .....	138
Engine .....	103	Floating Forks (For England) .....	139
Engine Air Filter.....	104	800 Litres Shovel .....	140
Engine Cooling System .....	105	500 Lt Mixing Bucket.....	141
Checking The Oil Level In The Tank.....	106	500 Litres Concrete Bucket.....	142
Changing The Hydraulic Oil .....	106	800 Litres Concrete Bucket.....	143
Changing The Oil Filter Cartridge .....	107	Fixed Hook On Plate .....	144
Cab Air Filter .....	108	900 Kg Extension Jib .....	145
Oil Level In The Differential Gears .....	109	900 Kg Extension Jib .....	146
Oil Level In The (Front/Rear) Wheel Reduction Gears ....	109	2000 Kg Extension Jib .....	147
Oil Level In The Power Divider Gearbox.....	110	3000 Kg Hydraulic Hoist.....	148
Greasing.....	111	Man-Platform 3P/700 Rem4400 Only For Ex.....	149
Tyres And Wheels.....	112	Man-Platform 2P/300 F Only For Ex.....	150
Brakes .....	112	Basket For Bricks .....	151
Shafting Alignment .....	113	<b>Specifications</b> .....	<b>153</b>
Adjusting The Sliding Pads Of The Boom Sections .....	114	Machine Data .....	153
Boom Re-Sequencing (GTH4013SX & EX) .....	115	Center Of Gravity GTH-4013SX & Ex.....	155
BOOM CHAINS TENSIONING (GTH4017SX & EX) .....	115	Center Of Gravity GTH-4017SX & Ex.....	156
Checking The Safety Devices.....	116	<b>Load Charts</b> .....	<b>157</b>
<b>LOAD LIMITING SYSTEM.</b> .....	<b>116</b>	Forks On Wheel GTH-4017SX & Ex .....	157
<b>MICRO-SWITCHES On The OUTRIGGERS</b> .....	<b>117</b>	Forks On Outriggers GTH-4017SX & Ex.....	158
<b>Emergency Stop Pushbutton</b> .....	<b>117</b>	Hook On Wheel GTH-4017SX & Ex.....	159
<b>Block Valves Fitted To All Cylinders</b> .....	<b>118</b>	Hook On Outriggers GTH-4017SX & Ex .....	160
<b>Safety Switches:</b> .....	<b>120</b>	Hoist On Wheel GTH-4017SX & Ex.....	161
		Hoist On Outriggers GTH-4017SX & GTH-4017EX .....	162



2000 Kg Jib On Wheel GTH-4017SX & Ex .....	163	<b>Diagrammatic Representation Of Suspended Load</b>	
2000 Kg Jib On Outriggers GTH-4017SX & Ex .....	164	<b>Condition Test Results For GTH-4017SX .....</b>	<b>213</b>
900 Kg Jib On Wheel GTH-4017SX & Ex .....	165	Appendix B .....	214
900 Kg Jib On Outriggers GTH-4017SX & Ex .....	166	<b>Lorry Trailer Condition .....</b>	<b>214</b>
Shovel On Wheel GTH-4017SX & Ex .....	167	<b>Diagrammatic Representation Of Lorry Trailer Condition</b>	
Shovel On Outriggers GTH-4017SX & GTH-4017EX ....	168	<b>Test Results For GTH-4013SX .....</b>	<b>215</b>
Man-Platform 3P/700 Rem 4400 - GTH-4017EX .....	169	<b>Diagrammatic Representation Of Lorry Trailer Condition</b>	
Man-Platform 2P/300 F - GTH-4017EX .....	170	<b>Test Results For GTH-4017SX .....</b>	<b>216</b>
Fork On Wheel GTH-4013SX & GTH-4013EX .....	171	<b>Diagrammatic Representation Of Lorry Trailer Condition</b>	
Fork On Outriggers GTH-4013SX & GTH-4013EX .....	172	<b>Test Results For GTH-4013SX .....</b>	<b>217</b>
Hook On Wheel GTH-4013SX & GTH-4013EX .....	173	<b>Diagrammatic Representation Of Lorry Trailer Condition</b>	
Hook On Outriggers GTH-4013SX & GTH-4013EX .....	174	<b>Test Results For GTH-4017SX .....</b>	<b>218</b>
Hoist On Wheel GTH-4013SX & GTH-4013EX .....	175	Overload Test Procedure .....	219
Hoist On Outriggers GTH-4013SX & GTH-4013EX .....	176	<b>EC Declaration Of Conformity .....</b>	<b>221</b>
2000 Kg Jib On Wheel GTH-4013SX & GTH-4013EX ...	177	Ec Declaration Of Conformity Full Text .....	221
2000 Kg Jib On Outriggers GTH-4013SX GTH-4013EX	178	<b>Routine Check Schedule .....</b>	<b>223</b>
900 Kg Jib On Wheel GTH-4013SX & GTH-4013EX .....	179	<b>Safety Devices Daily Checking .....</b>	<b>223</b>
900 Kg Jib On Outriggers GTH-4013SX GTH-4013EX ..	180		
Shovel On Wheel GTH-4013SX & GTH-4013EX .....	181		
Shovel On Outriggers GTH-4013SX & GTH-4013EX ....	182		
Man-Platform 3P/700 Rem 4400 - GTH-4013EX .....	183		
Man-Platform 2P/300 F - GTH-4013EX .....	184		
<b>Diagrams And Schemes .....</b>	<b>185</b>		
GTH-4013SX & GTH-4017SX Wiring Diagram 1/10 .....	185		
GTH-4013SX & GTH-4017SX Wiring Diagram 2/10 .....	186		
GTH-4013SX & GTH-4017SX Wiring Diagram 3/10 .....	187		
GTH-4013SX & GTH-4017SX Wiring Diagram 4/10 .....	188		
GTH-4013SX & GTH-4017SX Wiring Diagram 5/10 .....	189		
GTH-4013SX & GTH-4017SX Wiring Diagram 6/10 .....	190		
GTH-4013SX & GTH-4017SX Wiring Diagram 7/10 .....	191		
GTH-4013SX & GTH-4017SX Wiring Diagram 8/10 .....	192		
GTH-4013SX & GTH-4017SX Wiring Diagram 9/10 .....	193		
GTH-4013SX & GTH-4017SX Wiring Diagram 10/10 ....	194		
GTH-4013EX & GTH-4017EX Wiring Diagram 1/11 .....	195		
GTH-4013EX & GTH-4017EX Wiring Diagram 2/11 .....	196		
GTH-4013EX & GTH-4017EX Wiring Diagram 3/11 .....	197		
GTH-4013EX & GTH-4017EX Wiring Diagram 4/11 .....	198		
GTH-4013EX & GTH-4017EX Wiring Diagram 5/11 .....	199		
GTH-4013EX & GTH-4017EX Wiring Diagram 6/11 .....	200		
GTH-4013EX & GTH-4017EX Wiring Diagram 7/11 .....	201		
GTH-4013EX & GTH-4017EX Wiring Diagram 8/11 .....	202		
GTH-4013EX & GTH-4017EX Wiring Diagram 9/11 .....	203		
GTH-4013EX & GTH-4017EX Wiring Diagram 10/11 ....	204		
GTH-4013EX & GTH-4017EX Wiring Diagram 11/11 ....	205		
GTH-4013SX Hydraulic Diagram .....	206		
GTH-4017SX Hydraulic Diagram .....	207		
GTH-4017EX Hydraulic Diagram .....	208		
GTH-4013EX Hydraulic Diagram .....	209		
<b>Test .....</b>	<b>211</b>		
Appendix A .....	211		
<b>Suspended Load Condition .....</b>	<b>211</b>		
<b>Diagrammatic Representation Of Suspended Load</b>			
<b>Condition Test Results For GTH-4013SX .....</b>	<b>212</b>		



Intentionally blank page

# Introduction

## Symbols



*Safety alert symbol: used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death*



*Red: indicates a hazardous situation which, if not avoided, will result in death or serious injury.*



*Orange: indicates a hazardous situation which, if not avoided, could result in death or serious injury.*




*Yellow: indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.*



*Blue: indicates a hazardous situation which, if not avoided, could result in property damage.*



*Green: used to draw the attention to important information on environment protection.*



Intentionally blank page

## Machine Identification

**Check that the operator handbook refers to the delivered machine.**

### DESIGNATION

**Rough Terrain Variable Reach Truck**

### MODEL

**GTH-4013 SX / GTH-4017 SX  
GTH-4013 EX / GTH-4017 EX**

### MANUFACTURER:

**TEREXLIFT srl**

Zona Industriale - I-06019 UMBERTIDE (PG) - ITALY  
Enrolled in the register of companies at the Court of Perugia under no. 4823

C.C.I.A.A. 102886

Fiscal Code/V.A.T. no. 00249210543

### APPLICABLE STANDARDS

For the operator's safety, the following standards were obeyed during the risk assessment of the handler fitted with telescopic boom norme:

<b>Directive</b>	<b>Title</b>
2006/42/EC	Machinery Directive
2008/104/EC	Electromagnetic compatibility
2000/14/CE	Environment Acoustic Emissions
<b>Standard</b>	<b>Title</b>
EN 1459:1988	Harmonised standard. Safety of
A2:2009	Industrial trucks - Self- propelled variable reach trucks.

### MACHINE IDENTIFICATION PLATES

The following data plates are applied on the machine:

#### Machine data plate

The identification plate contains the main identification data of the machine like model, serial number and year of manufacture, it is applied on the front right side of the chassis.

#### Road traffic data plate

The road traffic data plate is installed on the front right side of the chassis (only on machines destined for the Italian market).

This plate shows the road traffic related data and the weights of the specific machine model.

#### Fork data plate

Placed on the left side of the fork frame.

This plate shows the identification data of fork such as model, serial number, year of manufacture, weight, nominal payload, centre of the load and model of the machine on which the forks are installed.

## Machine Identification

### CE MARKING

This machine fulfils the safety requirements of the Machinery Directive. The conformity has been certified and the placing of the **CE** marking on the machine demonstrates compliance with the regulatory requirements.

The **CE** marking is placed directly on the identification plate of the machine.

### IDENTIFICATION PLATES OF THE MAIN PARTS

The plates of the main components, not directly manufactured by **TEREXLIFT srl** (for instance, engines, pumps, etc.), are located where originally applied by the manufacturers.


### CHASSIS SERIAL NUMBER

The chassis serial number is punched on the front right part of the chassis side member.

### HOW TO READ YOUR SERIAL NUMBER

#### Chassis serial number:

the chassis serial number is punched on the front right part of the chassis side member



**GTH4017SX 10 20695**

MODEL

































SERIAL  
NUMBER

YEAR OF  
MANUFACTURER

#### Machine data plate:

the machine data plate is applied on the front right side of the chassis

## Symbols Used On The Machine

				
Fuel Level	Brake pressure	Fog lamp	Parking Brake	Battery Charge
				
Low Engine Oil Pressure	Hydraulic Oil Filter Clogged	Low Hydraulic Oil Level	Turn Signals	High Beam
				
Hydraulic Oil Temperature Indicator	Air Filter Restricted	Glow Plugs Preheating	High Coolant Temperature	Low Beam
				
Steering Mode	Cab Ventilation Fan	Transfer Mode	Hazard Warning Lights	Position Lights
				
Fuel Cap	Hydraulic Oil	Lift Point	Air Conditionin	Emergency Pump
				
Aux. Hydr. Circuit	Outriggers Control	Mixing Bucket	Electronic Level	Mixing Bucket Oil Direction
				
Work Light	Chassis Levelling			

## Symbols Used On The Machine


### HAZARD PICTORIAL DESCRIPTIONS

				
Electrocution Hazard	Maintain required clearance.	Falling Object Hazard	No people under load.	Fall Hazard
				
No riders.	Burn Hazard	Allow system to cool.	Explosion/Burn Hazard	No smoking. No open flame.
				
Read the operator's manual.	Support boom when performing maintenance.	Crush Hazard	Burn Hazard	Allow surfaces to cool.
				
Crush Hazard	Keep away from moving parts.	Crush Hazard	Keep clear of moving parts.	Allow compartment access
				
Crush Hazard	Keep away from belt.	Insert Maintenance Collar	Battery Cut-Out	Safety Alert Symbol
				
Crush Hazard	Keep clear of moving outriggers.			










## Labels And Plates Applied On The Machine

GTH 4013 SX - GTH 4017 SX












## Labels And Plates Applied On The Machine










*Use the pictures on these pages to verify that all decals are legible and in place.  
The following chart shows quantities and description too.*

Ref.	Decal	Code	Description	Qt.
1		09.4618.1398	Safety pin operation	1
2		09.4618.1375	The capacity of the truck and attachment combination shall be complied with.	1
3		09.4618.0061 09.4618.0547	Tyre inflat. P=4.5bar/65psi GTH-4017 SX Tyre inflat. P=5.5bar/80psi GTH-4013 SX	4
4		09.4618.0918	Falling Object Hazard	3
5		09.4618.0919	Crush Hazard	4
6		09.4616.0041	Guaranteed sound power level	1
7		09.4618.0920	Compartment Access	1
8	<b>Kg 4000</b>	09.4616.0040	Max Capacity	1









## Labels And Plates Applied On The Machine

Ref.	Decal	Code	Description	Qt.
9		09.4618.0989	Label - Stabilizer Max Pres. GTH-4017 SX	2
		09.4618.0991	Label - Stabilizer Max Pres. GTH-4013 SX	2
10		09.4618.1399	Label - Upper Door Internal Unlock System	1
11		09.4618.1369	Quick guide and Control lever decal	1
12		09.4618.0921	Label - Use limits close to electric power lines	1
13		09.4618.0933	Crush Hazard	4
14		09.4618.0922	Crush Hazard	6
15 16 17		09.4618.0243 09.4618.0241 09.4618.0242	Cosmetic - GENIE Logo in WHITE	1 1 1
18 19		09.4618.0821 09.4618.0822	Cosmetic - Genie GTH-4017 SX	2 1
		09.4618.0721 09.4618.0722	Cosmetic - Genie GTH-4013 SX	2 1










## Labels And Plates Applied On The Machine

Ref.	Decal	Code	Description	Qt.
20		09.4618.0923	Burn Hazard	2
21		09.4618.0924	Burn/Explosion Hazard	1
22		09.4618.0925	Crush Hazard	1
23		09.4618.0926	No Riders	1
24		09.4618.0927	Burn Hazard	1
25		09.4618.0916	Lift Point	4
26		09.4618.0917	Diesel Fuel Cap	1
27		09.4618.0928	Hydraulic Oil	2
28		09.4618.0807	Label - Engine Fuses & Relays Board	1

## Labels And Plates Applied On The Machine


Ref.	Decal	Code	Description	Qt.
29		09.4618.1001	<b>Label - Maintenance Collar</b>	1
30		09.4618.1381	<b>Forks Pitching Back</b>	1
31		09.4618.0986	<b>Crush Hazard</b>	1
32		09.4618.1028	<b>Label - Parking Brake</b>	1
33		09.4618.1386	<b>Re-sequencing the telescopic boom extension.</b> If, during normal operation, a change in the boom extended lengths is noticed, proceed with re-sequencing as indicated in the operator's manual. <b>JUST FOR GTH 4013 SX</b>	1
34		09.4618.1427	<b>Label -Cabin Fuses &amp; Relays Board</b>	1
35		09.4618.1331	<b>Battery Cut-Out Switch</b>	1
36		09.4618.1423	<b>Accumulator Hazard</b>	3

## Labels And Plates Applied On The Machine

Ref.	Decal	Code	Description	Qt.
37		09.4618.1418	<b>Instruction - Emergency Exit</b>	1
38		09.4618.1419	<b>Biodegradable Hydraulic Oil</b> (optional)	2
39		09.4618.1029	<b>Label - Road Traffic Warnings</b> (only for machines destined for the Italian market).	1
40		09.4618.1458	<b>Tip-over</b>	2
41		09.4618.1645	<b>Load Limiter Disable Selector</b>	1
A		/	<b>Machine data plate.</b> The identification plate contains the main identification data of the machine.	1
B		/	<b>Fork data plate.</b> This plate shows the main data of the fork installed on the machine.	1
C		09.0803.0357	<b>Boom Tilting Degree</b>	1
D		/	<b>Road Traffic Data Plate.</b> This plate contains the road traffic related data and the weights of the specific machine model (only for machines destined for the Italian market).	1

## Labels And Plates Applied On The Machine








GTH 4013 EX - GTH 4017 EX



**Genie**  
A TITAN GROUP








## Labels And Plates Applied On The Machine

*Use the pictures on these pages to verify that all decals are legible and in place.  
The following chart shows quantities and description too.*











Ref.	Decal	Code	Description	Qt.
1		09.4618.1398	Safety pin operation	1
2		09.4618.1375	The capacity of the truck and attachment combination shall be complied with.	1
3		09.4618.0061 09.4618.0547	Tyre inflat. P=4.5bar GTH-4017 EX Tyre inflat. P=5.5bar GTH-4013EX	4 4
4		09.4618.0918	Falling Object Hazard	3
5		09.4618.0919	Crush Hazard	4
6		09.4616.0041	Guaranteed sound power level	1
7		09.4618.0920	Compartment Access	1
8	<b>Kg 4000</b>	09.4616.0040	Max Capacity	1











## Labels And Plates Applied On The Machine

Ref.	Decal	Code	Description	Qt.
9		09.4618.0989	<b>Label - Stabilizer Max Pres. GTH-4017EX</b>	2
		09.4618.0991	<b>Label - Stabilizer Max Pres. GTH-4013 EX</b>	2
10		09.4618.1399	<b>Label - Upper Door Internal Unlock System</b>	1
11		09.4618.1415	<b>Quick guide and Control lever decal</b>	1
12		09.4618.0921	<b>Label - Use limits close to electric power lines</b>	1
13		09.4618.0933	<b>Crush Hazard</b>	4
14		09.4618.0922	<b>Crush Hazard</b>	6
15 16 17		09.4618.0243 09.4618.0241 09.4618.0242	<b>Cosmetic - GENIE Logo in WHITE</b>	1 1 1








## Labels And Plates Applied On The Machine

Ref.	Decal	Code	Description	Qt.
18 19		09.4618.0817 09.4618.0818	Cosmetic - Genie GTH-4017 EX	2 1
		09.4618.0813 09.4618.0814	Cosmetic - Genie GTH-4013 EX	2 1
20		09.4618.0923	Burn Hazard	2
21		09.4618.0924	Burn/Explosion Hazard	1
22		09.4618.0925	Crush Hazard	1
23		09.4618.0926	No Riders	1
24		09.4618.0927	Burn Hazard	1
25		09.4618.0916	Lift Point	4
26		09.4618.0917	Diesel Fuel Cap	1
27		09.4618.0928	Hydraulic Oil	2





## Labels And Plates Applied On The Machine


Ref.	Decal	Code	Description	Qt.
28		09.4618.1481	Label - Engine Fuses & Relays Board	1
29		09.4618.1001	Label - Maintenance Collar	1
30		09.4618.1416	Label - Emergency Manual Controls Of The Main Valve	1
31		09.4618.0986	Crush Hazard	1
32		09.4618.1028	Label - Parking Brake	1
33		09.4618.1386	<b>Re-sequencing the telescopic boom extension.</b> If, during normal operation, a change in the boom extended lengths is noticed, proceed with re-sequencing as indicated in the operator's manual. <b>ONLY FOR GTH 4013 EX</b>	1
34		09.4618.1480	Label - Cabin Fuses & Relays Board	1 1
35		09.4618.1381	Forks Pitching Back	1

## Labels And Plates Applied On The Machine

Ref.	Decal	Code	Description	Qt.
36		09.4618.1423	<b>Accumulator Hazard</b>	4
37		09.4618.1331	<b>Battery Cut-Out Switch</b>	1
38		09.4618.1418	<b>Instruction - Emergency Exit</b>	1
39		09.4618.1419	<b>Biodegradable Hydraulic Oil</b> (optional)	2
40		09.4618.1029	<b>Label - Road Traffic Warnings</b> (only for machines destined for the Italian market).	1
41		09.4618.1458	<b>Tip-over</b>	2
42		09.4618.1645	<b>Load Limiter Disable Selector</b>	1

## Labels And Plates Applied On The Machine

Ref.	Decal	Code	Description	Qt.
A		/	<b>Machine data plate.</b> The identification plate contains the main identification data of the machine.	1
B		/	<b>Fork data plate.</b> This plate shows the main data of the fork installed on the machine.	1
C		09.0803.0357	<b>Boom Tilting Degree</b>	1
D		09.4616.0000	<b>Road Traffic Data Plate.</b> This plate contains the road traffic related data and the weights of the specific machine model (only for machines destined for the Italian market).	1



Intentionally blank page

## Safety Precautions

### DAMAGED MACHINE HAZARDS

- Do not use a damaged or malfunctioning machine.
- Do a thorough pre-operation inspection of the machine and test all functions before each work shift. Tag and remove from service a damaged or malfunctioning machine.
- Make sure that all maintenance jobs have been carried out as specified in this manual and the appropriate service manual.
- Make sure that all decals are in place and legible.
- Make sure that the operator's is intact, legible and placed in the special container located in the machine.

### PERSONAL INJURY HAZARDS

- Do not operate the machine in case of hydraulic oil or air leak. Air or hydraulic oil leaks can penetrate or burn the skin.
- Always operate the machine in a well ventilated area to avoid carbon monoxide poisoning.
- Do not lower the boom if the area underneath is not clear of personnel or obstructions.

### SAFETY DEVICES



***Several safety devices have been fitted to the machine. They must never be tampered with or removed.***

***Regularly check the efficiency of such devices. In case of faults, stop working immediately and proceed in replacing the malfunctioning device. For the checking procedures, read chap. "Maintenance"***

### MOMENT LIMITING SYSTEM (LLMI/LLMC)

The moment limiting system has been developed to help the operator to maintain the machine longitudinal stability. Audible and visual messages are provided when the limits of longitudinal stability are being approached.

However this device cannot replace the experience of the operator. It is up to the user to adopt the necessary safety measures to work within the rated limits of the machine.

### SEAT SWITCH

This micro switch is located inside the seat cushion, and it prevents any machine transmission movements if the operator is not correctly seated in the driving seat.

## Safety Precautions



Not observing the instructions and safety rules in this manual may result in death or serious injury.

### Do not operate the machine unless:

- You learn and practice the principles of safe machine operation contained in this operator's manual.
  - 1. Avoid hazardous situations.** Read and understand the safety instructions before going on to the next chapter.
  - 2. Always perform a pre-operation inspection.**
  - 3. Always test the machine functions prior to use.**
  - 4. Inspect the work place.**
  - 5. Only use the machine for the intended application.**
- Read, understand and obey the manufacturer's instructions and the safety rules, the safety and operator's manuals, and the decals applied on the machine.
- Read, understand and obey the employer's safety rules and worksite regulations.
- Read, understand and obey the applicable national regulations.
- Only trained personnel informed on the safety rules can operate the machine.

### GENERAL REMARKS

Most accidents occurring while working, repairing or maintaining machines, are caused by not complying with the basic safety precautions.

Therefore, it is necessary to pay steady attention to the potential hazards and the effects that may come of operations carried out on the machine.



***If you recognise hazardous situations, you can prevent accidents!***



***The instructions given in this handbook are the ones established by TEREXLIFT. They do not exclude other safe and most convenient ways for the machine installation, operation and maintenance that take into account the available spaces and means.***

If you decide to follow instructions other than those given in this manual, you shall absolutely:

- be sure that the operations you are going to carry out are not explicitly forbidden;
- be sure that the methods are safe, say, in compliance with the rules and provisions given in this section;
- be sure that the methods cannot damage the machine directly or indirectly or make it unsafe;
- contact TEREXLIFT Assistance Service for any suggestion and the necessary written permission.



## Safety Precautions

### REQUISITES OF THE PERSONNEL IN CHARGE

#### Requisites of the machine operators

The operators who use the machine regularly or occasionally (i.e. for transport reasons) shall have the following prerequisites:

**health:**

before and during any operation, operators shall never take alcoholic beverages, medicines or other substances that may alter their psycho-physical conditions and, consequently, their working abilities.

**physical:**

good eyesight, acute hearing, good co-ordination and ability to carry out all required operations in a safe way, according to the instructions of this manual.

**mental:**

ability to understand and apply the enforced rules, regulations and safety precautions. They shall be careful and sensible for their own as well as for the others' safety and shall desire to carry out the work correctly and in a responsible way.

**emotional:**

they shall keep calm and always be able to evaluate their own physical and mental conditions.

**training:**

they shall read and be familiar with this handbook, its enclosed graphs and diagrams, the identification and hazard warning plates. They shall be skilled and trained about the machine use.

#### Requisites of the servicemen

The personnel charged with the machine maintenance shall be qualified, specialised in the maintenance of telehandlers, and shall have the following prerequisites:

**physical:**

good eyesight, acute hearing, good co-ordination and ability to carry out all required maintenance operations in a safe way, according to this manual.

**mental:**

ability to understand and apply the enforced rules, regulations and safety precautions. They shall be careful and sensible for their own as well as for the others' safety and shall desire to carry out the work correctly and in a responsible way.

**training:**

they shall read and be familiar with this handbook, its enclosed graphs and diagrams, the identification and warning plates. They shall be skilled and trained about the machine functioning.

## NOTICE

***From a technical point of view, the ordinary maintenance of the machine is not a complex intervention and can be carried out by the machine operator, too, provided he has a basic knowledge of mechanics.***




***The operator shall have a licence (or a driving licence) when provided for by the laws enforced in the country where the machine works. Please, ask the competent bodies. In Italy the operator must be at least 18 year old.***

## Safety Precautions

### WORKING CLOTHES

During work, but especially when maintaining or repairing the machine, operators must wear suitable protective clothing:

- Overalls or any other comfortable garments. Operators should not wear clothes with large sleeves or objects that can get stuck in moving parts of the machine.
- Ear-protectors or equivalent equipment.
- Protective helmet.
- Protective gloves.
- Working shoes.



**Use only type-approved working clothing in good condition.**

### PERSONAL PROTECTIVE EQUIPMENT

Under special working conditions, the following personal protective equipment should be used:

- Breathing set (or dust mask).
- Goggles or facial masks.

### HAZARDS ON THE JOBSITE

Always take into account the features of the job site where you are going to work:

- Always examine the working area and compare it with the machine dimensions in the different configurations.



**The machine is not electrically insulated and does not provide protection from contact with or proximity to electrical power lines.**

**Always keep at a minimum safe distance from the telescopic boom and the lifted load. Electrical hazards!**

- Keep away from the machine in case of contact with energized power lines. Personnel on the ground must never touch or operate the machine until energized power lines are shut off.

**DEATH OR INJURY CAN RESULT FROM CONTACTING ELECTRIC POWER LINES.**

**ALWAYS CONTACT THE ELECTRIC POWER LINES OWNER. THE ELECTRIC POWER SHALL BE DISCONNECTED OR THE POWER LINES MOVED OR INSULATED BEFORE MACHINE OPERATIONS BEGIN**

POWER LINE VOLTAGE		REQUIRED CLEARANCE	
0	to 50 kV	10 ft	3.00 m
50	to 200 kV	15 ft	4.60 m
200	to 350 kV	20 ft	6.10 m
350	to 500 kV	25 ft	7.62 m
500	to 750 kV	35 ft	10.67 m
750	to 1000 kV	45 ft	13.72 m



**Do not at any time use the machine during a storm.**



**Operator have to survey his/her field of vision when operating the truck.**


## Safety Precautions

### **WARNING**

Make sure the machine (wheels and stabilisers) rests on a firm ground to prevent hazardous unstable conditions.

If the ground is not firm enough, position some supporting planks under the stabilisers or the wheels.

- Look for the best route to the job site.
- When the machine is running, nobody can enter its working range.
- While working, keep the working area in order. Never leave objects scattered: they could hinder the machine movements and represent a danger for personnel.
- In presence of trenches, lower the outriggers at a safe distance from the trench edge.



### OPERATION OR MAINTENANCE HAZARDS

Before any operation, following precautions should be taken:

- First of all, make sure that the maintenance interventions have been carried out with care according to the established schedule.

### **WARNING**

Set the machine to working configuration and sway it. Use the special inclinometer to the right of the driving place to check that the machine is level before operating it.

- Ensure you have enough fuel to avoid a sudden stop of the engine, especially during a crucial manoeuvre.
- Clean instruments, data plates, lights and the cab windscreen thoroughly.
- Check the correct functioning of all the safety devices installed on the machine and in the job site.
- In case of troubles or difficulties, inform the foreman at once. Never start working under unsafe conditions.
- Do not carry out any repair work in a makeshift way to start working!


During work, and especially maintenance, always pay the greatest attention:

- Do not walk or stop under raised loads or machine parts supported by hydraulic cylinders or ropes only.
- Keep the machine handholds and access steps always clean from oil, grease or dirt to prevent falls or slips.



## Safety Precautions

- When entering/leaving the cab or other raised parts, always face the machine; never turn the back.



- When carrying out operations at hazardous heights (over 1.5 meters from the ground), always use approved fall restraint or fall arrest devices.
- Do not enter/leave the machine while it is running.
- Do not leave the driving place when the machine is running.
- Neither stop nor carry out interventions under or between the machine wheels when engine is running. When maintenance in this area is required, stop the engine.
- Do not carry out maintenance or repair works without a sufficient lighting.
- When using the machine lights, the beam should be oriented in order not to blind the personnel at work.
- Before applying voltage to electric cables or components, check their connection and proper functioning.
- Do not carry out interventions on electric components with voltage over **48V**.
- Do not connect wet plugs or sockets.
- Plates and hazard warning stickers shall never be removed, hidden or become unreadable.
- Except for maintenance purposes, do not remove safety devices, shields, protection cases, etc. Should their removal be necessary, stop the engine, remove them with the greatest care and always remember to refit them before starting the engine and using the machine again.
- Before any maintenance or repair work, stop the engine and disconnect the batteries.
- Do not lubricate, clean or adjust moving parts.

- Do not carry out operations manually when specific tools are provided for this purpose.
- Avoid the use of tools in bad condition or use in an improper way i.e. pliers instead of adjustable wrenches, etc.
- Applying loads in different points of the attachment holding plate is forbidden.

### **WARNING**

***Any intervention on the hydraulic circuit must be carried out by authorised personnel.***

***The hydraulic circuit of this machine is fitted with pressure accumulators. You and others could be seriously injured if accumulators are not completely depressurized.***

***For this purpose, shut the engine down and step on the brake pedal 8/10 times.***



- Before carrying out operations on hydraulic lines under pressure or disconnecting hydraulic components, ensure the relevant line has been previously depressurised and does not contain any hot fluid.
- Do not empty catalytic mufflers or other vessels containing burning materials without taking the necessary precautions.
- After any maintenance or repair work, make sure that no tool, cloth or other object has been left within machine compartments, fitted with moving parts, or where suction and cooling air circulates.
- When working, do not give instructions or signs to several people at the same time. Instructions and signs must be given by one person only.

## Safety Precautions

- Always pay due attention to the instructions given by the foreman.
- Never distract the operator during working phases or crucial manoeuvres.
- Do not call an operator suddenly, if unnecessary.
- Do not frighten an operator or throw objects by any means.
- After work, never leave the machine under potentially dangerous conditions.
- Before any maintenance or repair work, remove the attachment.

### MACHINE OPERATION HAZARDS

#### Absolutely avoid the following work situations:

- Do not handle loads beyond the maximum capacity of the machine.
- Do not raise or extend the boom if the machine is not on a firm, level surface.
- Do not operate the machine in strong wind. Do not increase the surface area of the machine or forked load exposed to the wind. Increasing the area exposed to the wind will decrease machine stability.
- Use extreme caution and slow speeds when the machine is driven across uneven or unstable grounds, slippery surfaces or near trenches or drop-offs.
- Limit travel speed according to ground conditions, slopes, presence of personnel or other factors which may cause collision.
- Do not place or attach overhanging loads to any part of the machine.

### EXPLOSION OR FIRE HAZARDS

- Do not start the engine if you smell or detect LPG, gasoline, diesel fuel or other explosive substances.
- Do not refuel the machine with the engine running.
- Refuel the machine and charge the battery only in a well ventilated area away from sparks, naked flames and lighted cigarettes.

- Do not operate the machine in dangerous environments or in places with flammable or explosive gases or materials.
- Do not inject ether in engines equipped with glow plugs.
- Do not leave fuel cans or bottles in unsuitable places.
- Neither smoke nor use open flames in areas subject to fire dangers and in presence of fuel, oil or batteries.
- Carefully handle all flammable or dangerous substances.
- Do not tamper with fire-extinguishers or pressure accumulators.

### DAMAGED COMPONENT HAZARDS

- Do not use battery chargers or batteries with a voltage above 12V to start the engine.
- Do not use the machine as a ground for welding.



### PERSONAL INJURY HAZARDS

- Do not operate the machine in case of hydraulic oil or air leak. Air or hydraulic oil leaks can penetrate or burn the skin.
- Always operate the machine in a well ventilated area to avoid carbon monoxide poisoning.
- Do not lower the boom if the area underneath is not clear of personnel or obstructions.

## Safety Precautions

### SUSPENDED LOAD HAZARDS

- A suspended load has a dynamic, and therefore unpredictable, effect on machine stability, so extreme caution should always be exercised when operating with suspended loads.
- Only lift the load when the telehandler is on firm level ground.
- Do not operate the machine while people are under a suspended load.
- All movements of the load must be accomplished at lowest possible speed.
- Do not lift loads when wind speeds exceed 20 mph (32 kmh).
- Level the telehandler before lifting the load.
- Use guide ropes or tag lines by qualified personnel to help control the load and prevent it from swinging.
- Do not attempt to use the telehandler frame-leveling to compensate for a swinging load.
- Never drag the load.
- Do not try to move fixed or obstructed loads.
- Only lift a load vertically; do not pull a load horizontally as it could cause excessive swinging of the load.
- When visibility is or could be obstructed, the operator shall use alternative/additional means to safely transport the load.
- Use of additional personnel to direct the operator in his movements as well as surrounding ground traffic.
- Speed shall be limited by any conditions that could cause any unexpected movement of the load, or jeopardize the safe transport of the load.
- The boom shall be fully retracted during travel.
- Only travel on solid surfaces.
- Start, travel, turn and stop slowly to prevent the load from becoming unstable or swing.
- Do not exceed walking speed.
- The load shall be transported as low to the ground as practical.
- Do not use any controls for re-positioning the load when traveling. Come to a gradual and complete stop before attempting to re-position the load.

### LLMI/ LLMC HAZARDS

The LLMI/LLMC will only function to the design specification:

- when the truck is static;
- when the truck is on consolidated, stable and level ground;
- when the truck is performing loading or placing functions;
- when the LLMI/LLMC is activated (not overridden);


The LLMI will only warn the operator in the event of inadequate stability in the longitudinal plane in the forward direction.

The LLMI/LLMC is not intended for warning of the risk of overturning in the case of:

- a sudden overload;
- travelling with the load in the elevated position;
- travelling on rough terrain or on grounds with obstacles and holes;
- travelling across a slope or turning on a slope;
- driving in bends too fast or too sharp;

Adjustments affecting the setting of the LLMI/LLMC shall be performed only by authorised personnel.

## Description Of The Machine



1. **Boom**
2. **Chassis**
3. **Forks**
4. **Attachment holding frame**
5. **Outrigger**
6. **Driving cab according to ROPS-FOPS provisions**
7. **Front axle**
8. **Fuel tank**
9. **Access step**
10. **Rear axle**
11. **Engine**



## Description Of The Machine

### GTH-4013 SX GENERAL DESCRIPTION

The machine mainly consists of a mobile carriage, equipped with an operator's cabin and a telescopic boom with a load handling attachment articulation capable to handle and carry payloads not exceeding the rated capacity of the machine.

The mechanical power necessary to move the machine and to operate the load handling mechanism is provided by a diesel engine installed on the right side of the machine and controlled by a mechanical pedal located inside the operator's cabin.

The diesel fuel feeding the engine is contained in a steel tank located on the left side of the chassis, immediately behind the operator's cabin. The engine powers three hydraulic pumps.

The bigger one, which is a piston type variable displacement pump, is directly flanged to the engine flywheel housing and is hydraulically linked to a piston type variable displacement hydraulic motor, which generates the torque necessary for the machine translation.

These two units are the main components of the hydrostatic transmission which is mechanically linked to the machine axles and wheels. In particular, the hydraulic motor is flanged to a mechanical drop box installed on a central structural beam linking the two sides of the chassis.

The mechanical torque generated by the hydrostatic motor and passing through the drop box, is transmitted to the front and rear axles by two drive shafts located on the machine centerline so providing a 4X4 wheels drive capability.

Both the hydrostatic pump and motor are hydraulically controlled and automatically adjust their functioning parameters against the engine rpm and the power requested by the pumps.

The four wheels are equipped with tires suitable to operate the machine in all the working conditions which have been foreseen for this model and capable to withstand the maximum loads generated by the machine weight and payloads.

The second gear type pump, flanged on the back of the bigger one and mechanically linked to that by a passing through PTO, produces the flow and pressure to move the telescopic boom and the load handling attachment articulation, to operate the front

stabilizers and the chassis leveling system and to power the steering system.

The third gear type pump is flanged to the engine distribution lateral PTO and powers the service brakes system.

These three pumps are fed through oil suction lines which are linked to the hydraulic oil tank installed on the bottom center of the chassis.

This oil tank, steel made, is provided also with the oil filter package (return type), the oil level gauges and the oil charging cap.

The engine and the three pumps are installed inside a suitable engine compartment consisting of a fixed lower bay made in steel and of a upper bonnet which can be opened to allow servicing activities in the engine compartment.

The engine compartment also includes the engine and hydraulic system cooler, provided with an internal coolant expansion tank, the air intake duct and filter, the electrical alternator, the battery, the fuel and the engine oil filters and the engine exhaust muffler.

The engine exhaust duct is then routed from the bottom of the engine compartment to the lateral back side of the chassis with a geometry capable to eject the engine exhaust gas up and back from the machine.

The telescopic boom, hinged on the back of the chassis, mainly consists in three steel tubes having rectangular sections and provided with a load handling attachment articulation for payload stuffing/unstuffing and transportation purposes. The outer section is hinged in the back top area of the chassis and moved by an hydraulic cylinder linked between its bottom surface and the central bottom area of the chassis.

The extension/retraction of this cylinder produces the boom outer section to rotate between the boom up and down limits.

The boom intermediate section can telescope with respect the outer one by a boom extension cylinder which is installed on the top of the boom. The inner section is moved by another telescope cylinder internally installed.

These two cylinders are hydraulically linked in series



## Description Of The Machine

and are designed in such a way the extension of the bigger one (moving the intermediate boom section) produces the same extension of the smaller one (moving the inner boom section).

At the top of the inner section a load handling attachment articulation is provided with a rotating carriage, which can be easily interfaced with a number of different attachments, and which is activated by another specific cylinder.

The different attachments selected for this machine can be easily replaced and are secured by a mechanical pin (standard feature) or by a hydraulic quick lock/unlock cylinder (optional).

The boom cylinders described before are driven through a main valve which is mechanically controlled through a main joystick lever located in the operator's cabin.

The same valve also controls the front stabilizers, hinged on the front area of the machine and actuated by specific hydraulic cylinders hinged between the chassis and the stabilizers legs, and the chassis lateral leveling system, activated by another specific cylinder hinged between the right side of the chassis and the front axle.

The operator can activate the stabilizers and the chassis leveling through mechanical levers located behind the main joystick controlling the boom functions.

Downstream of the main valve to additional hydraulic manifolds are installed. The first one reduces the speed of the boom down, boom telescope out, attachment tilt down and the flow rate to one of the two auxiliary lines when the longitudinal stability of the machine is approaching. The second hydraulic manifold changes over the telescope and the forks tilt functions according to the condition of a electrical switch installed on the top of the main joystick.

The other main controls available in the operator's cabin are the steering wheel (to control the machine steering function), the service brake pedal and the parking brake mechanical lever.

The steering wheel is mechanically connected to a steering unit which feeds the steering cylinders installed on the front and rear axles in such a way the steering angle is proportional to the steering wheel turns.

The service brake pedal is linked to a brake pump which is hydraulically powered and, according to the stroke of the pedal, generates a hydraulic pressure activating the service brakes disks package (wet type) which is installed inside the front and rear axles and works on the axle internal shafts.

The same brake disks package installed on the rear axle is operated by the parking brake system through an internal mechanism which is mechanically actuated and hydraulically released. When the parking brake is released, through the relevant handle located in the operator's cabin immediately on the left side of the operator's seat, a hydraulic pressure is applied to the internal mechanism so releasing the force on the brake disks. When the parking brake is activated this pressure is removed and the internal mechanism pushes on the brake disks so developing the requested braking force.

Another hydraulic cylinder is installed on the back left side of the chassis and is hinged between the chassis and the rear axle.

The aim of this cylinder is to improve the lateral stability of the machine by locking the rear axle when the boom angle is higher than a specified value.

The operator's cabin is of full enclosed type and provided with windshield and glasses to protect the operator and to the maximum visibility.

The operator is seated on a cushioned and adjustable seat and can operate the machine using the specific controls which have been properly located inside the cabin.

A dedicated dashboard is provided with all the necessary controls and gauges necessary to properly and safely operate the machine.

An automatic stability control system is provided with a display located inside the cabin and showing the stability status of the machine to the operator and a strain sensor installed on the rear axle and measuring the residual load on the axle.

The machine is also equipped with a complete set of road lights allowing a safe circulation on public roads in dark conditions.

A counterweight system is installed on the back area of the chassis to improve the longitudinal stability of the machine.

## Description Of The Machine

### GTH-4017 SX GENERAL DESCRIPTION

The machine mainly consists of a mobile carriage, equipped with an operator's cabin and a telescopic boom with a load handling attachment articulation capable to handle and carry payloads not exceeding the rated capacity of the machine.

The mechanical power necessary to move the machine and to operate the load handling mechanism is provided by a diesel engine installed on the right side of the machine and controlled by a mechanical pedal located inside the operator's cabin.

The diesel fuel feeding the engine is contained in a steel tank located on the left side of the chassis, immediately behind the operator's cabin.

The engine powers three hydraulic pumps.

The bigger one, which is a piston type variable displacement pump, is directly flanged to the engine flywheel housing and is hydraulically linked to a piston type variable displacement hydraulic motor, which generates the torque necessary for the machine translation.

These two units are the main components of the hydrostatic transmission which is mechanically linked to the machine axles and wheels. In particular, the hydraulic motor is flanged to a mechanical drop box installed on a central structural beam linking the two sides of the chassis.

The mechanical torque generated by the hydrostatic motor and passing through the drop box, is transmitted to the front and rear axles by two drive shafts located on the machine centerline so providing a 4X4 wheels drive capability.

Both the hydrostatic pump and motor are hydraulically controlled and automatically adjust their functioning parameters against the engine rpm and the power requested by the pumps.

The four wheels are equipped with tires suitable to operate the machine in all the working conditions which have been foreseen for this model and capable to withstand the maximum loads generated by the machine weight and payloads.

The second gear type pump, flanged on the back of the bigger one and mechanically linked to that by a passing through PTO, produces the flow and pressure to move the telescopic boom and the load handling attachment articulation, to operate the front

stabilizers and the chassis leveling system and to power the steering system.

The third gear type pump is flanged to the engine distribution lateral PTO and powers the service brakes system.

These three pumps are fed through oil suction lines which are linked to the hydraulic oil tank installed on the bottom center of the chassis.

This oil tank, steel made, is provided also with the oil filter package (return type), the oil level gauges and the oil charging cap.

The engine and the three pumps are installed inside a suitable engine compartment consisting of a fixed lower bay made in steel and of a upper bonnet which can be opened to allow servicing activities in the engine compartment.

The engine compartment also includes the engine and hydraulic system cooler, provided with an internal coolant expansion tank, the air intake duct and filter, the electrical alternator, the battery, the fuel and the engine oil filters and the engine exhaust muffler.

The engine exhaust duct is then routed from the bottom of the engine compartment to the lateral back side of the chassis with a geometry capable to eject the engine exhaust gas up and back from the machine.

The telescopic boom, hinged on the back of the chassis, mainly consists in four steel tubes having rectangular sections and provided with a load handling attachment articulation for payload stuffing/unstuffing and transportation purposes.

The outer section is hinged in the back top area of the chassis and moved by an hydraulic cylinder linked between its bottom surface and the central bottom area of the chassis.

The extension/retraction of this cylinder produces the boom outer section to rotate between the boom up and down limits.

The boom bigger intermediate section can telescope with respect the outer one by a boom extension cylinder which is installed on the top of the boom.

The smaller intermediate and the inner sections are moved by a chains system made by special chains, specifically designed for load lifting purposes, and by

## Description Of The Machine

pulleys and pins necessary to the chains to properly operate.

At the top of the inner section a load handling attachment articulation is provided with a rotating carriage, which can be easily interfaced with a number of different attachments, and which is activated by another specific cylinder.

The different attachments selected for this machine can be easily replaced and are secured by a mechanical pin (standard feature) or by a hydraulic quick lock/unlock cylinder (optional).

The boom cylinders described before are driven through a main valve which is mechanically controlled through a main joystick lever located in the operator's cabin.

The same valve also controls the front stabilizers, hinged on the front area of the machine and actuated by specific hydraulic cylinders hinged between the chassis and the stabilizers legs, and the chassis lateral leveling system, activated by another specific cylinder hinged between the right side of the chassis and the front axle.

The operator can activate the stabilizers and the chassis leveling through mechanical levers located behind the main joystick controlling the boom functions.

Downstream of the main valve to additional hydraulic manifolds are installed. The first one reduces the speed of the boom down, boom telescope out, attachment tilt down and the flow rate to one of the two auxiliary lines when the longitudinal stability of the machine is approaching. The second hydraulic manifold changes over the telescope and the forks tilt functions according to the condition of a electrical switch installed on the top of the main joystick.

The other main controls available in the operator's cabin are the steering wheel (to control the machine steering function), the service brake pedal and the parking brake mechanical lever.

The steering wheel is mechanically connected to a steering unit which feeds the steering cylinders installed on the front and rear axles in such a way the steering angle is proportional to the steering wheel turns.

The service brake pedal is linked to a brake pump which is hydraulically powered and, according to the stroke of the pedal, generates a hydraulic pressure activating the service brakes disks package (wet type) which is installed inside the front and rear axles and works on the axle internal shafts.

The same brake disks package installed on the rear axle is operated by the parking brake system through an internal mechanism which is mechanically actuated and hydraulically released. When the parking brake is released, through the relevant handle located in the operator's cabin immediately on the left side of the operator's seat, a hydraulic pressure is applied to the internal mechanism so releasing the force on the brake disks. When the parking brake is activated this pressure is removed and the internal mechanism pushes on the brake disks so developing the requested braking force.

Another hydraulic cylinder is installed on the back left side of the chassis and is hinged between the chassis and the rear axle.

The aim of this cylinder is to improve the lateral stability of the machine by locking the rear axle when the boom angle is higher than a specified value.

The operator's cabin is of full enclosed type and provided with windshield and glasses to protect the operator and to the maximum visibility.

The operator is seated on a cushioned and adjustable seat and can operate the machine using the specific controls which have been properly located inside the cabin.

A dedicated dashboard is provided with all the necessary controls and gauges necessary to properly and safely operate the machine.

An automatic stability control system is provided with a display located inside the cabin and showing the stability status of the machine to the operator and a strain sensor installed on the rear axle and measuring the residual load on the axle.

The machine is also equipped with a complete set of road lights allowing a safe circulation on public roads in dark conditions.

A counterweight system is installed on the back area of the chassis to improve the longitudinal stability of the machine.

## Description Of The Machine

### GTH-4013 EX GENERAL DESCRIPTION

The machine mainly consist of a mobile carriage, equipped with an operator's cabin and a telescopic boom with a load handling attachment articulation capable to handle and carry payloads not exceeding the rated capacity of the machine. The mechanical power necessary to move the machine and to operate the load handling mechanism is provided by a diesel engine installed on the right side of the machine and controlled by a mechanical pedal located inside the operator's cabin. The diesel fuel feeding the engine is contained in a steel tank located on the left side of the chassis, immediately behind the operator's cabin.

The engine powers three hydraulic pumps. The bigger one, which is a piston type variable displacement pump, is directly flanged to the engine flywheel housing and is hydraulically linked to a piston type variable displacement hydraulic motor, which generates the torque necessary for the machine translation. These two units are the main components of the hydrostatic transmission which is mechanically linked to the machine axles and wheels. In particular, the hydraulic motor is flanged to a two-speed mechanical gear box installed on a central structural beam linking the two sides of the chassis.

The mechanical torque generated by the hydrostatic motor and passing through the gear box, is transmitted to the front and rear axles by two drive shafts located on the machine centerline so providing a 4X4 wheels drive capability. Both the hydrostatic pump and motor are hydraulically controlled and automatically adjust their functioning parameters against the engine rpm and the power requested by the pumps.

The four wheels are equipped with tires suitable to operate the machine in all the working conditions which have been foreseen for this model and capable to withstand the maximum loads generated by the machine weight and payloads. The second gear type pump, flanged on the back of the bigger one and mechanically linked to that by a passing through PTO, produces the flow and pressure to move the telescopic boom and the load handling attachment articulation and to power the steering

system. The third gear type pump is flanged to the engine distribution lateral PTO and powers the service brakes system, the front stabilizers and the chassis leveling system. These three pumps are fed through oil suction lines which are linked to the hydraulic oil tank installed on the bottom center of the chassis. This oil tank, steel made, is provided also with the oil filter package (return type), the oil level gauges and the oil charging cap.

The engine and the three pumps are installed inside a suitable engine compartment consisting of a fixed lower bay made in steel and of a upper fiberglass bonnet which can be opened to allow servicing activities in the engine compartment.

The engine compartment also includes the engine and hydraulic system cooler, provided with an internal coolant expansion tank, the air intake duct and filter, the electrical alternator, the battery, the battery disconnection device, the fuel and the engine oil filters and the engine exhaust muffler.

The engine exhaust duct is then routed from the bottom of the engine compartment to the lateral back side of the chassis with a geometry capable to eject the engine exhaust gas up and back from the machine. The telescopic boom, hinged on the back of the chassis, mainly consists in three steel tubes having rectangular sections and provided with a load handling attachment articulation for payload stuffing/unstuffing and transportation purposes. The outer section is hinged in the back top area of the chassis and moved by an hydraulic cylinder linked between its bottom surface and the central bottom area of the chassis.

The extension/retraction of this cylinder produces the boom outer section to rotate between the boom up and down limits. The boom intermediate section can telescope with respect the outer one by a boom extension cylinder which is installed on the top of the boom. The inner section is moved by another telescope cylinder internally installed. These two cylinders are hydraulically linked in series and are designed in such a way the extension of the bigger one (moving the intermediate boom section) produces the same extension of the smaller one (moving the inner boom section).

## Description Of The Machine

At the top of the inner section a load handling attachment articulation is provided with a rotating carriage, which can be easily interfaced with a number of different attachments, and which is activated by another specific cylinder. This cylinder is hydraulically linked to another cylinder, hinged between the boom first section left side and the slewing turret bottom plate, providing an automatic forks leveling mechanism which maintains the forks automatically leveled when the boom is moved up and down.

The different attachments selected for this machine can be easily replaced and are secured by a mechanical pin (standard feature) or by a hydraulic quick lock/unlock cylinder (optional).

The boom cylinders described before are driven through a main valve which is electrically controlled through a main joystick lever located on the right armrest of the operator's seat. This valve is located in the rear area of the chassis, immediately underneath the boom hinge articulation.

Another hydraulic valve, on/off type, electrically actuated and located inside the engine compartment, controls the front stabilizers, hinged on the front area of the machine and actuated by specific hydraulic cylinders hinged between the chassis and the stabilizers legs, and the chassis lateral leveling system, activated by another specific cylinder hinged between the right side of the chassis and the front axle.

The operator can activate the stabilizers and the chassis leveling through electrical switches located on the left dashboard panel inside the cabin.

The other main controls available in the operator's cabin are the steering wheel (to control the machine steering function), the service brake pedal, the parking brake mechanical lever and the two-speed gear box shifting switch.

The steering wheel is mechanically connected to a steering unit which feeds the steering cylinders installed on the front and rear axles in such a way the steering angle is proportional to the steering wheel turns.

The service brake pedal is linked to a brake pump

which is hydraulically powered by the third pump installed on the engine distribution PTO and, according to the stroke of the pedal, generates a hydraulic pressure activating the service brakes disks package (wet type) which is installed inside the front and rear axles and works on the axle internal shafts. The same brake disks package installed on the rear axle is operated by the parking brake system through an internal mechanism which is mechanically actuated and hydraulically released. When the parking brake is released, through the relevant handle located in the operator's cabin immediately on the left side of the operator's seat, a hydraulic pressure is applied to the internal mechanism so releasing the force on the brake disks. When the parking brake is activated this pressure is removed and the internal mechanism pushes on the brake disks so developing the requested braking force. Another hydraulic cylinder is installed on the back left side of the chassis and is hinged between the chassis and the rear axle. The aim of this cylinder is to improve the lateral stability of the machine by locking the rear axle when the boom angle is higher than a specified value.

The operator's cabin is of full enclosed type and provided with windshield and glasses to protect the operator and to the maximum visibility.

The operator is seated on a cushioned and adjustable seat and can operate the machine using the specific controls which have been properly located inside the cabin.

A dedicated dashboard is provided with all the necessary controls and gauges necessary to properly and safely operate the machine.

An automatic stability control system is provided with a display located inside the cabin and showing the stability status of the machine to the operator and a strain sensor installed on the rear axle and measuring the residual load on the axle.

The machine is also equipped with a complete set of road lights allowing a safe circulation on public roads in dark conditions.

A counterweight system is installed on the back area of the chassis to improve the longitudinal stability of the machine.



## Description Of The Machine

### GTH-4017 EX GENERAL DESCRIPTION

The machine mainly consist of a mobile carriage, equipped with an operator's cabin and a telescopic boom with a load handling attachment articulation capable to handle and carry payloads not exceeding the rated capacity of the machine.

The mechanical power necessary to move the machine and to operate the load handling mechanism is provided by a diesel engine installed on the right side of the machine and controlled by a mechanical pedal located inside the operator's cabin.

The diesel fuel feeding the engine is contained in a steel tank located on the left side of the chassis, immediately behind the operator's cabin.

The engine powers three hydraulic pumps. The bigger one, which is a piston type variable displacement pump, is directly flanged to the engine flywheel housing and is hydraulically linked to a piston type variable displacement hydraulic motor, which generates the torque necessary for the machine translation.

These two units are the main components of the hydrostatic transmission which is mechanically linked to the machine axles and wheels. In particular, the hydraulic motor is flanged to a two-speed mechanical gear box installed on a central structural beam linking the two sides of the chassis.

The mechanical torque generated by the hydrostatic motor and passing through the gear box, is transmitted to the front and rear axles by two drive shafts located on the machine centerline so providing a 4X4 wheels drive capability.

Both the hydrostatic pump and motor are electronically controlled by an electronic control unit located inside the operator's cabin immediately behind the operator's seat.

The four wheels are equipped with tires suitable to operate the machine in all the working conditions which have been foreseen for this model and capable to withstand the maximum loads generated by the machine weight and payloads.

The second gear type pump, flanged on the back of the bigger one and mechanically linked to that by a passing through PTO, produces the flow and pressure to move the telescopic boom and the load handling attachment articulation and to power the

steering system.

The third gear type pump is flanged to the engine distribution lateral PTO and powers the service brakes system, the front stabilizers and the chassis leveling system and the engine cooler fan hydraulic motor. These three pumps are fed through oil suction lines which are linked to the hydraulic oil tank installed on the bottom center of the chassis. This oil tank, steel made, is provided also with the oil filter package (return type), the oil level gauges and the oil charging cap.

The engine and the three pumps are installed inside a suitable engine compartment consisting of a fixed lower bay made in steel and of a upper fiberglass bonnet which can be opened to allow servicing activities in the engine compartment.

The engine compartment also includes the engine and hydraulic system cooler, provided with an additional coolant expansion tank and with a remote coolant fan hydraulically powered, the air intake duct and filter, the electrical alternator, the battery, the battery disconnection device and the fuel and the engine oil filters.

The engine exhaust duct is then routed from the bottom of the engine compartment to the lateral back side of the chassis where the engine exhaust muffler is installed with a final duct having a geometry capable to eject the engine exhaust gas up and back from the machine.

The telescopic boom, hinged on the back of the chassis, mainly consists in four steel tubes having rectangular sections and provided with a load handling attachment articulation for payload stuffing/unstuffing and transportation purposes.

The outer section is hinged in the back top area of the chassis and moved by an hydraulic cylinder linked between its bottom surface and the central bottom area of the chassis.

The extension/retraction of this cylinder produces the boom outer section to rotate between the boom up and down limits.

The boom bigger intermediate section can telescope with respect the outer one by a boom extension cylinder which is installed on the top of the boom. The smaller intermediate and the inner sections are moved by a chains system made by special chains,

## Description Of The Machine

specifically designed for load lifting purposes, and by pulleys and pins necessary to the chains to properly operate.

At the top of the inner section a load handling attachment articulation is provided with a rotating carriage, which can be easily interfaced with a number of different attachments, and which is activated by another specific cylinder.

This cylinder is hydraulically linked to another cylinder, hinged between the boom first section left side and the slewing turret bottom plate, providing an automatic forks leveling mechanism which maintains the forks automatically leveled when the boom is moved up and down.

The different attachments selected for this machine can be easily replaced and are secured by a mechanical pin (standard feature) or by a hydraulic quick lock/unlock cylinder (optional).

The boom cylinders described before are driven through a main valve which is electrically controlled through a main joystick lever located on the right armrest of the operator's seat. This valve is located in the rear area of the chassis, immediately underneath the boom hinge articulation.

Another hydraulic valve, on/off type, electrically actuated and located inside the engine compartment, controls the front stabilizers, hinged on the front area of the machine and actuated by specific hydraulic cylinders hinged between the chassis and the stabilizers legs, and the chassis lateral leveling system, activated by another specific cylinder hinged between the right side of the chassis and the front axle.

The operator can activate the stabilizers and the chassis leveling through electrical switches located on the left dashboard panel inside the cabin.

The other main controls available in the operator's cabin are the steering wheel (to control the machine steering function), the service brake pedal, the parking brake mechanical lever and the two-speed gear box shifting switch.

The steering wheel is mechanically connected to a steering unit which feeds the steering cylinders installed on the front and rear axles in such a way the steering angle is proportional to the steering wheel turns.

The service brake pedal is linked to a brake pump which is hydraulically powered by the third pump installed on the engine distribution PTO and, according to the stroke of the pedal, generates a hydraulic pressure activating the service brakes disks package (wet type) which is installed inside the front and rear axles and works on the axle internal shafts. The same brake disks package installed on the rear axle is operated by the parking brake system through an internal mechanism which is mechanically actuated and hydraulically released. When the parking brake is released, through the relevant handle located in the operator's cabin immediately on the left side of the operator's seat, a hydraulic pressure is applied to the internal mechanism so releasing the force on the brake disks. When the parking brake is activated this pressure is removed and the internal mechanism pushes on the brake disks so developing the requested braking force. Another hydraulic cylinder is installed on the back left side of the chassis and is hinged between the chassis and the rear axle. The aim of this cylinder is to improve the lateral stability of the machine by locking the rear axle when the boom angle is higher than a specified value.

The operator's cabin is of full enclosed type and provided with windshield and glasses to protect the operator and to the maximum visibility.

The operator is seated on a cushioned and adjustable seat and can operate the machine using the specific controls which have been properly located inside the cabin.

A dedicated dashboard is provided with all the necessary controls and gauges necessary to properly and safely operate the machine.

An automatic stability control system is provided with a display located inside the cabin and showing the stability status of the machine to the operator and a strain sensor installed on the rear axle and measuring the residual load on the axle.

The machine is also equipped with a complete set of road lights allowing a safe circulation on public roads in dark conditions.

A counterweight system is installed on the back area of the chassis to improve the longitudinal stability of the machine.

## Description Of The Machine

### ALLOWED USE

The telehandlers have been designed and manufactured for lifting, handling and transporting agricultural or industrial products by means of specific attachments (See "Optional Attachments" chapter) manufactured by TEREXLIFT.

Any other use is considered contrary to that established and, therefore, improper.

The compliance with and the strict respect of the operation, maintenance and repair conditions, indicated by the Manufacturer, represent an essential part of the allowed use.

The telehandler must be used and serviced only by operators knowing its characteristics and the safety procedures in depth.

It is also essential to comply with the safety at work legislation, the precautions concerning safety and industrial medicine as well as the local and national road traffic regulations.

The telehandler can be used in residential and commercial environment, light industry and industry.



***Effecting changes or carrying out interventions on the machine other than those of routine maintenance is expressly forbidden. Any modification of the machine not carried out by TEREXLIFT or an authorised assistance centre involves the automatic invalidation of the conformity of the machine to the Directive 2006/42/EC.***



***Please check the accessories available for your machine.***

### IMPROPER USE

Improper use means a utilisation of the telehandler following working criteria that do not comply with the instructions of this manual, and that, in general, may result in risks for both operators and bystanders.




***We list below some of the most frequent and hazardous situations of improper use:***

- ***Carrying passengers on the machine***
- ***Not strictly complying with the operation and maintenance instructions of this handbook***
- ***Working beyond the handler working limits***
- ***Working on unstable edges of ditches***
- ***Driving crosswise on slopes or hills***
- ***Working during a storm***
- ***Working on steep slopes***
- ***Using attachments other than those recommended***
- ***Using attachments not approved or directly manufactured by TEREXLIFT***
- ***Working in potentially explosive areas***
- ***Working in confined and non-ventilated environments.***
- ***Working in poorly enlightened area.***



## Controls And Instruments




1. Fresh Air Flap
2. Forward/Reverse Gear Selector  
- Horn
3. Steering Column Angle Adjustment
4. Turn Signals - Windscreen Washer  
- Lights
5. Auxiliary Drive Controls
6. Load Limiter Disable Selector
7. Load Moment Indicator (Llmi/  
Llmc)
8. Emergency Stop Pushbutton


9. Instruments Dashboard
10. Inclinometer
11. Multipurpose Control Lever
12. Movements Control Levers  
(Only For Sx)
13. Throttle Pedal
14. Service Brake Pedal
15. Cab Heater Control Cock
16. Fuses And Relays Board
17. Parking Brake Lever
18. Manual Accelerator

## Controls And Instruments

### GTH-4013 SX GTH-4017 SX





- 19.Outriggers Switches
- 20.Chassis Levelling Switch
- 21.Cab/Road/Platform Selector
- 22.Hydraulic Mixing Bucket Oil Direction Switch (OPTIONAL)
- 23.Mixing Bucket Switch (OPTIONAL)
- 24.Ignition Switch
- 25.Auxiliary Hydraulic Circuit Switch (OPTIONAL)



- 26.Emergency Pump Switch (ONLY with MAN-PLATFORM)
- 27.Steering Mode Selector
- 28.Hazard Warning Lights Switch
- 29.Work Lights Switch (OPTIONAL)
- 30.Road Lights Switch
- 31.Cab Heater Fan Switch
- 32.Air Conditioning Switch (OPTIONAL)
- 33.Road/Jobsite switch

### GTH-4013 EX GTH-4017 EX



## Controls And Instruments


### IGNITION SWITCH


Four-position switch:


**P** Position of the ignition key to switch the controls from cab to platform.

**O** No circuit under voltage, key can be removed and engine is stopped.

**I** Circuits under voltage, presetting for the engine starting. Board controls and instruments are on.

 Thermal starter for cold climates. Turn the key to this position and hold it for 10÷15 seconds, then turn it to pos. Engine starting.

 Engine starting; when released, key springs back to pos. I automatically.




### FORWARD/REVERSE GEAR SELECTOR

Three-position switch with lock in neutral position:

**0** Neutral position; no gear engaged


**1** Shift lever to pos. 1 to select the forward gear

**2** Shift lever to pos. 2 to select the reverse gear



### HORN FUNCTION

When sliding the lever along its axis, horn switches on, independently from other pre-set functions.




## Controls And Instruments

### TURN SIGNALS - WINDSCREEN WIPER - LIGHTS

#### **Windscreen Washer Function:**


Push the second stage of the lever along its axis to direct a jet of water onto the cab windscreen.



#### **Windscreen Wiper Function:**

To operate the windscreen wiper, rotate the lever tip to one of the four positions:


- Intermittence
- 0 Wiper OFF
- I Low speed
- II High speed



#### **Lights Function:**


To switch the handler lights, lever can be set to three different positions along its vertical axis:

- 0 low beam ON, stable condition
- 1 high beam ON, stable condition
- 2 high beam used for intermittent signalling; when released, the lever springs back to position 0.



#### **Turn Signals Function:**

Set lever to pos. 1 to indicate a turn leftwards or to pos. 2 to indicate a turn rightwards.




## Controls And Instruments

### BRAKES

#### 14\_Service Brake Pedal (Transmission Inching Function)

This function allows to progressively reduce the machine travel speed but with no effect on the boom functions speed. It is controlled through the service brake pedal which, during the first part of its stroke, proportionally reduces the transmission pump displacement and consequently the machine travel speed. During the second part of the brake pedal stroke the machine is completely stopped and the full braking forces is applied.



#### 17\_Parking Brake Lever

To engage the parking brake, pull the lever upward while holding the locking button pressed down. Release the button when reaching the required braking tension. It operates on the axle shafts of the rear axle and, when engaged, it cuts both forward and reverse gear off.

## NOTICE

**Never use the parking brake to slow down the machine, unless in an emergency. It may reduce the brake efficiency.**

### ACCELERATOR CONTROL

#### 13\_Throttle Pedal

Its pressure controls the engine rpm and the machine speed. It is fitted with an adjustable stop in the lower part.

#### 18\_Manual Accelerator

By pulling the lever up, the engine rpm increases gradually. To reduce the rpm, set the lever down.



**The manual gas control can only be used with man-platform, winch, mixing bucket, hook and maintenance jib.**


### SAFETY AND EMERGENCY DEVICES

#### 28\_Hazard Warning Lights Switch



Fitted with on-off position, it switches on the turn signals simultaneously. When the hazard warning light is lit, the relevant switch and the turn signals light start flashing.

#### 8\_Emergency Stop Pushbutton



By pressing this button, the engine of the machine is shut down.

Before restarting the machine, it is necessary to reset the pushbutton by rotating it clockwise.

#### 26\_Emergency Pump Switch (OPTIONAL)

Two position switch:



0 OFF

1 Hold pressed down to turn on the electric pump and operate the controls

## Controls And Instruments



**Check the operation of the emergency pump every week as it could get damaged if it is not used.**

### 6\_Load Limiter Disable Selector

**The load limiter can be deactivated operating the key-selector when the boom is fully retracted, see dedicated paragraph into "Operating Instruction" section.**




**Working with the load limiting system cut out can result in a machine overturning and in serious injury.**

**The load limiting system deactivation key is active only in the Jobsite mode. In the Platform mode, the limiting system cannot be deactivated.**

## STEERING MODE SELECTION

### 27\_Steering Mode Switch

Three-position switch for the selection of the steering mode:




#### 27.1\_Rear Wheel Alignment Indicator Light

The indicator light comes on when turning the steering selector switch from position **1** to position **0** or from position **2** to position **0**, and wheels are aligned.

### 33\_Road/Jobsite Switch

Switch with two positions, fitted with a position locking device **B** :



- 1** The switch is on and the jobsite mode is enabled.
- 2** The switch is off and the machine is set to road transfer mode.

The selector has a safety block to avoid any accidental switching. Before switching the selector to another position, unlock control **B** at the top of the selector.

In **Jobsite** mode:

- all the machine functions are enabled


In **Road transfer** mode:

- the boom movement is disabled
- only the two-wheel steering mode is enabled
- fuel saving

## JOB-SITE/ROAD/PLATFORM SELECTION

### 21\_Job-site/Road/Platform Selector

Three-position switch:



**1 Job-site setting** (operate the handler by the cab controls)

**0 Road setting**

**2 Platform setting** (operate the handler by the platform controls)  
The green light indicator lights up.

In **Jobsite** mode:

- all the machine functions are enabled

In **Road transfer** mode:

- the boom movements, outriggers and sway controls are disabled

- only the two-wheel steering mode is enabled

In **Platform** mode:

- the only enabled functions are: boom lowering/lifting and boom extraction/retraction


- all the controls from the cabin are disabled.

## Controls And Instruments

### AUXILIARY DRIVE CONTROLS


#### 31\_Cab Heater Fan Switch

Three-position switch:

	0	OFF
	1	Low speed
	2	High speed


#### 30\_Road Lights Switch

Three-position switch:

	0	Lights OFF
	1	Position lights ON (the switch indicator lights up partially).
	2	Low beam ON (the switch indicator fully lights up).


#### 32\_Air Condition Switch (OPTIONAL)

Two-position switch:

	0	OFF
	1	ON

#### 29\_Work Lights Switch (OPTIONAL)

Two-position switch:

	0	Lights OFF
	1	Lights ON


#### 15\_Cab Heater Control Cock

Located on the left side of the driving seat base.

- Turn the cock clockwise to switch off heated air.
- Turn the cock counter-clockwise to switch on the cab heater.
- Adjust the flow of heated air in the cab operating the switch 31.

#### 25\_Auxiliary Hydraulic Circuit (OPTIONAL)


Two-position switch. The pressure of this button causes the switching of the hydraulic circuit for the movement of the attachments equipped with auxiliary lines:

	0	Oil to the main circuit
	1	Attachments hydraulic circuit switching

The selector has a block to keep the switch pressed. Before switching the selector to another position, unlock control **B** at the top of the selector.

#### 23\_Mixing Bucket Switch (OPTIONAL)


Two-position switch. The pressure of this button enables the hydraulic mixing bucket functioning.

	0	Mixer OFF
	1	Mixer ON

The selector has a block to keep the switch pressed. Before switching the selector to another position, unlock control **B** at the top of the selector.


#### 22\_Hydraulic Mixing Bucket Oil Direction Switch (OPTIONAL)

Three-position switch. The pressure of this button regulates the oil flow direction towards right or left.

	2	Oil flow towards left
	0	No oil to the mixing bucket
	1	Oil flow towards right

## Controls And Instruments

### WARNING LIGHTS AND INSTRUMENTS





## Controls And Instruments

### Descriptions

#### **34\_ Warning light - glow plugs preheating**

This light comes on during the pre-heating of the engine glow plugs.

#### **35\_ Warning light - low battery charge**

Signals a low charge by the alternator.

#### **36\_ Warning light - low engine oil pressure**

It lights when the engine oil pressure is too low.

#### **37\_ Warning light - air filter restricted**

When this lamp comes on, proceed with cleaning or changing the air filter cartridge.

#### **38\_ Not Active**

#### **39\_ Warning light - parking brake engaged**

When ON, this light indicates that the parking brake is engaged.

#### **40\_ Warning light - low brake pressure**

It lights when the pressure of the braking circuit is too low for a correct functioning.

#### **41\_ Warning light - high beam**

Warning light that signals when high beam is ON.

#### **42\_ Warning light - turn signals**

Indicator light that signals when turn signals are ON.

#### **43\_ Warning light - position lights**

Warning light that signals when position lights are ON.

#### **44\_ General alarm warning light**

This red light comes on to warn of a problem of the machine. Contact the TEREXLIFT Service Centre.

#### **45\_ Warning light - low hydraulic oil level**

This light comes on to alert to a low level of the hydraulic oil for a correct functioning. Replenish and eliminate the oil leak

#### **46\_ Warning light - hydraulic oil filter clogged**

When this lamp sets to on, immediately change the oil filter on the return line to the tank.

#### **47\_ Warning light - machine levelling (ONLY WITH MAN-PLATFORM)**

Indicator light that signals when the machine on outriggers is levelled within a range of  $\pm 2^\circ$ .

#### **48\_ Engine coolant temperature indicator**

This indicates the engine coolant temperature. If the finger is in the red zone and the warning light **48.1** comes on, you must stop the machine and find and rectify the problem.

#### **49\_ Hour-meter**

Signals the total operating hours of the machine. Use the hour-meter to gauge the routine maintenance jobs.

#### **50\_ Hydraulic oil temperature indicator**

This indicates the temperature of the hydraulic oil in the tank. If the temperature rises above the permissible value or the warning light **50.1** comes on, you must stop the machine and find and rectify the problem.

#### **51\_ Fuel gauge**

This indicates the fuel level in the tank. If the fuel level is low (reserve), the relevant warning light **51.1** comes on.

#### **52\_ Warning light - control box error**


This red light comes on to warn of a problem of the machine MC2M control box. When a failure is signalled, **warning light 52** starts flashing representing an alarm code. The meaning of these alarm codes is shown in section "**Faults and Troubleshooting**". Contact the TEREXLIFT Service Centre.

## Controls And Instruments

### CONTROL LEVERS FOR SX

The handlers are equipped with a joystick **11** with servo-assisted hydraulic control for the boom lifting/lowering movements and the boom telescopes out/in movements. The joystick can be shifted to any of the four directions, that is forward, backward, to the right or to the left. Pressing the red button **5** on the joystick switches the telescope out/in movement to the attachment frame pitching.

On the right side, at the back of the joystick, there are three levers **12** for the independent operation of the following functions: machine sway control, left and right outrigger movements.



**Seize the control lever correctly and move it gently.**


**The motion speed of the actuators depends on the lever position: a small motion results in a slow motion of the actuators; vice versa, a full range motion of the lever corresponds to the max. speed of the actuator.**



**The control lever shall be operated only when the operator is correctly seated in the driving place.**



**Before operating the control lever, make sure that nobody is within the working range of the machine.**



## Controls And Instruments

### Function Selection

The joystick **11** is enabled to carry out the following functions:

Without pressing button **5**:


- Boom lifting/lowering to activate the function shift the joystick to B or A
- Boom extension/retraction to activate the function shift the joystick to D or C

Pressing button **5**:

- Boom lifting/lowering to activate the function shift the joystick to B or A
- Attachment frame backward/forward pitching to activate the function shift the joystick to C or D

The four levers **12** control the following functions in an independent way:

- 1 Machine sway function
- 2 Right outrigger movement
- 3 Left outrigger movement
- 4 Attachment locking/unlocking (*OPTIONAL*)



## Controls And Instruments



### Boom Lifting/Lowering



*Before operating the boom, make sure that nobody is within the working range of the machine.*

To lift or lower the boom:

- Smoothly shift the lever to position B to lift the boom or to position A to lower it.



## Controls And Instruments



### Boom Extension/Retraction



*Before operating the boom, make sure that nobody is within the working range of the machine.*

To extend or retract the telescopic elements of the boom:

- Smoothly shift the lever to position D to extend the boom or to position C to retract it.



## Controls And Instruments



### Attachment Holding Frame Pitching



*Before operating the boom, make sure that nobody is within the working range of the machine.*

To pitch forward/backward the attachment holding frame:

- Press the button 5 on the joystick
- Smoothly shift the lever to position D to pitch the holding frame forward or to position C to pitch the holding frame backward.



## Controls And Instruments


### Attachments Quick-Coupling (OPTIONAL)




**Before operating the boom, make sure that nobody is within the working range of the machine.**

To lock/unlock the attachments:

- Shift the lever 4 toward the cab windscreen D to release the attachment
- Shift the lever toward the operator's seat C to lock the attachment.



**Before using the machine, visually check the attachment is correctly coupled.**



## Controls And Instruments


### Machine Sway Control



**Check that the machine is level on inclinometer 10. The water level must be right in the middle of the instrument.**

To sway the machine:


- Shift the lever 1 toward the cab windscreen D to sway the machine by lowering the right side
- Shift the lever toward the operator's seat C to sway the machine by lowering the left side.



**Machine levelling and outriggers control activation is affected by the boom position and extension, as shown in the chart below:**

#### FOR GTH-4013 SX

- AREA A**, within this area controls can be always activated, regardless of boom angle and extension.
- AREA B**, within this area controls cannot be activated unless the boom is fully retracted.
- AREA C**, within this area controls cannot be activated.



### Outriggers Movement



**Before lowering the outriggers, make sure that nobody is within the working range of the machine.**

To operate the outriggers:

- Shift the lever 2 or 3 (depending on the outrigger to move, right and left respectively) to position A to lower the outrigger
- Shift the lever to position B to raise the outrigger.

#### FOR GTH-4017 SX

- controls cannot be activated if the boom is over 20°.




## Controls And Instruments

### CONTROL LEVER FOR EX

The handlers are equipped with a multipurpose electro-proportional joystick **11** which allows operating all the machine movements.

When shifted to one of the four directions (right/left, forward/backward) it controls the boom lifting/lowering and the forward/back pitching of the attachment frame.

Moving the roller **2** or pressing the button **1** you can make all the boom movements.



**Seize the control lever correctly and move it gently.**

**The motion speed of the actuators depends on the lever position: a small motion results in a slow motion of the actuators; vice versa, a full range motion of the lever corresponds to the max. speed of the actuator.**



**The control lever shall be operated only when the operator is correctly seated in the driving place.**



**Before operating the control lever, make sure that nobody is within the working range of the machine.**




## Controls And Instruments

### Function Selection

The joystick **11** is enabled to carry out the following functions:

- Boom lifting/lowering, to activate the function shift the joystick to B or A
- Boom extension/retraction, to activate the function move the roller 2 to A or B without shifting the joystick
- Attachment frame backward/forward pitching, to activate the function shift the joystick to C or D
- Attachment locking/unlocking, to activate the function press the button 1 and shift the joystick to C or D



## Controls And Instruments



### Boom Lifting/Lowering



*Before operating the boom, make sure that nobody is within the working range of the machine.*

To lift or lower the boom:

- Smoothly shift the lever to position B to lift the boom or to position A to lower it.



## Controls And Instruments



### Boom Extension/Retraction



*Before operating the boom, make sure that nobody is within the working range of the machine.*

To extend or retract the telescopic elements of the boom:

- Smoothly move the roller 2 to A to extend the boom or to B to retract it, without shifting the joystick.



## Controls And Instruments


### Attachment Holding Frame Pitching



*Before operating the boom, make sure that nobody is within the working range of the machine.*

To pitch forward/backward the attachment holding frame:

- Smoothly shift the lever to position D to pitch the holding frame forward or to position C to pitch the holding frame backward.



## Controls And Instruments

### Attachments Quick-Coupling





*Before operating the boom, make sure that nobody is within the working range of the machine.*

To lock/unlock the attachments:

- Press the button 1
- Shift the lever to position D to release the attachment
- Shift the lever to position C to lock the attachment.



*Before using the machine, visually check the attachment is correctly coupled.*



## Controls And Instruments

### Machine Sway Control



**Check that the machine is level on inclinometer 10. The water level must be right in the middle of the instrument.**

To sway the machine:

- Press button 20 and hold it down until the complete execution of the function selected:  
select A to raise the right-hand side of the machine  
select B to lower the right-hand side of the machine.




### FOR GTH-4013 EX

Machine levelling and outriggers control activation is affected by the boom position and extension, as shown in the chart below:

**AREA A**, within this area controls can be always activated, regardless of boom angle and extension.

**AREA B**, within this area controls cannot be activated unless the boom is fully retracted.

**AREA C**, within this area controls cannot be activated.



### FOR GTH-4017 EX

controls cannot be activated if the boom is over 20°.

### Outriggers Movements



**Before lowering the outriggers, make sure that nobody is within the working range of the machine.**

To operate the outriggers:

Left outrigger

- Press button 19a and hold it down to enable the motion of the left outrigger:

select A to lower the outrigger


select B to raise the outrigger

Right outrigger

- Press button 19b and hold it down to enable the motion of the right outrigger:

select A to lower the outrigger

select B to raise the outrigger



## Controls And Instruments

### MANUAL CONTROLS - GTH-4013 EX & GTH-4017 EX

If the control lever is malfunctioning or a function cannot be operated, it is possible to use the emergency manual controls of the main valve. The main valve has two control levers that operate the following functions:

**Lever 1** In position **A** Boom down

In position **B** Boom up

**Lever 2** In position **A** Boom telescope in

In position **B** Boom telescope out



**The manual controls can be used only if the machine is running or it is equipped with the emergency pump.**

In order to operate the emergency pump with the manual controls, follow the instructions below:

- Press the emergency stop button in the cabin or in the platform.
- Open the rear cover to reach the main valve.
- Fit the control levers (supplied) to the elements of the main valve.
- Activate the emergency pump by holding button **Z** pressed down. If the button is released, the pump stops.
- Shift the lever of the main valve to the position corresponding to the movement you wish to obtain.




**When operating the emergency controls in manual mode, the load limiting device is disabled.**



**For the use of the emergency controls, observe the following sequence:**

**Lever 2 in A Boom fully retracted**

**Lever 1 in A Boom lowered**







---

**Make sure:**

- ☒ You learn and practice the principles of safe machine operation contained in this operator's manual.

- 1 Avoid hazardous situations.
- 2 **Always perform a pre-operation inspection.**

**Know and understand the pre-operation inspection before going on to the next section.**

- 3 Always perform function tests prior to use.
- 4 Inspect the workplace.
- 5 Only use the machine as it was intended.

## **PRE-OPERATION INSPECTION FUNDAMENTALS**

It is the responsibility of the operator to perform a pre-operation inspection and routine maintenance.

The pre-operation inspection is a visual inspection performed by the operator prior to each work shift. The inspection is designed to discover if anything is apparently wrong with a machine before the operator performs the function tests.

The pre-operation inspection also serves to determine if routine maintenance procedures are required. Only routine maintenance items specified in this manual may be performed by the operator.

Refer to the list on the next page and check each of the items.

If damage or any unauthorized variation from factory delivered condition is discovered, the machine must be tagged and removed from service.

Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications. After repairs are completed, the operator must perform a pre-operation inspection again before going on to the function tests.

Scheduled maintenance inspections shall be performed by qualified service technicians, according to the manufacturer's specifications.

# Inspections

## PRE-OPERATION INSPECTION

- Make sure the operator's manual is intact, legible and placed inside the machine.
- Make sure all decals are present and legible. See "**Labels and plates applied on the machine**" chapter.
- Check for engine oil leaks and proper oil level. Top up if necessary. See "**Maintenance**" chapter.
- Check for axle oil leaks and proper oil level. Top up if necessary. See "**Maintenance**" chapter.
- Check for hydraulic oil leaks and proper oil level. Top up if necessary. See "**Maintenance**" chapter.
- Check for engine coolant leaks and proper coolant level. Add coolant if necessary. See "**Maintenance**" chapter.
- Check for battery fluid leaks and proper fluid level. Add distilled water if necessary. See "**Maintenance**" chapter.

Check the following components or zones for damage, missing or wrongly fitted parts or non-authorised modifications:

- electrical components, wiring and electrical cables
- hydraulic hoses, fittings, cylinders and main valves
- fuel and hydraulic oil tanks
- drive pump and motor and transmission axles
- steering system
- braking system
- boom telescopes sliding pads
- visually check the boom chains tensioning
- clean glasses, lights and rear view mirrors
- engine and relevant components
- horn
- lights
- machine ignition control
- nuts, bolts and other fasteners

Check the entire machine for:

- cracks on welds or structural components
- dents or damage to the machine

- \* Make sure that all structural and other critical components are present and the relevant fasteners and pins are fitted and properly tightened.
- \* After inspection, check that all the compartment covers are in place and latched.



**WARNING**  
*If even one single item is damaged or defective, do not start work. Stop the machine and repair the fault.*

### Checking the tyres

- \* Check the correct inflation of the tyres; see par. "**Tyres and Wheels**" in the Maintenance section.
- \* Make sure that the tyre plies are not cut or worn.



**WARNING**  
*A tyre burst may result in serious injury; never use the machine if tyres are worn, wrongly inflated or damaged.*



**NOTICE**  
*If the machine shall be used in a marine or equivalent environment, protect it against salt deposits with an adequate treatment against saltiness to prevent rust formation.*

# Inspections

## FUNDAMENTAL FUNCTION TESTS

**Know and understand the function tests before going on to the next section.**

The function tests are designed to discover any malfunctions before the machine is put into service. The operator must follow the step-by-step instructions to test all machine functions. A malfunctioning machine must never be used. If malfunctions are discovered, the machine must be tagged and removed from service. Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications. After repairs are completed, the operator must perform a pre-operation inspection and function tests again before putting the machine into service.

### Make sure:

- ☑ You learn and practice the principles of safe machine operation contained in this operator's manual.
  - 1 Avoid hazardous situations.
  - 2 **Always perform a pre-operation inspection.**
  - 3 Always perform function tests prior to use.
  - 4 Inspect the workplace.
  - 5 Only use the machine as it was intended.

### Tests

- 1 Select a test area that is firm, level and free of obstruction. Be sure there is no load on the forks or attachment.
- 2 Enter the operator's compartment and sit on the seat.
- 3 Fasten the seat belt.
- 4 Adjust all the mirrors. See par "**Adjusting the Mirrors**" in the Operating Instructions section.
- 5 Be sure the parking brake is on and the transmission control is in neutral.
- 6 Start the engine. See par. "**Starting the Engine**" in the Operating Instructions section.

### Test the Control Lever (for SX)

- 7 Using the control lever, momentarily raise and lower the boom, extend and retract the boom.
  - ⦿ Result: All functions should operate smoothly.
- 8 Using the control lever and the red button, momentarily tilt the forks up and tilt the forks down.
  - ⦿ Result: The function should operate smoothly.
- 9 Using the control lever **4**, momentarily lock and unlock the attachment (OPTIONAL).
  - ⦿ Result: The function should operate smoothly.

### Test the Control Lever (for EX)

- 10 Using the control lever, momentarily raise and lower the boom, tilt the forks up and tilt the forks down.
  - ⦿ Result: All functions should operate smoothly.
- 11 Using the yellow roller, momentarily extend and retract the boom.
  - ⦿ Result: The function should operate smoothly.
- 12 Pressing the white button and moving the control lever, momentarily lock and unlock the attachment.
  - ⦿ Result: The function should operate smoothly.

## Inspections

### Test the Steering

- 14 Rotate the steering mode selector toward right to select the four-wheel steering mode.
- 15 Check the steering operation by turning the steering wheel approximately  $\frac{1}{4}$  turn in each direction.
  - ⦿ Result: The front wheels should turn in the same direction as the steering wheel. The rear wheels should turn in the opposite direction.
- 16 Straighten the wheels.
- 17 Rotate the steering mode selector to the middle position to select two-wheel steering mode
- 18 Check the steering operation by turning the steering wheel approximately  $\frac{1}{4}$  turn in each direction.
  - ⦿ Result: The front wheels should turn in the same direction as the steering wheel. The rear wheels should not turn.
- 19 Straighten the wheels.
- 20 Rotate the steering mode selector toward left to select crab steering mode.
- 21 Check the steering operation by turning the steering wheel approximately  $\frac{1}{4}$  turn in each direction.
  - ⦿ Result: The front wheels and rear wheels should turn in the same direction as the steering wheel.

### Test the Transmission and Brakes

- 22 Be sure the boom is fully lowered and retracted.
- 23 Step on the service brake pedal.
- 24 Move the transmission control lever to forward. Slowly let up on the service brake pedal. As soon as the machine starts to move, push the service brake pedal.
  - ⦿ Result: The machine should move forward, then come to an abrupt stop.

- 25 Move the transmission control lever to reverse. Slowly let up on the service brake pedal. As soon as the machine starts to move, push the service brake pedal.

- ⦿ Result: The machine should move in reverse, then come to an abrupt stop. The back-up alarm should sound when the transmission control lever is in reverse.

- 26 Move the transmission control lever to neutral.

- 27 Pull the parking brake lever upward.

- ⦿ Result: The parking brake indicator light should come on, indicating the parking brake is on.

- 28 Move the transmission control lever forward, then in reverse.

- ⦿ Result: The machine should not move.

- 29 Push the parking brake lever downward. The parking brake is off when the indicator light is off.

### Test Outriggers and Sway Control (for SX)

- 30 Using the control lever **2** and **3**, fully lower and raise the outriggers.

- ⦿ Result: The outriggers should operate smoothly.

- 31 Using the control lever **1**, sway the machine

- ⦿ Result: The machine should sway smoothly.

- 32 Raise the boom over  $20^\circ$  and extend it.

- ⦿ Result: The sway function and the outriggers should not work.

### Test Outriggers and Sway Control (for EX)

- 33 Using the buttons **19**, fully lower and raise the outriggers.

- ⦿ Result: The outriggers should operate smoothly.

- 34 Using the buttons **20** sway the machine

- ⦿ Result: The machine should sway smoothly.

# Inspections

35 Raise the boom over 20° and extend it.

- ⦿ Result: The sway function and the outriggers should not work.

## Test the Road Lights

36 Verify that all lights are functional.

## WORKPLACE INSPECTION

The workplace inspection helps the operator determine if the workplace is suitable for safe machine operation. It should be performed by the operator prior to moving the machine to the workplace.


### Make sure:

- ☒ You learn and practice the principles of safe machine operation contained in this operator's manual.
  - 1 Avoid hazardous situations.
  - 2 Always perform a pre-operation inspection.
  - 3 Always perform function tests prior to use.
  - 4 **Inspect the workplace.**
  - 5 Only use the machine as it was intended.

It is the operator's responsibility to read and remember the workplace hazards, then watch for and avoid them while moving, setting up and operating the machine

Be aware of and avoid the following hazardous situations:

- drop-offs or holes
- bumps, floor obstructions or debris
- sloped surfaces
- unstable or slippery surfaces
- overhead obstructions and high voltage conductors
- hazardous locations
- inadequate surface support to withstand all load forces imposed by the machine
- wind and weather conditions
- the presence of unauthorized personnel
- other possible unsafe conditions



Intentionally blank page

## Operating Instructions

This chapter describes some techniques and provides instructions for a safe use of the machine fitted with standard forks. Before using different attachments, thoroughly read the chapter "Optional attachments".



***Before using the machine, inspect the job site and check for possible hazardous conditions. Make sure that there are no holes, moving banks or debris that may cause you to lose the control of the machine.***



***Pay the greatest attention when working close to electric lines. Check their position and ensure that no part of the machine operates at less than 6 meters from the power lines.***

---

### Make sure:

- ☒ You learn and practice the principles of safe machine operation contained in this operator's manual.
  - 1 Avoid hazardous situations.
  - 2 Always perform a pre-operation inspection.
  - 3 Always perform function tests prior to use.
  - 4 Inspect the workplace.
  - 5 Only use the machine as it was intended.
- 



***For a safe use of the machine, always check the weight of the loads going to be handled.***

# Operating Instructions

## ENTERING THE MACHINE

### Entering the cab




**Always make sure that your hands and shoe soles are clean and dry before getting into the driving cab. Always face the machine when entering and leaving it and hold to the suitable handles.**

The handler cab is equipped with an access door on the left-hand side.

#### Door opening from outside:

- Insert the key and release lock 1.
- Press the pushbutton 1 and open the door.




#### Door closing from inside:

Pull the door with force: it locks automatically.



#### Door opening from inside:

- Lower lever 2 and release the lock to open the door completely.
- Rotate handle 3 to open the upper section of the door and lock it against the special catch.



### To unlock the door latched in open position:


- Press button 4 to unlock the door from the catch
- Once released, re-close the upper section of the door by means of handle 3.



### Leaving the cab in an emergency

In an emergency, use the rear window of the cab as safety exit-way.

This window has special locking handles with plastic pins 5 easy to pull out when you need to fully open the glass.



**The upper section of the door must be secured to the rear part of the driving cab or latched to the lower section of the same door.**




## Operating Instructions

### Adjusting the seat

Position the seat so you can comfortably reach all the controls. The handler seat is fitted with devices which let you adjust the seat springing, height and distance from the controls, the backrest angle and the armrest height.


- **Adjusting the seat distance from the controls**  
To slide the seat forward or back, rotate lever A and push the seat to the desired direction. Then release the bar and make sure that the seat locks in position.
- **Adjusting seat height and springing**  
Free the lever of knob B and turn clockwise or counter-clockwise until reaching the desired springing. Once you're correctly seated in the seat check that the yellow indicator C is in the green field.
- **Adjusting the backrest angle**  
Operate lever D, press your back firmly against the backrest and put the backrest at the angle you wish, then release the lever.
- **Adjusting the armrest height**  
Raise armrest E and turn wheel F to put the armrest at the height you want.



### Fastening the seat belts

Sit correctly in the driving seat; then:

- The safety belts are equipped with reel retractor. To fasten the belt, pull tab 1 and push it into buckle 2.
- To release the belt, push button 3 and remove the tab from the buckle.
- Make sure that the buckle is correctly located at the hip point and not on the stomach.
- Operate the end adjusters to reach the length you wish and make sure the buckle is always in the middle.



## CAUTION

- *The seat is for one person only.*
- *Don't adjust the seat when the machine is moving.*

## DANGER

**Not fastening the seat belts could result in death or serious injury.**

## Operating Instructions

### Adjusting the steering column

both steering column and dashboard can be set to a different angle.


To adjust the steering wheel angle, unlock lever 1 and pull or push the steering wheel to the required position, then re-lock lever 1.



***Before driving the machine, ensure the steering wheel is perfectly clamped.***

### Switching on the cab interior lamp

the ceiling light fixture is fixed to the rear top strut of the cab. The relevant lamp is switched on/off by switch.





## Operating Instructions

### ADJUSTING THE MIRRORS

The machine is fitted with five mirrors:


- The right convex mirror **1** is located on a special supporting bracket in advanced position and allows checking the area **A** behind the machine, on the right-hand side. To adjust its position, manually rotate the joint it is fitted with.
- The right rear view mirror **2** is located on a special supporting bracket and allows checking the carriageway **B** behind the machine. To adjust its position, manually rotate the joint it is fitted with.
- The left rear view mirror **3** is placed on the left upper post of the windscreen and allows checking the area **C** behind the machine, on the left-hand side. To adjust its position, manually rotate the joint it is fitted with.
- The rear convex mirror **4** is placed on a special bracket located at the back of the boom and allows checking the area **D** behind the machine as well as the rear part of the chassis. To adjust its position, manually rotate the joint it is fitted with.
- The front left convex mirror **5** is located on a special supporting bracket in advanced position and allows checking the area **E** in front of the machine, on the right-hand side. To adjust its position, manually rotate the joint it is fitted with.




**Modification of the telehandler may affect the operator's visibility.**

## Operating Instructions

### STARTING THE ENGINE

- Set the forward/back speed lever to neutral position.
- To start the engine, rotate the ignition switch to position , and release when the engine starts. If the engine does not start within 20 seconds, release the key and wait at least 2 minutes before attempting again.
- After the engine starting, slow down the rpm and wait some seconds before engaging a gear; this allows for a gradual warm up of the engine oil and a better lubrication.
- In case of engine jump-starting, remove the connecting cables (see following chapter).



## NOTICE

**If the light indicators do not switch off/on when engine is running, immediately stop the machine and find and rectify the fault.**

## WARNING

**Once it has been started, the engine continues to run even if you leave the driving place. DO NOT LEAVE THE DRIVING PLACE BEFORE HAVING SHUT THE ENGINE DOWN, LOWERED THE BOOM TO THE GROUND, TURNED THE SPEED SWITCH TO THE NEUTRAL POSITION AND ENGAGED THE PARKING BRAKE.**



**Engine can not be started if the speed switch is not in the neutral position.**

### JUMP-STARTING THE ENGINE

## NOTICE

**Do not start the engine using a quick charge booster to avoid any damage to the electronic boards.**

## DANGER

**When jump-starting the engine through the battery of another machine, make sure that the two vehicles cannot collide to prevent formation of sparks. Batteries give off a flammable gas and sparks may burn it and cause an explosion. Do not smoke when checking the electrolyte level.**

**Keep any metal object like buckles, watch straps, etc. clear of the battery positive (+) terminal. These elements can short between the terminal and nearby metal work and the operator can get burned.**

**The booster supply must have the same rated voltage and output of the battery installed on the handler.**

To jump-start the engine:


- Turn any users off by the special control levers.
- Put the gear lever to neutral and engage the parking brake.
- Ensure the machine battery A is connected to the frame earth, the terminals are well tightened and the electrolyte level is regular.
- Connect the two batteries as shown in the figure. Connect first the positive terminals of the two batteries, then the negative terminal of the booster supply B to the machine frame earth.
- If the booster supply is installed on a second vehicle, make sure that the latter does not touch the handler. To avoid damage to the electronic instruments of the machine, the engine of the machine where the booster supply is installed, must be stopped.

## Operating Instructions

### LOW TEMPERATURE STARTING

In case of cold starting, use an oil with a SAE viscosity adequate to the ambient temperature. Please refer to the engine use and maintenance manual.


The machine is supplied with oil SAE 15W/40.



- Turn the ignition key and start the handler.
- Disconnect the cables. Remove first the negative terminal from the frame earth, then from the booster supply. Disconnect the positive terminal from the machine battery, then from the booster supply.



**Use only a 12V battery; other devices like battery chargers, etc. may cause an explosion of the battery or result in damage to the electrical system.**




To start the engine from cold, proceed as follows:

- Set the forward/back speed lever to neutral position.
- Turn the ignition switch to the glow plugs preheating position holding it in this position for few seconds. Step down on the gas pedal and start the engine by turning the ignition switch. Release the switch as soon as the engine fires.
- Let the engine run at idle for a few seconds before putting a gear; this allows for a gradual warm up of the engine oil and a better lubrication.

## Operating Instructions

### DISCONNECTING THE BATTERY

During maintenance or repair works, and while welding, turn off the battery cut-out switch **A**, located into the engine compartment below the engine air filter.



### STARTING THE MACHINE

When the engine reaches the running temperature, ensure all parts are in transfer position and the gearbox lever is in neutral. Then, proceed as follows:

- Select the required steering mode.
- Select the required gear (forward or reverse).
- Release the parking brake.
- Slowly step on the gas pedal to start moving off.



***Do not operate the forward/reverse gear lever when the machine is running. The machine would reverse the running direction abruptly and you could seriously be injured.***

### STOPPING AND PARKING THE MACHINE

When possible, stop the machine on a dry, level and solid ground. Then:

- Bring the machine to a smooth stop by easing up the gas pedal and stepping down on the brake pedal.
- Set the forward/back speed lever to neutral position.
- Engage the parking brake and ensure its indicator light switches on.
- Release the service brake pedal.
- Rest the attachment coupled to the boom flat on the ground.
- Rotate the ignition key to "0" and remove the key.
- Leave the driving cab and lock the cab door.



***Always face the machine when getting off the driving cab; make sure that your hands and shoe soles are clean and dry, and hold to the handholds to prevent falls or slips.***



***Always engage the parking brake after stopping the machine to prevent possible accidental motions of the vehicle.***

## Operating Instructions

### USING THE LOAD CHARTS

The load charts **1** indicating the maximum permissible load in relation to the boom extension and the type of attachment used, are installed on the cab. To operate under safe conditions, always refer to these charts. The extension level of the boom can be checked with the help of the letters (**A, B, C, D, E**) painted on the same boom (pos. **3**), while the actual degrees of inclination of the boom are shown by the angle indicator **2**.

All the load charts are placed into a dedicated holder installed in the right side of the cabin, on the top of the dashboard.

The tag **4** located at the top of each load chart, indicates the type of attachment used.





**The load charts illustrated in this manual are given only as a mere example. To define the payload limits, refer to the load charts applied within the cab of your machine.**



**The load charts applied on the cab refer to a stationary machine standing on a solid and level ground.**

**Raise the load some centimetres and check its stability before raising it completely.**




## Operating Instructions

### LOAD LIMITER

On the front top strut of the cab, there is limiter **6** which warns the operator of the variation of stability of the machine and blocks any manoeuvre before the same reaches a critical condition.

#### Description of the controls

1. Used only for calibration
2. Stability indicator with LED-bar
3. Green light - power OK
4. Used for calibration. It lights up when the outriggers are lowered.
5. Used only for calibration




#### Operation

When power is turned on, light **3**, the led bar **2** and button **4** and **5** come on.

The monitoring system runs a self-test.

During operation, the LED-bar **2** lights up gradually depending on the variation of stability.



**Green LED's (L1 and L2):** during normal operation when the percentage of overturning moment is between 0 and 89, these LED's are ON. The machine is stable.

**Orange LED's (L3 and L4):** they light up when the machine tends to overturn and the percentage of overturning moment with respect to the threshold value is between 90 and 99.

The system enters the **pre-alarm** mode: the buzzer sounds with an intermittent sound and the boom extension, lowering and forks forwards tilting movements slow down.

**Red LED's (L5 and L6):** risk of overturning! The percentage of overturning moment is above 100 with respect to the threshold value.

The machine enters the **alarm** mode: the buzzer sounds continuously and any dangerous manoeuvre is blocked: boom up, boom down, boom out, forks frame forwards. The operator can only retract the load within safety limits.



## Operating Instructions

### Alarm codes and resetting

The limiter has diagnostic facilities to aid in the identification of failures of the transducers, breakages of the cables or malfunction of the electronic system. When a failure is signalled, the limiter enters the safety mode blocking any dangerous manoeuvres: **LED L6** starts flashing representing an alarm code. The meaning of these alarm codes is shown in section "Faults and Troubleshooting".



**Before using the machine, make sure that the first green LED of the overload warning system is ON.**

**The overload warning system must not be used to check the load going to be lifted: it has only been designed to signal possible unbalances of the machine along its motion axis.**

**Such unbalances may also be caused by an abrupt operation of the levers during the load handling. If, during work, several indicators light up, operate the levers more smoothly.**

### Load Limiter Disable Selector

The LMI disable selector allows to override the LMI system in order to recover the machine:

- when it is stuck after the LMI has triggered;
- in case of main machine failures requesting the unlock of all the machine movements;

In order to prevent any misuse of this device (ie working outside the load and stability limits of the machine), the control system is provided with a timer (calibrated at 10 seconds) which, after this time is expired, restores automatically the lock-out functions.

### ADJUSTING THE FORKS

#### With FEM forks (*OPTIONAL*)


Forks shall be spaced to suit the load going to be handled. For this purpose:

- Lift the clamping lever of the forks.
- Slide the forks to the desired position, then re-lock the lever.

#### With floating forks

In the case of floating forks:

- Loosen the nut of the locking screws.
- Raise the forks and slide them on the pivot until correct spacing.
- Lock the screws re-tightening the nut.



- **The centre of gravity of the load must always be halfway between the forks.**
- **Ensure you exactly know the weight of the load before handling it.**
- **When extending the boom, do not exceed the payload limit.**
- **Refer to the payload limits given in the load chart applied on the cab.**
- **Space the forks as wide as possible to suit the load being handled.**

## Operating Instructions

### WORKING PHASES







*Operator have to survey his/her field of vision when operating the truck.*

#### Loading phase

- Approach the load to the handled perpendicularly and check that the machine is level on the inclinometer.
- Insert the forks under the load and raise the load some centimetres.
- Pitch the forks back to retract the load.



*The risks during load handling are principally in the rearward direction during the reversing part of the manoeuvre.*



## Operating Instructions

### Transfer phase

- Do not start or brake abruptly.
- Drive to the unloading point cautiously and keep the load 20÷30 cm from the ground.
- Suit the machine speed to the ground conditions to avoid dangerous jumps, side skids of the vehicle and possible load falls.
- When driving on slopes or ramps, hold the load uphill.



***If a suspended load or the resulting boom geometry creates a substantial blockage that the user should consider alternative carrying means.***



***Do not drive on slopes sideways; this wrong manoeuvre is one of the main reasons for accidents due to vehicle overturning.***

### Unloading phase

- Drive to the unloading point with straight wheels and bring the machine to a smooth stop leaving enough space to operate the boom.
- Put the parking brake and set the transmission to neutral.
- Position the load some centimetres above the desired position and set the forks level.
- Lower the load and make sure it is level.
- Carefully withdraw the forks by operating the boom retraction control and, if necessary, raise or lower the boom as forks come out.
- When the forks are clear of the load, set them to transfer position.
- Release the parking brake and start a new working cycle.

# Operating Instructions

## CHANGING THE ATTACHMENT




**Use only attachments directly manufactured or recommended by Terexlift and detailed in the "Optional Attachments" section.**

### Version with MECHANICAL LOCKING

To change an attachment, operate as follows:






- Drive to the place where you will release the mounted attachment (when possible, a solid and sheltered site).
- Disconnect the quick connectors of the attachment (if any).
- Pull out pin 1 locking the attachment after removing the safety split-pin 2 at its end.



- Rest the attachment flat on the ground.
- Pitch the attachment holding frame forward and lower the boom to release the attachment upper lock.
- Move back with the machine and drive to the new attachment to be coupled.
- Hold the frame pitched forward and hook the upper lock of the new attachment.
- Retract and raise the attachment some centimetres. It will centre automatically on the quick coupling frame.
- Refit pin 1 fixing it with its safety split-pin 2.
- Re-couple the connectors of the attachment (if any).



**After substitution, visually check the attachment is correctly coupled to the boom, before operating the machine. A wrongly coupled attachment may result in damage to persons or things.**




## Operating Instructions

### Version with HYDRAULIC LOCKING (optional)

To change an attachment, operate as follows:

- Drive to the place where you will release the mounted attachment (when possible, a solid and sheltered site).
- Disconnect the quick connectors of the attachment (if any), and connect the hydraulic locking pipes of the attachments to couplings 3.



- Rest the attachment flat on the ground.
- Remove the safety pin 2 placed at its end.
- Free the attachment operating the control of the attachment locking/unlocking cylinder
- Pitch the attachment holding frame forward and lower the boom to release the attachment upper lock.
- Move back with the machine and drive to the new attachment to be coupled.
- Hold the frame pitched forward and hook the upper lock of the new attachment.
- Retract and raise the attachment some centimetres. It will centre automatically on the quick coupling frame.
- Operate the attachment locking lever (optional) and secure the attachment in place with safety pin 2 previously removed.
- Re-couple the connectors of the attachment (if any).

# Operating Instructions

## ROAD OR SITE TRANSFER


When travelling on public roads, strictly obey the local or national road traffic regulations.

Besides, take into account the following general precautions:

- Start the engine.
- Align the rear wheels.
- Sway the machine.
- Only for the italian market install the locking devices provided for the machine registration document as follows:
  1. install the boom extension locking cable A;
  2. install the locking collar B on the tilting cylinder;
  3. install the locking collar C on the lifting cylinder;
  4. install the locking chain D on the outriggers arms.
  5. Cover the teeth of the conventional forks with the special guard; or withdraw the floating forks.

## NOTICE

**With the floating forks pitched back, do not move the fork pitching cylinder as the machine could suffer from damage.**






- Retract the boom and the attachment to transfer position.
- Set the Road/Jobsite switch to "ROAD".
- Make sure that lights, horn and turn signals are in working order.
- Engage the gear.
- The transfer speed of the vehicle will depend on the engine rpm and the position of the control lever.

## NOTICE

**Public road circulation is allowed only for transferring an unloaded machine.  
Do not use the machine to tow trailers.**

### ONLY FOR THE ITALIAN MARKET



## Operating Instructions

### USE OF THE MAN-PLATFORM (ONLY FOR EX)

For the use of the man-platform, proceed as follows:

- 1 Couple the man-platform to the attachment holding frame.
- 2 Lower the outriggers; checking that the machine is level on the inclinometer **10** in the cab.
- 3 Level the platform floor.



***The platform floor cannot be levelled once the controls have been switched from the driving cabin to the platform. Before starting using the platform, make sure the floor is level.***

- 4 Turn the jobsite/road/platform selector to platform position (the green indicator comes on).
- 5 Stop the engine, turn the ignition switch to P position and engage the parking brake.
- 6 Remove the key from the jobsite/road/platform selector to use it for the platform controls.
- 7 Open the protection cover of the power socket on the boom and plug in the platform plug.
- 8 Enter the man-platform and insert the key, previously removed, in the controls switch.



***If the platform controls remain disabled once the key has been inserted, check the correct position of the sensors of the attachment coupling pin (see relevant manual) and the efficiency of the outriggers limit switches (see dedicated paragraph on "Maintenance" section).***



***For the use and maintenance of the man-platform, read the specific manual.***

Intentionally blank page



## Transporting The Machine

### MOVING A DISABLED MACHINE

Tow the machine only when no alternative is possible, since this operation may result in serious damage to the transmission. When possible, repair the machine on site.


When the machine shall absolutely be towed:

- Unlock the parking brake.
- Tow the machine for short distances and at a low speed only (less than 5 km/h).
- Use a rigid drawbar.
- Select the two-wheel steer.
- Set the forward/back speed lever to neutral position.
- Raise the front wheels of the machine.
- When possible, start the engine and use the hydraulic drive and the braking system.

### UNLOCKING THE NEGATIVE BRAKE.

To unlock the negative brake of a faulty machine, use the four screws **31** on the two sides of the rear differential casing as follows:

- Loosen the four counter-nuts fixing screws **31**, then move the nuts backwards by approx. 8 mm.
- Tighten screws **31** so as to fasten them onto the pressure plate.
- Using a wrench, tighten the screws **31** in an alternate sequence by 1/4 turn a time so as to compress the Belleville washers and disengage the braking disks. Tighten max. by one turn.
- After the manual release, adjust screws **31** to obtain a jut of  $30 \pm 0.5$  mm in relation to the arm.



## Transporting The Machine

### LIFTING THE MACHINE

When the machine shall be lifted, use only means having a suitable capacity. The characteristic data and the center of gravity details are listed in the section "**Specifications**".

For lifting the machine, proceed as follow:

- Retract the boom to transfer position.
- Put the parking brake and rest the attachment flat.
- Shut the engine down and close the driving cab of the machine.
- Anchor the chains to the four special lugs on the machine (marked with the decal below).




**Lift the machine only when the chains has been anchored to all the lugs.**

### TRANSPORTING THE MACHINE ON OTHER VEHICLES

To transport the machine on another vehicle, follow the steps below:

- Ensure ramps are correctly positioned.
- Retract the boom to transfer position.
- Carefully drive the machine onto the transporting vehicle.
- Put the parking brake and rest the attachment flat on the vehicle platform.
- Ensure the overall dimensions do not exceed the allowed limits.
- Shut the engine down and close the driving cab of the machine.
- Secure the machine to the vehicle platform by wheel-chocks.
- Anchor the machine to the transporter's platform by fixing the chains to the special eyebolts **A** on the chassis.



## Transporting The Machine

### PARKING AND STORAGE

#### Short inactivity

Always park the machine in a safe way after a working day, a shift and at night.

Take all precautions to prevent damage to those persons who will approach the machine while stationary:

- Park the machine so that it does not hinder other operations.
- Lower the boom fitted with attachment on the ground.
- Disengage the transmission and put the parking brake.
- Remove the key from the ignition switch and lock the cab door.



***Leaving a battery connected can result in shorts and, as a consequence, in a fire.***

#### Machine storage

In case of extended inactivity of the machine, follow the above precautions. Additionally:

- Wash the machine thoroughly. For a better cleaning, remove grills and protection casings.
- Carefully dry all machine parts by blowing some compressed air.
- Lubricate the machine thoroughly.
- Do a walk-around inspection and replace any worn or damaged part.
- Re-paint any worn or damaged part.
- Remove the battery, smear its terminals with vaseline and store it in a dry place. Battery can be used for other purposes. Otherwise, periodically check its charge level.
- Refuel the tank to prevent internal oxidation.
- Store the machine in a sheltered and well-ventilated place.
- Start the engine for about 10 minutes at least once a month.
- When weather is particularly cold, empty the radiator.

## NOTICE

***Always remember that the ordinary maintenance must be carried out even during the machine inactivity. Pay particular attention to the fluid levels and to those parts subject to ageing. Before re-starting the machine, carry out an extraordinary maintenance and carefully check all mechanical, hydraulic and electrical components.***

## Transporting The Machine

### CLEANING AND WASHING THE MACHINE

Clean the machine in accordance with the following instructions:

- Remove any oil or grease traces with a dry solvent or a volatile mineral alcohol
- Before assembling a new part, remove any protection product (rust-preventer, grease, wax etc.).
- Remove any trace of rust from metal parts with some emery cloth before smearing the part with a protection product (rust-preventer, paint, oil etc.).

## NOTICE

***Do not use water at high pressure for washing the machine and especially the main valve, the solenoid valves and electrical parts.***

### External washing

Before washing the machine, check that the engine is shut down and the doors and windows are closed. Do not, at any times, use fuel to clean the machine. Use water or some steam. In cold climates, dry the locks after washing or smear them with an antifreeze. Before using the machine again, check its conditions.

### Internal washing

Wash the machine interior with some water and a sponge. Do not use water at high pressure. After washing, dry with a clean cloth.

### Washing the engine

Before washing the engine, protect the air intake filter to prevent water from entering the circuit.

## NOTICE

***If the machine shall be used in a marine or equivalent environment, protect it against salt deposits with an adequate treatment against saltiness to prevent rust formation.***

### MACHINE DISPOSAL



***At the end of the machine life, call in a specialised firm to dispose of it in compliance with the local or national regulations.***

### Battery disposal



***Used lead-acid batteries cannot be disposed of as normal industrial solid wastes. Because of the presence of harmful substances, they must be collected, eliminated and/or recycled in accordance with the laws of the UE.***

***Used batteries must be kept in a dry and confined place. Make sure the battery is dry and the cell plugs are tight. Place a sign on the battery to warn of not using it. If before disposal the battery is left in the open air, it will be necessary to dry, smear the box and the elements with a coat of grease and tighten the plugs. Do not rest the battery on the ground; it is always advisable to rest it on a pallet and cover it. The disposal of batteries shall be as rapid as possible.***

## Maintenance

### Observe and obey:

- \* The operator can only perform the routine maintenance operations envisaged in this manual.
- \* Scheduled maintenance procedures shall be completed by qualified technical personnel according to the manufacturer's specifications.



### Maintenance symbol legend:

*The following symbols are used in this manual to help you understand better the instructions provided. When one or more symbols appear at the beginning of a maintenance procedure, they indicate the following:*



Indicates that tools are required to perform the procedure.



Indicates that new parts are required to perform the procedure.



Indicates that a cold engine is required to perform the procedure.



### SERVICE INTERVAL

Running-in \_\_\_\_\_

Ordinary \_\_\_\_\_

Indicates the time interval for the maintenance jobs expressed in working hours.

### INTRODUCTION

A thorough and regular maintenance keeps the machine in a safe and efficient working condition.

For this reason, it is advisable to wash, grease and service the machine properly, especially after having worked under particular conditions (muddy or dusty environments, heavy operations, etc.).

Always ensure all machine components are in good condition. Check for oil leaks or loosening of guards, and make sure that the safety devices are efficient. In case of defects, find and rectify them before using the machine again.

Not respecting the ordinary maintenance schedule of this manual automatically voids TEREXLIFT warranty.

## NOTICE

***For the engine maintenance, please refer to the specific Operator handbook supplied with the machine.***



## CAUTION

***Before any maintenance or repair work, remove the attachment.***

# Maintenance

## SPARE PARTS



**Use only original spare parts. Please refer to the specific Spare Parts Catalogue.**

SAFETY DEVICES SPARE PARTS	
Load Cell	09.0802.0037
LMI Display & Board	56.0021.0128
Emergency Stop Pushbutton	07.0703.0441
Seat Switch	07.0703.0484
Slave Cylinder Safety Valve	04.4239.0003
Lifting Cylinder Safety Valve (for GTH 4013 SX & GTH 4017 SX)	04.4239.0005
Lifting Cylinder Safety Valve (for GTH 4013 EX & GTH 4017 EX)	04.4239.0120
2nd Telescope Extension Cylinder Safety Valve for GTH 4013SX & GTH 4013 EX	04.4239.0079
2nd Telescope Extension Cylinder Safety Valve for GTH 4017SX & GTH 4017 EX	04.4239.0041
3rd Telescope Extension Cylinder Safety Valve for GTH 4013SX & GTH 4013 EX	04.4239.0001
Attachment Tilting Cylinder Safety Valve	04.4239.0000
Axle Locking Cylinder Safety Valve	04.4239.0115
Axle Levelling Cylinder Safety Valve	04.4239.0007
Outrigger Cylinder Safety Valves	04.4239.0007
Outigger Micro-switches	55.0602.0616
Parking Brake Sensor N.C.	05.4329.0017
Parking Brake Sensor N.O.	05.4329.0016
Service Brake Low Pressure Micro	05.4329.0002
Service Brake Lights Micro	05.4329.0001
Boom Safety Switches	56.0602.0392

## LUBRICANTS - HEALTH AND SAFETY PRECAUTIONS

### Health

A prolonged skin contact with oil can cause irritation. Use rubber gloves and protective goggles. After handling oil, carefully wash your hands with soap and water.

### Storage

Always keep lubricants in a closed place, out of the children's reach. Never store lubricants on the open air and without a label indicating their contents.

### Disposal

New or exhausted oil is always polluting! Never drain oil on the ground. Store new oil in a suitable warehouse. Pour exhausted oil into cans and deliver them to specialised firms for disposal.

### Oil leaks

In case of accidental oil leaks, cover with sand or type-approved granulate. Then scrape off and dispose of it as chemical waste.

### First aid

**Eyes** : In case of accidental contact with the eyes, wash with fresh water. If the irritation persists, seek medical advice.

**Intake** : In case of oil intake, do not induce vomiting, but seek medical advice.

**Skin** : In case of a prolonged contact, wash with soap and water.

### Fire

In case of fire, use carbon dioxide, dry chemical or foam extinguishers. Do not use water.

## Maintenance

### ORDINARY MAINTENANCE

A wrong or neglected maintenance can result in possible risks for both operator and bystanders. Make sure maintenance and lubrication are carried out according to the manufacturer's instructions to keep the machine safe and efficient.

The maintenance interventions are based on the machine working hours. Regularly check the hour-meter and keep it in good conditions to define the maintenance intervals correctly. Make sure any defect detected during the maintenance is promptly rectified before using the machine.



**All "▲" marked operations must be carried out by a skilled technician.**

#### During the first 10 working hours

1. Check the oil level within reduction gears, power divider and differential gears
2. Regularly check the tightening of the wheel bolts
3. Check the tightening of all bolts and nuts
4. Check the couplings for oil leaks

#### Within the first 100 working hours

1. Change the oil of the differential casing, the wheel reducer and the power divider gearbox.

#### Every 10 working hours or daily

1. Check the engine oil level.
2. Clean the air suction filter.
3. Check the engine coolant level.
4. Clean the radiator, if necessary.
5. Check the hydraulic oil level in the tank.
6. Check the greasing of the boom section pads.
7. Grease the attachment holding frame.
8. Grease all joints of the boom, the rear axle shaft joint, the transmission shafts, the front and rear axles and any equipment of the machine.
9. Check the efficiency of the overload warning system.
10. Check the efficiency of the lighting electric system.
11. Check the efficiency of braking system and parking brake.
12. Check the efficiency of the steering selection system.
13. Check the efficiency of the fork balancing system.
14. Make sure the safety devices installed are in efficient working order.
15. Check or re-sequence the boom telescopes.

#### Every 50 working hours or weekly

Jobs to be done in addition to those above

1. Check the tension of the alternator belt.
2. Check the tyre inflation.
3. Check the tightening of the wheel nuts.
4. Check the tightening of the Cardan shaft screws.
5. Clean the radiator fins.

#### Every 250 working hours or monthly

Jobs to be done in addition to those above

1. Check the oil level in the front and rear differential gears.
2. Check the oil level in the four wheel reduction gears.
3. Check the main filtering element of the engine air filter. Replace, if necessary.
4. Check the clamping of the cableheads to the battery terminals.



## Maintenance

5. Check the air suction hose between engine and filter.
6. Check the cylinder chromium-plated rods.
7. Check the hydraulic lines are not worn because of rubbing against the frame or other mechanical components.
8. Check the electric cables do not rub against the frame or other mechanical components.
9. ▲ Check the wear of the sliding pads of the boom sections.
10. ▲ Adjust the play of the sliding pads of the boom sections.
11. Remove any grease from the boom, then re-grease the sliding parts of the boom sections.
12. Check the level of the battery electrolyte.

### Every 3 working months

Jobs to be done in addition to those above

1. Check the efficiency of the block valves.

### Every 500 working hours or every six months

Jobs to be done in addition to those above

1. Visually check the smoke quantity evacuated from the engine exhaust.
2. Check the tightening of the engine fixing screws.
3. Check the tightening of the cab fixing screws.
4. Check the backlash between pins and bushings in all joints.
5. Change the hydraulic oil filter in the tank.
6. Have the hydraulic system checked by a skilled technician.
7. Change the main cartridge of the engine air filter.
8. Renew the cartridge of the engine oil filter and the fuel filter.
9. Change the oil of the front and rear differential casings.
10. Proceed with boom chain tensioning.

### Every 500 working hours or yearly

Jobs to be done in addition to those above

1. Change the engine oil and renew the fuel filter.

### Every 1000 working hours or yearly

Jobs to be done in addition to those above

1. Change the safety element of engine air filter.
2. Change the oil in the power divider gearbox.
3. Change the oil in the four wheel reduction gears.
4. Change the hydraulic oil.

### Every 2000 working hours or every two years

Jobs to be done in addition to those above

1. Change the engine coolant.

### At 6000 hours or 5 years and, subsequently, every 2 years

Jobs to be done in addition to those above

1. Check that the structure is intact paying a special attention to the welded supporting joints and the boom pins.



## Maintenance

### OIL CHANGE SCHEDULE

	Job	Operating hours *	Service interval *	Oil type
<b>Engine</b>	Oil level check	10	daily	SHELL RIMULA 15W-40 (API CH-4/CG-4/CF-4/CF; ACEA E3; MB228.3)
	First change	500	-	
	Subsequent changes	500	yearly	
<b>Axles and power divider gearbox</b>	Oil level check	250	monthly	TRACTORENAULT THFI 208 LF SAE 80W; API GL4 / FORD M2C 86B; MASSEY FERGUSON M 1135
	First change	-	-	
	Subsequent changes	1000	yearly	
<b>Hydraulic oil</b>	Oil level check	10	daily	GAZPROMNEFT HYDRAULIC HDZ 46 (DIN 51524 part 3 HVLP, ASTM D6158 HV, SAE MS1004 MS)
	First change	-	-	
	Subsequent changes	1000	yearly	

\* whichever occurs first.

## Maintenance

### MAINTENANCE INTERVENTIONS

#### **WARNING**

*All maintenance interventions must be carried out with engine stopped, parking brake engaged, working attachments flat on the ground and gear lever in neutral.*

#### **WARNING**

*When raising a component for maintenance purposes, secure it in a safe way before any maintenance intervention.*

#### **WARNING**

*Any intervention on the hydraulic circuit must be carried out by skilled personnel. The hydraulic circuit of this machine is fitted with pressure accumulators. You and others could be seriously injured if accumulators are not completely depressurised. For this purpose, shut the engine down and step on the brake pedal 8/10 times.*

#### **WARNING**

*Before any operation on hydraulic lines or components, make sure there is no residual pressure. For this purpose, stop the engine, engage the parking brake and operate the control levers of the main valve in both working directions (alternately) to depressurise the hydraulic circuit.*

#### **CAUTION**

*High pressure lines must be replaced by qualified personnel only. Any foreign matters entering the closed circuit may result in a sudden deterioration of the transmission.*

#### **CAUTION**

*The qualified staff charged with the maintenance of the hydraulic circuit must clean all areas around with care before any intervention.*

#### **PROTECT THE ENVIRONMENT**

*The handling and disposing of used oils can be ruled by local or national regulations. Address to authorised centres.*

#### **NOTICE**

*During maintenance or repair works, and while welding, turn off the disconnected battery switch, located into the engine compartment below the engine air filter.*


## Maintenance

### ACCESS TO THE ENGINE COMPARTMENT

For any operation within the engine compartment, open the protection bonnet.

The bonnet is equipped with pneumatic shock absorbers which unburdens and hold the bonnet in raised position. To open the bonnet:

- Shut the engine down and put the parking brake.
- Turn the key to unlock and open the bonnet.




### CAUTION

*Take all precautions when approaching the engine compartment. Some parts of the engine may be very hot. Always use protective gloves.*

### ENGINE

#### Perkins 1104 D-44T

Number of Cylinders	4 In-Line
Bore	105 mm
Stroke	127 mm
Aspiration	Turbocharged
Compression Ratio	18.2:1
Displacement	4.4 L
Firing Order	1 3 4 2
Rotation (flywheel end)	Counterclockwise
Valve Lash Setting (Inlet)	0.20 mm
Valve Lash Setting (Exhaust)	0.45 mm
Power	74kW@2300rpm
Max Torque	392Nm@1400rpm



TPL No \_\_\_\_\_

LIST No \_\_\_\_\_

SERIAL No \_\_\_\_\_

TYPE \_\_\_\_\_

## NOTICE

*For further info, please refer to the specific Operator handbook supplied with the machine.*

## Maintenance

### ENGINE AIR FILTER



Clean the engine air filter and replace the elements, when necessary.

#### 1 Cleaning and changing the external element

- Shut the engine down and put the parking brake.
- Open the four latches **A**.
- Remove the protection cap **B**.
- Extract the external cartridge **C**.
- Clean the filter bowl.
- Beat the cartridge against a piece of wood surface to eliminate any dust.
- Dry clean the cartridge (max. pressure: 6 bar).
- Check for cracks in the filtering element.
- Before refitting the cleaned cartridge or a new one, smear its seal with a thin coat of grease; fit the cartridge and make sure it is properly positioned.
- Refit cap **A**.

## NOTICE

**As soon as the warning lamp 37 on the cab dashboard switches on, replace the outer element.**

**Never wash the cartridge with water or solvents.**


#### 2 Changing the internal element

- See step 1 for removing the outer element.
- Extract the internal cartridge **D**.
- Clean the filter bowl.
- Smear the seal with grease, then mount the new element and make sure it is correctly positioned.
- Refit the main filter and the cap as described in point 1.

## NOTICE

**The inner element should be replaced every two times the outer element is replaced.**

**Never wash the cartridge with water or solvents.**



### SERVICE INTERVAL

Running-in \_\_\_\_\_ None  
 Cleaning \_\_\_\_\_ Every 10 hours  
 Outer element change \_\_\_\_\_ Every 500 hours  
 Inner element change \_\_\_\_\_ Every 1000 hours

## Maintenance



### ENGINE COOLING SYSTEM




## CAUTION

*When the coolant is hot, the cooling system is under pressure. With warm engine, loosen the radiator plug slowly and carefully, without removing it, to drain the pressure. Use protection gloves and keep your face at a safe distance.*

- Weekly check the coolant level through the level window **C**, before starting working (when fluid is cold).
- When necessary, add clean water or an antifreeze mixture through cap **A**.
- Change the antifreeze mixture every two years.  
To drain the antifreeze:
  - Let the engine cool down
  - Unscrew the plug **B** at the bottom of the radiator or disconnect the rubber hose, if no plug is present. Allow the coolant to flow out into a special container.
  - Refit the hose and pour new antifreeze (50% water-antifreeze). This proportion will provide protection up to -38°C.
- Daily clean the radiator grille using a brush with hard bristles or compressed air at a max pressure of 6 bar.



On delivery, the machine is filled with a cooling mixture consisting of 50% water and 50% anti-freeze.



### SERVICE INTERVAL

Running-in \_\_\_\_\_ None

Ordinary \_\_\_\_\_ Every **50** hours

TEREX PRO COOL Ethylene Glycol (ASTM D3306, ASTM D1384, FORD, G.M, FIAT)		
Product %	Freezing point	Boiling point
33	-17°C	123°C
40	-24°C	126°C
50	-36°C	128°C
70	-67°C	135°C

## Maintenance

### CHECKING THE OIL LEVEL IN THE TANK



***Fine jets of hydraulic oil under pressure can penetrate the skin. Do not use your fingers, but a piece of cardboard to detect oil leaks.***

Visually check the hydraulic oil level through level **A** located on the reservoir and visible through the slot on the right side of the chassis.

When necessary, add new oil through filler **B**.



### SERVICE INTERVAL


Running-in \_\_\_\_\_ Within the first **10** hours

Ordinary \_\_\_\_\_ Every **50** hours



### PROTECT THE ENVIRONMENT

***The handling and disposing of used oils can be ruled by local or national regulations. Address to authorised centres.***




### CHANGING THE HYDRAULIC OIL



To change the hydraulic oil, proceed as follows:


- 1** Stop the machine on a level ground and make sure the parking brake is engaged.
- 2** Release the pressure from the hydraulic circuit.
- 3** Place a container of suitable size under the drain plug, placed in the lower part of the reservoir, and collect any oil leaks.
- 4** Remove the drain plug **C** and allow oil to flow out into the container.
- 5** Remove the inspection cover of tank **D**.
- 6** Carefully wash the tank with Diesel oil and blow a jet of compressed air.
- 7** Refit the drain plug and the inspection cover.
- 8** Add new oil by making sure that it matches the recommended type until it is level with **A**.



### SERVICE INTERVAL

Running-in \_\_\_\_\_ None

Ordinary \_\_\_\_\_ Every **1000** hours




## Maintenance

### CHANGING THE OIL FILTER CARTRIDGE



To change the hydraulic oil filter element, proceed as follows:

- 1 Stop the machine on a level ground and engage the parking brake.
- 2 Place a container of suitable size under the filter to collect any oil leaks.
- 3 Remove the filter cover to get access to the filter element **A**.
- 4 Change the filter element, then, before fitting a new one, thoroughly clean and grease both seat and gasket.
- 5 Refit and tighten the filter cover.



## NOTICE

*The hydraulic oil filter cartridge shall be replaced as soon as the clogging indicator light on the control board comes on (see par. Controls and Instruments).*

## NOTICE

*Hydraulic oil filter canisters cannot be cleaned or washed and refitted. They must be replaced with new ones of the type recommended by the manufacturer.*



## PROTECT THE ENVIRONMENT


*The handling and disposing of used oils may be ruled by local or national regulations. Address to authorised centres.*



### SERVICE INTERVAL

Running-in \_\_\_\_\_ None

Ordinary \_\_\_\_\_ Every **500** hours



# Maintenance



## CAB AIR FILTER



Every six months clean the air filter in the cab. Replace the cartridge if the filtering cloth is damaged.

### 1 ***Cleaning and changing the cartridge:***

- Shut the engine down and engage the parking brake.
- Pull filter **A** out of the housing accessible from the outside of the cab.
- Clean the filter bowl.
- Clean the filter cartridge by beating it against a piece of wood. Replace the cartridge if damaged.



## NOTICE

***Paper filters must never be cleaned using compressed air or washed with water and/or solvents.***



## Maintenance

### OIL LEVEL IN THE DIFFERENTIAL GEARS


To check the oil level in the front and rear differential gears:

- Stop the machine on a level ground and engage the parking brake.
- Loosen level plug ③ and check if oil is level with the hole.
- If necessary, top-up through hole ① until oil comes out from hole ③.
- Refit and tighten plugs ③ and ①.

To change the oil:

- Place a container of suitable size under drain plug ②.
- Loosen the drain plug, the level plug ③ and the filler ① and allow oil to flow out from the reduction gear.
- Refit and tighten drain plug ②.
- Add new oil through the filler until it is level with hole ①.
- Refit and tighten plugs ③ and ①.

- ① **Filling plug**  
② **Drain plug**  
③ **Level plug**



#### SERVICE INTERVAL

Running-in \_\_\_\_\_ Within the first **10** hours

Ordinary \_\_\_\_\_ Every **250** hours

### OIL LEVEL IN THE (front/rear) WHEEL REDUCTION GEARS




To check the oil level within the wheel reduction gears:

- Stop the machine on a level ground and ensure the parking brake is engaged and plug finds on the horizontal axis.
- Clean the plug all around, then remove it and check if oil is level with the hole.
- If necessary, add new oil through hole ① until it is level.
- Refit the plug.

To change the oil:

- Stop the machine and ensure the plug is oriented along the vertical axis.
- Place a container of suitable size under the reduction gear plug.
- Unscrew plug and drain any oil from the reduction gear.
- Rotate the wheel by 90° until the plug finds again on the horizontal axis.
- Add new oil through hole ①.
- Refit and tighten plug.



#### SERVICE INTERVAL

Running-in \_\_\_\_\_ Within the first **10** hours

Ordinary \_\_\_\_\_ Every **250** hours

## Maintenance

### OIL LEVEL IN THE POWER DIVIDER GEARBOX




To check the oil level in the power divider gearbox:

- Stop the machine on a level ground and make sure the parking brake is engaged.
- Clean level plug ① all around.
- Remove the plug and check if oil is level with the hole.
- When necessary, add new oil through plug ① until it is level with the hole.
- Refit and tighten the plug.

To change the oil:

- Place a container of suitable size under the drain plug.
- Remove the plug ①.
- Remove the drain plug ② and empty the power divider gearbox.
- Refit and tighten the drain plug ②.
- Pour in new oil through the filler ① placed at the top of the reduction gear of the power divider. Stop when oil is level with hole ①.
- Refit and tighten plug ①.

- |   |                     |
|---|---------------------|
| ① | <b>Filling plug</b> |
| ② | <b>Drain plug</b>   |



#### SERVICE INTERVAL

Running-in \_\_\_\_\_ Within the first **10** hours

Ordinary \_\_\_\_\_ Every **250** hours

## Maintenance

### GREASING



#### CAUTION

**Before injecting grease into the greasers, thoroughly clean them to avoid that mud, dust or other matters can mix with the lubricant and reduce or annihilate the lubrication effect. Remove any old grease with a degreaser from the telescopes before smearing them with new grease.**

Regularly grease the machine to grant it efficient conditions and a long life.

By means of a pump, inject grease into the special greasers.

As the fresh grease comes out, stop the operation. The greasing points are shown in the following figures:


- the symbol  represents the points to be greased by a pump
- the symbol  represents the points to be greased by a brush.


#### CAUTION

**Use only PTFE INTERFLON FIN GREASE LS 2 to lubricate the sliding parts of the telescopic section. Observe the following schedule:**

- After the first 50 operating hours (1 week)
- After the first 250 operating hours (1 month)
- Every 1000 operating hours (6 months)

**Remove any old grease from the boom and smear the sliding area of the blocks with a thin coat of grease.**







### SERVICE INTERVAL

Running-in \_\_\_\_\_ None

Ordinary \_\_\_\_\_ Every 10 hours



# Maintenance

## TYRES AND WHEELS




**Over-inflated tyres can burst.**



**Overheated can burst. Do not weld the wheel rims. For any repair work, call in a qualified technician.**

**OKAY**



**WRONG**



For the tyre inflation or substitution, please refer to the table below:

	GTH 4017 SX	GTH 4013 SX
<b>Dimensions</b> (front and rear)	405/70-24	405/70-20
<b>P.R.</b> (or load index)	14 pr	14 pr
<b>Rim</b>	13x24	13x20
<b>Wheel disc</b>	8 holes DIN 70361	
<b>Pressure</b> bar/Psi	4.5/65	5.5/80
<b>Optional</b>	<b>Part Number</b>	
<b>Polyurethane Filled Tyres</b>	-----	55.0403.0022

**Always use tyres having the dimensions indicated in the vehicle registration card.**

On new machines, and when a wheel has been disassembled or replaced, check the nut torque of the wheels every 2 hours until they stay correct.

**Torque: 400 N/m.**



### SERVICE INTERVAL

Running-in \_\_\_\_\_ Within the first **10** hours

Ordinary \_\_\_\_\_ Every **250** hours

## BRAKES

For any intervention on the braking system (adjustment and/or substitution of the brake discs) address to the TEREXLIFT Technical Assistance Service or the nearest TEREXLIFT authorised workshop.

## Maintenance


### SHAFTING ALIGNMENT

During operation, the alignment of the front and rear axles of the machine can be subject to variations. This can depend on an oil blow-by from the steering control circuit, or on a steering of both axles when front and rear wheels are not perfectly aligned.

To fix this problem, rather than checking the alignment visually, follow the procedure below:

- 1) Move to a solid and level ground
- 2) Set the steering selection switch **27** to "four-wheel steering" (pos. **2**)
- 3) Rotate the steering wheel up to its stop (either to the right or to the left)
- 4) Set the steering selection switch to "two-wheel steering" (pos. **0**)
- 5) Rotate the steering wheel up to its stop (turn in the same direction as above)
- 6) Reset the steering selection switch to "four-wheel steering" (pos. **2**)
- 7) Rotate the steering wheel (to the side opposite to point **3**) so that the rear axle reaches its stop
- 8) Reset the steering selection switch to "two-wheel steering" (pos. **0**)
- 9) Rotate the steering wheel (to the same side as in point **7**) so that the front axle reaches its stop
- 10) Reset the steering selection switch to "four-wheel steering" (pos. **2**)

Now the wheels should be re-aligned.



**The machine is equipped with an automatic system for the rear wheels alignment. To align the rear wheels turn the steering selector switch to position 0 then turn the steering wheel slowly until the rear wheels are locked. On the LMI panel a note comes on automatically when the rear wheels are not aligned ("rear tyres not aligned").**



### SERVICE INTERVAL

Running-in \_\_\_\_\_ None

Ordinary \_\_\_\_\_ When necessary

## Maintenance

### ADJUSTING THE SLIDING PADS OF THE BOOM SECTIONS



Any boom section is fitted with adjustable pads located on the four sides of the profile. These pads are secured to both fixed and mobile part of every section.

All pads can be adjusted by the special shims supplied by TEREXLIFT upon demand.

#### Adjusting the pads:

- Remove or loosen the screws fixing the pads in relation to type of shims used (with or without slots).
- Fit the necessary amount of shims.
- If the residual thickness of the pad is insufficient or near the maximum wearing limit, renew the pad.
- Tighten the screws fixing the pads at the recommended torque (see below). Use a dynamometric wrench.

#### Tightening torques of the pad screws in relation to the screw diameter




Screws M10	Nm 30
Screws M14	Nm 50

Tightening torques higher than those recommended can cause the break of the pad or of the locking threaded bush.



**Pads must compulsorily be replaced if the residual thickness of the plastic layer with respect to the iron bush fixing the block is equal or inferior to 1 mm.**

SERVICE INTERVAL	
Running-in	None
Ordinary	When necessary



## Maintenance

### BOOM RE-SEQUENCING (GTH4013SX & EX)

If, during normal operation, a change in the boom extended lengths of 150 mm or more is noticed when the boom is retracted, proceed as follows:

1. Fully retract the telescope cylinder and keep the retraction system under pressure (approx. 15 seconds); the boom sections should become equal.

If after performing this procedure the boom still remains out of sequence, proceed with the steps below:

2. Move the boom to the zero position, fully retract the boom and keep the retraction system under pressure for approx. 20 seconds.

3. Raise the boom to approx. 60° and operate the retraction function for approx. 20 seconds.

4. Lower the fully retracted boom to the lowest angle possible without striking the ground and keep the retraction system under pressure for approx. 20 seconds.

If, despite these procedures, the boom does not return in sequence, raise the boom to approx. 60°, fully extend and retract it to full stroke and keep the retraction system under pressure (approx. 20 seconds) in each direction.

By following these procedures the boom re-sequencing should be correct.

### BOOM CHAINS TENSIONING (GTH4017SX & EX)

To tighten the boom chains, follow the instructions below:

1. Fully extend the boom
2. Retract the boom by some 20/30 cm.
3. Tighten the chain up to a maximum tension value of 50 Nm.
4. Check that all chains have been equally tensioned. If not, repeat the operation described above.
5. Lock the chain tensioners by means of a counter-nut and locknut.

To achieve a proper tensioning of the four lower chains proceed as follows:

1. Tighten the first pair of chains to 30 Nm.
2. Tighten the second pair of chains to 30 Nm.
3. Alternately tighten the two pairs of chains to 5 Nm at a time until reaching the tension value of 50 Nm.



#### SERVICE INTERVAL

Running-in \_\_\_\_\_ None

Ordinary \_\_\_\_\_ When necessary



#### SERVICE INTERVAL

Running-in \_\_\_\_\_ None

Ordinary \_\_\_\_\_ Every 500 hours

# Maintenance

## CHECKING THE SAFETY DEVICES

### LOAD LIMITING SYSTEM.


It consists of a load cell fitted to the rear axle and a display installed in the driving place. This device enables the operator to check the stability variation through a bar with 6 LED's (2 green, 2 orange and 2 red).

### Checking the load limiting system (at every use)

When power is turned on, the load limiting system runs a self-test. In the case of troubles, the limiter enters the safety mode blocking any dangerous manoeuvres: **LED L6** starts flashing representing an alarm code.

The meaning of these alarm codes is shown in section **"Faults and Troubleshooting"**.

To do a manual check, it will be enough to load a weight exceeding the maximum permitted with the boom fully out and attempt to lift it. The system shall enter in alarm; should that not be the case, contact TEREXLIFT Technical Service.






## Maintenance

### MICRO-SWITCHES on the OUTRIGGERS

- When the outriggers are lowered to the ground:
- the overload warning system changes the meter scale
  - the transmission is deactivated



### Checking the micro-switches of the outriggers (at every use)

To check the micro-switches of the outriggers:

- Lower the outriggers to the ground and attempt to engage a gear.  
If the gear can be engaged, contact the TEREXLIFT Technical Assistance Service. Proceed on one outrigger at a time.
- With the outriggers up, light 4 on the load limiter panel must be off; with the outriggers down to the ground, the same light must be on. Should it not be the case, contact the TEREXLIFT Technical Service.




***If a micro-switch is faulty or a lever is deformed, immediately replace the part.***

### Emergency stop pushbutton

On the dashboard, to the right of the steering wheel.  
Pressing down this button stops the engine of the machine.

Before starting work again, find and rectify the relevant causes, then reset the button to neutral position turning it clockwise.



### Checking the emergency stop pushbutton (at every use)


To check the efficiency of this pushbutton, simply press it down during a movement. The pressure of the pushbutton shall cause the movement to stop and the engine to shut down.

## Maintenance

### BLOCK VALVES FITTED TO ALL CYLINDERS


All machine's cylinders are equipped with block valves:

- Block valve on lifting cylinder
- Block valve on slave cylinder
- Block valve on boom telescoping cylinder
- Block valve on attachment tilting cylinder
- Block valve on outrigger cylinders
- Block valve on rear axle locking cylinder
- Block valve on axle levelling cylinder



***Always use the lock ring of the lifting cylinder (see picture below), when carrying out maintenance on the lifting cylinder block valve or, in general, any operation in the area under the boom:***

- I. Lift and extend the boom***
- II. Unscrew the two screws on the frame (pos. A) to release the ring***
- III. Put the ring on the lifting cylinder rod (pos. B)***
- IV. Lock the ring by tightening the screws provided on the ring.***



## Maintenance

### Checking the block valves (every 3 months)

The piloted blocking valves allow to held the load in position in case of burst of a flexible hose.

To check the efficiency of a valve, proceed as follows:

- Load a weight near the maximum payload onto the boom.
- Raise the load some centimetres above the ground (max 10 cm). To check the valve on the telescope extension cylinder move the boom to maximum height and extend it some centimetres.
- Loosen the oil hoses to the cylinder of which you are checking the valve with caution.
- To check the efficiency of the block valves of the outriggers, lower them to the ground and unload the weight of the tyres without raising them. Loosen the cylinder hoses to check the efficiency of the valve.

During the check, the oil will flow out of the hoses and the load shall remain blocked in position.

Should that not be the case, the valve must be replaced. Contact TEREXLIFT Technical Service.

### To remove the block valves or the cylinders

- Lower the boom to the ground in a firm way since the removal of the block valve or the cylinder can cause an uncontrolled down-movement.
- After refitting the valve or the cylinder, replenish the circuit and eliminate any air before starting working. To eliminate the air from the circuit, move the involved cylinders to end-of-stroke in the two directions (opening/closing). To eliminate the air from the fork slave cylinder, move the boom up and down and tilt the fork plate forwards/backwards.



***Do the check of the valves taking all the possible precautionary measures:***

- ***Wear safety glasses***
- ***Wear safety gloves***
- ***Wear safety shoes***
- ***Wear suitable working clothes***
- ***Use guards against leaks of oil at high pressure***
- ***Do the check in a free space with barriers all around to keep non-authorized people away***
- ***Ensure that the part to be checked is in safe condition and that the action generated does not result in an uncontrolled movement of the machine.***

# Maintenance


## SAFETY SWITCHES:

- L Low boom sensor:** switch installed at the back of the boom.
- M High boom sensor:** switch installed at the back of the boom.
- N Extended boom sensor:** switch installed at the back of the boom (for GTH 4013 SX & GTH 4013 EX)
- O Extended boom sensor:** switch installed at the back of the boom (for GTH 4017 SX & GTH 4017 EX)
- 1 Switch on the parking brake:** when the parking brake is engaged, it stops the machine travel.
- 2 Switch on the parking brake:** when the parking brake is engaged, this pressure switch activates the warning lights **39** present in the instruments panel.

### Switches 1 and 2 on the parking brake

- Engage the parking brake and start the engine.
- The warning light **39** should come on.
- Attempt to move with the machine. The machine must not move.

Should that not be the case, contact the TEREXLIFT Technical Service.



### Switch control

(at every use)

#### Switch L on boom

- Lift the boom with a tilt angle below **20°** and check if, regardless of the boom extension, machine sway function and outriggers controls can be activated.

If they cannot be activated, call TEREXLIFT Technical Assistance Service.

#### Switch M on boom


- Lift the boom with a tilt angle over **50°** and make sure the machine sway function and outriggers' controls are disabled.

If they are not disabled, call TEREXLIFT Technical Assistance Service.

#### Switch N and O on boom

- Lift the boom with a tilt angle between **20° and 50°**, extend the boom and make sure the machine sway function and outriggers controls are disabled.

If they are not disabled, call TEREXLIFT Technical Assistance Service.



## Maintenance

### CHECKING THE MACHINE START CONTROL

Attempt to start the engine with the forward or reverse gear put.

The engine must not start. If the engine starts, contact the TEREXLIFT Technical Service.

Repeat the operation putting first one gear, then the other.

### CHECKING THE STATE OF THE STRUCTURE


Five years or 6000 hours after the first placing into operation of the machine (whichever occurs first), check the state of the structure paying an extreme attention to the welded supporting joints and the pins of both boom and platform (if present).



***After the first 5 years, repeat this check every 2 years.***

### SEAT SWITCH

Located inside the seat cushion, this micro switch prevents any machine transmission movements if the operator is not correctly seated in the driving seat.



#### Checking the seat switch (at every use)

To check if the seat switch is in efficient working order, it will be enough to attempt to make the machine to move without sitting on the drive seat.

In this condition, the machine shall not move.

Should that not be the case, contact TEREXLIFT Technical Service.

## NOTICE

***See section ROUTINE CHECK SCHEDULE for noting the result of the daily safety devices checking.***

## Maintenance

### ELECTRICAL SYSTEM

#### **WARNING**

*All maintenance interventions must be carried out with engine stopped, parking brake engaged, working attachments on the ground and gearbox lever in neutral.*

#### **WARNING**

*When raising a component for maintenance purposes, secure it in a safe way before carrying out any maintenance.*

#### **WARNING**

*Any intervention on the electrical system unless performed by authorized personnel, is expressly forbidden.*

#### **NOTICE**

*Modifications and/or adds to the machine's electronic components and systems must comply to the provisions of EN12895.*

#### **CAUTION**

- *Do not use fuses having a higher amperage than that recommended, since they can damage the electric system seriously.*
- *If the fuse blows after a short time, look for the fault source by checking the electric system.*
- *Always keep some spare fuses for an emergency.*
- *Never try to repair or short blown fuses.*
- *Make sure the contacts of fuses and fuse-sockets ensure a good electric connection and are not oxidised.*

## Maintenance

### FUSES AND RELAYS

The electrical system is protected by fuses placed in the driving cab, on the left. Before replacing a blown fuse with a new one having the same amperage, find out and rectify the fault.


#### GTH 4013 SX & GTH 4017 SX

##### Fuses

Ref.	Circuit	Amp.
F1	FRONT WIPER	10
F2	HEATING	15
F3	OPTIONAL	5
F4	REAR/ROOF WIPER	7.5
F5	STEERING MODE SELECTOR	10
F6	LOW BEAM	15
F7	RIGHT POSITION LIGHTS	3
F8	INSTRUMENT LIGHTING	3
F9	INDICATOR LIGHTS POWER SUPPLY	7.5
F10	ROAD LIGHTS SWITCH	7.5
F11	FLASHING BEACON	7.5
F12	STOP LIGHTS	10
F13	2° HYDR. CIRCUIT SWITCH	10
F14	SPEED SWITCH	10
F15	HIGH BEAM	10
F16	HAZARD WARNING LIGTH	15
F17	ROAD LIGTH	10
F18	OUTRIGGERS MICRO-SWITCH	10
F19	WORK MODE SELECTOR	10
F20	+12V ON THE BOOM	10
F21	HORN	15
F22	CONTROL UNIT	15
F23	CAB INTERIOR LIGHT	10
F24	EMERGENCY STOP	10
F25	LMI CONTROL UNIT	10
F26	BOOM/MAIN VALVE SENSORS	10
F27	WORK LIGHTS	10

##### Relays

Ref.	Circuit
K1	HIGH BEAM
K2	LOW BEAM
K3	HORN
K4	SPEED SWITCH POWER SUPPLY
K5	OPTIONAL
K6	OPTIONAL
K7	FORWARD SPEED
K8	REVERSE SPEED
K9	TRANSMISSION DISCONNECTED
K10	TRANSMISSION DISCONNECTED
K11	START-UP ENABLING COMMAND
K12	OPTIONAL
K13	OPTIONAL
K14	OPTIONAL
K15	OPTIONAL
K16	OPTIONAL
K17	OPTIONAL
K18	WIPER MOTOR INTERVAL
K19	OPTIONAL
K20	OPTIONAL
K21	OPTIONAL
K22	OPTIONAL
K23	INTERMITTENCE
K24	OPTIONAL



# Maintenance


## GTH 4013 EX & GTH 4017 EX

### Fuses

Ref.	Circuit	Amp.
F1	FRONT WIPER + STOP LIGHTS	10
F2	HEATING + A/C	15
F3	OPTIONAL	5
F4	REAR/ROOF WIPER	7.5
F5	OPTIONAL	10
F6	LOW BEAMS	15
F7	POSITION LIGHTS	3
F8	CONTROL INSTRUMENT LIGHT.	3
F9	INDICATOR LIGHTS POWER SUPPLY	7.5
F10	ROAD LIGHTS SWITCH	7.5
F11	FLASHING BEACON	7.5
F12	STOP LIGHTS	10
F13	OPTIONAL	10
F14	FORWARD/REVERSE SELECTOR	10
F15	HIGH BEAMS	10
F16	HAZARD WARNING LIGHT	15
F17	ROAD LIGHTS	10
F18	OUTRIGGERS MICRO-SWITCH	10
F19	TOWER LIGHTS LMI STATUS	10
F20	EMERGENCY PUMP	10
F21	HORN	15
F22	MANPLATFORM POWER SUP.	15
F23	CAB INTERIOR LIGHTS	10
F24	CONTROL UNIT	10
F25	OPTIONAL	10
F26	AUXILIARY CIRCUIT	10
F27	WORK LIGHTS	10

### Relays


Ref.	Circuit
K1	HIGH BEAM
K2	LOW BEAM
K3	HORN
K4	STOP LIGHTS
K5	OPTIONAL
K6	OPTIONAL
K7	TRANSMISSION FORWARD MODE
K8	TRANSMISSION REVERSE MODE
K9	STOP TRANSMISSION
K10	STOP TRANSMISSION
K11	START-UP ENABLING COMMAND
K12	EMERGENCY PUMP
K13	ENGINE STOP
K14	OPTIONAL
K15	OPTIONAL
K16	OPTIONAL
K17	OPTIONAL
K18	BOOM FUNCTION ENABLING
K19	MANPLATFORM SAFETY SIGNAL
K20	OPTIONAL
K21	REAR AXLE LOCK
K22	MANPLATFORM ENABLING CONTROL
K23	WARNING LIGHTS TIMER
K24	OPTIONAL






## Maintenance

### Engine compartment fuses and relays



GTH-4013 SX & GTH-4017 SX		
Ref.	Circuit	Amp.
F1G	Starter Enabling Switch	30
F2G	Instruments Panel	40
F3G	Cabin Fuses Board	60
F4G	Glow Plugs	60
F5G	Fuel Pump	15
K01	Glow Plugs Preheating	
K02	Starter Enabling Switch	
K04	Engine Stop	



GTH-4013 EX & GTH-4017 EX		
Ref.	Circuit	Amp.
F1G	Starter Enabling Switch	30
F2G	Engine Ignition Key	40
F3G	Cabin Fuses Board	60
F4G	Glow Plugs	60
FUSE1	Fuel Pump	15
FUSE2	Emergency Pump	15
RL1	Glow Plugs Preheating	
RL2	Starter Enabling Switch	
RL3	Emergency Pump	
RL4	Engine Stop	
R1	Load Resistor	

## NOTICE

- **Do not use fuses having a higher amperage than that recommended, since they can damage the electric system seriously.**
- **If the fuse blows after a short time, look for the fault source by checking the electric system.**
- **Always keep some spare fuses for an emergency.**
- **Never try to repair or short blown fuses.**
- **Make sure the contacts of fuses and fuse-sockets ensure a good electric connection and are not oxidised.**

### 12V DC LAMPS

Use	Voltage	Mount type	Power
Front low/high beam	12 V	P45t	45/40 W
Front position lights	12 V	BA 9s	3 W
Side/tail turn signals	12 V	BA 15s	21 W
Stop lights and rear position lights	12 V	BAY 15d	21/5 W
Beacon - Work lights (OPTIONAL)	12 V	H3	55 W
Dashboard indicators and cab lighting	12 V	W 2x4.6d	1.2 W
Interior lamp	12 V	SV 8.5-8	5 W
License plate lights	12 V	BA 15s	5 W
Back-up lamps	12 V	BA 15s	21 W

## NOTICE


**Never touch the bulb of halogen lamps (mount type H3) with your fingers: this may damage the**

**lamp (use of a clean cloth or a paper tissue). If you touch it accidentally, thoroughly clean with a paper tissue and some ethyl alcohol.**

## Maintenance

### BATTERY

STARTER BATTERY SPECIFICATIONS	
Volt	12
Ah	120
Length <b>A</b>	510 mm
Width <b>B</b>	175 mm
Height <b>C</b>	228 mm
Weight	36 kg



- Check the electrolyte level every 250 working hours; if necessary, add distilled water.
- Ensure the fluid is 5÷6 mm above the plates and the cell levels are correct.
- Check the cable clips are well secured to the battery terminals. To tighten the clips, always use a box wrench, never pliers.
- Protect the terminals smearing them with pure vaseline.
- Remove the battery and store it in a dry place, when the machine is not used for a long time.
- **To disconnect the battery, disconnect the negative (-) lead from the frame earth first.**
- **To connect the battery, connect the positive (+) lead first.**
- **Recharge the battery far from the machine, in a well-ventilated place.**
- **Keep out of items which can produce sparks, of naked flames or lit cigarettes.**
- **Do not rest metal objects onto the battery. This can result in a dangerous short especially during a recharge.**

### WARNING

- **Battery electrolyte contains sulphuric acid. It can burn you if it touches your skin and eyes. Always wear goggles and protective gloves, and handle the battery with caution to prevent spillage. Keep metal objects (watch straps, rings, necklaces) clear of the battery leads, since they can short the terminals and burn you.**
- **Because the electrolyte is highly corrosive, it must never come in contact with the frame of the handler or electric/electronic parts. If the electrolyte comes in contact with these parts, contact the nearest authorised assistance centre.**

### WARNING

**Risk of explosion or shorts. During the recharge, an explosive mixture with release of hydrogen gas forms.**

### CAUTION

**Do not add sulphuric acid; add only distilled water.**

## Maintenance

### REFUELLING

Part	Product	Capacity (litres)
Diesel engine	Engine oil	7
Engine cooling system	Water+antifreeze	15
Fuel tank	Diesel fuel	135
Hydraulic system tank	Hydraulic oil	150
Gearbox	Oil	1.5
Differential gears	Oil	8.7
Wheel reduction gears	Oil	0.75

### PRODUCT SPECIFICATIONS

#### Engine oil

Use the oil recommended by the Diesel engine Manufacturer (see the relevant handbook delivered with the machine).

At the delivery, the machine is refilled with:

**SHELL RIMULA SAE 15W-40 (API CH-4 / CG-4 / CF-4 / CF, ACEA E3, MB 228.3)**

#### Lubrication oils

Refill the machine with following lubricants:

Use	Product	Definition
<b>Power divider-Differential gears- Reduction gears</b>	TRACTORENAULT THFI 208 LF SAE 80W	API GL4 / FORD M2C 86B Massey Ferguson M1135
<b>Hydraulic system and brakes</b>	GAZPROMNEFT HYDRAULIC HDZ 46	DIN 51524 part 3 HVLP, ASTM D6158 HV, SAE MS1004 MS

## NOTICE

**Never mix different oils: this may result in troubles and component breaks.**

#### Oils for hydraulic system:

Arctic climates: Temperatures below -10°C

Mild climates: Temperatures from -15°C to + 45°C

Tropical climates: Temperatures above +30°C

Biodegradable Oil:

Use SHELL Tellus T22

Use HDZ 46

Use SHELL Tellus T68

Use SHELL Naturelle Fluid HF-E Shell



**PROTECT THE  
ENVIRONMENT**

**Never mix the biodegradable fluid with conventional mineral oil in order to ensure that biodegradability properties are maintained.**


## Maintenance

### Fuel

Refuel through cap **A**. Use only Diesel fuel with less than 0.5% sulphur content, according to the specifications of the diesel engine operation handbook.

## NOTICE

***In cold climates (temperature under -20°C) use only "Arctic" type Diesel fuel, or oil-diesel fuel, or oil-diesel fuel mixtures. The composition of the latter can vary in relation to the ambient temperature up to max. 80% oil.***



### Grease

For the machine greasing, use:

Lithium-based Vanguard LIKO grease, type EP2	When greasing by pump.
Graphitized AGIP grease, type GR NG 3	When greasing by brush.
INTERFLON FIN GREASE LS 2	On the telescopic boom

## NOTICE

***Avoid mixing greases of different type or features and do not use greases of lower quality.***

### Engine coolant

It is advisable to use an antifreeze mixture (50% water-50% antifreeze). At the delivery, the machine is refilled with:

#### TEREX PRO COOL by VALVOLINE

The use of this product guarantees protection to the circuit for 3 years or 7000 hours without having to add any dry coolant additive.

TEREX PRO COOL Ethylene Glycol (ASTM D3306, ASTM D1384, FORD, G.M, FIAT)		
Product %	Freezing point	Boiling point
33	-17°C	123°C
40	-24°C	126°C
50	-36°C	128°C
70	-67°C	135°C

## NOTICE

***Use an antifreeze mixture in the proportions recommended by the manufacturer in relation to the ambient temperature of the jobsite.***

## Faults And Troubleshooting

### FAULTS AND TROUBLESHOOTING

This chapter represents a practical guide for the operator for fixing the most common failures and, at the same time, detecting those interventions that must be carried out by qualified technical engineers. If you are unsure about anything, do not carry out operations on the machine, but call in a skilled technician.



**Any repair work, maintenance or troubleshooting must be carried out with machine stopped, boom in rest position or laid on the ground, parking brake engaged and ignition key removed.**

PROBLEM	CAUSES	SOLUTIONS
<b>THE DASHBOARD DOES NOT TURN ON</b>	<ul style="list-style-type: none"> <li>Battery down</li> <li>Fuse in the engine compartment box blown</li> </ul>	<ul style="list-style-type: none"> <li>Check the battery condition</li> <li>Check the main fuse in the engine compartment and replace if necessary</li> </ul>
<b>THE STARTER DOES NOT RUN</b>	<ul style="list-style-type: none"> <li>Forward/reverse gear selector not in neutral position</li> <li>Battery down</li> </ul>	<ul style="list-style-type: none"> <li>Set the switch to <b>0</b></li> <li>Recharge or replace the battery</li> </ul>
<b>THE STARTER RUNS, BUT THE ENGINE DOES NOT START</b>	<ul style="list-style-type: none"> <li>Engine start fuse blown: <b>F1G for SX or F20 for EX</b></li> <li>No fuel</li> <li>Fuel filter clogged</li> <li>Fuel hose empty (fuel used up)</li> </ul>	<ul style="list-style-type: none"> <li>Check the fuse located i and replace if necessary</li> <li>Refuel</li> <li>Change the filter. See engine operator handbook)</li> <li>Refuel, then refer to engine operator handbook</li> </ul>
<b>THE MACHINE DOES NOT MOVE FORWARD/BACK</b>	<ul style="list-style-type: none"> <li>Operator is not correctly seated in the driving seat</li> <li>Parking brake engaged</li> <li>Outriggers lowered</li> <li>Fuse <b>F14 - F18</b> blown</li> </ul>	<ul style="list-style-type: none"> <li>Sit correctly in the driving seat</li> <li>Disengage</li> <li>Lift the outriggers</li> <li>Check the fuse and replace if necessary.</li> </ul>
<b>NO SELECTION OF THE STEERING MODE</b>	<ul style="list-style-type: none"> <li>Fuse blown: <b>F5 for SX or F24 for EX</b></li> </ul>	<ul style="list-style-type: none"> <li>Check the fuse and replace if necessary.</li> </ul>
<b>THE LOAD LIMITING SYSTEM IS IN ALARM</b>	<ul style="list-style-type: none"> <li>Fuse blown: <b>F25 for SX or F24 for EX</b></li> <li>System failure</li> </ul>	<ul style="list-style-type: none"> <li>Check and replace fuse, if necessary</li> <li>Check the load cell functionality</li> </ul>

## NOTICE

**In case of faults not listed in this chapter, address to the TEREXLIFT Technical Assistance, your nearest authorized workshop or dealer.**

## Faults And Troubleshooting

### LOAD LIMITING SYSTEM ALARM CODES

ALARM CODE	DESCRIPTION	SOLUTION
11	CRC error in the software memory area	Contact TEREXLIFT Technical Assistance
12	CRC error in the parameters memory area	Contact TEREXLIFT Technical Assistance
13	Error in the software flow check	Contact TEREXLIFT Technical Assistance
14	Exchange error	Contact TEREXLIFT Technical Assistance
15	Overrange power supply (+/- 7, +/- 18 Vdc)	Check the power supply
16	1st channel power supply error	Contact TEREXLIFT Technical Assistance
17	2st channel power supply error	Contact TEREXLIFT Technical Assistance
21	CUT OFF 1 error	Contact TEREXLIFT Technical Assistance
22	CUT OFF 2 error	Contact TEREXLIFT Technical Assistance
23	WDO1 error	Contact TEREXLIFT Technical Assistance
24	OUTPUT 1 error	Contact TEREXLIFT Technical Assistance
25	OUTPUT 2 error	Contact TEREXLIFT Technical Assistance
26	WDO2 error	Contact TEREXLIFT Technical Assistance
31	Load cell A CRC error	Contact TEREXLIFT Technical Assistance
32	Load cell A overrange signal	Contact TEREXLIFT Technical Assistance
33	Load cell A offset error	Contact TEREXLIFT Technical Assistance
34	Load cell A power supply error 5 Vdc	Contact TEREXLIFT Technical Assistance
35	Load cell A error-thermal calibration not present	Contact TEREXLIFT Technical Assistance
36	Load cell A - LIN bus message check error	Contact TEREXLIFT Technical Assistance
37	Load cell A - CRC error	Contact TEREXLIFT Technical Assistance
38	Load cell A - LIN bus error	Contact TEREXLIFT Technical Assistance
39	Load cell A - LIN bus message counter error	Contact TEREXLIFT Technical Assistance

## Faults And Troubleshooting

41	Load cell B CRC error	Contact TEREXLIFT Technical Assistance
42	Load cell B overrange signal	Contact TEREXLIFT Technical Assistance
43	Load cell B offset error	Contact TEREXLIFT Technical Assistance
44	Load cell B power supply error 5 Vdc	Contact TEREXLIFT Technical Assistance
45	Load cell B error-thermal calibration not present	Contact TEREXLIFT Technical Assistance
46	Load cell B - LIN bus message check error	Contact TEREXLIFT Technical Assistance
47	Load cell B - CRC error	Contact TEREXLIFT Technical Assistance
48	Load cell B - LIN bus error	Contact TEREXLIFT Technical Assistance
49	Load cell B - LIN bus message counter error	Contact TEREXLIFT Technical Assistance
51	Too big difference between load cell A and B signals	Contact TEREXLIFT Technical Assistance
52	Too big difference between the load percentage detected by channel 1 and 2	Contact TEREXLIFT Technical Assistance
61	Outriggers signal error	Contact TEREXLIFT Technical Assistance
62	Retracted boom signal error	Contact TEREXLIFT Technical Assistance
63	Road/Jobsite switch signal error (for SX models) Cab/Road/Platform selector signal error (for SX models)	Contact TEREXLIFT Technical Assistance
64	Error - LMI bypass key activated during the machine starting	Do not activate the LMI bypass key before the machine starting
66	Feedback signal error	Contact TEREXLIFT Technical Assistance
67	Feedback signal error	Contact TEREXLIFT Technical Assistance
68	Feedback signal error	Contact TEREXLIFT Technical Assistance
71	Joystick signal error	Contact TEREXLIFT Technical Assistance
81	Error - LMI buttons pressed during the machine starting	Release the LMI buttons, turn the machine off and turn it on again. If the error message is still shown contact TEREXLIFT Technical Assistance.

## Faults And Troubleshooting

### MC2M ALARM CODES

ALARM CODE	DESCRIPTION	SOLUTION
11	Flash Parameters check error	Contact TEREXLIFT Technical Assistance
12	Flash software check error	Contact TEREXLIFT Technical Assistance
13	Flash tables check error	Contact TEREXLIFT Technical Assistance
14	RAM check error	Contact TEREXLIFT Technical Assistance
30	Limit switch retracted boom congruence alarm	Contact TEREXLIFT Technical Assistance
31	Limit switch boom up congruence alarm	Contact TEREXLIFT Technical Assistance
32	Limit switch boom down congruence alarm	Contact TEREXLIFT Technical Assistance
41	Crab steering electrovalve alarm rereading alarm	Contact TEREXLIFT Technical Assistance
42	Concentric steering electrovalve alarm rereading alarm	Contact TEREXLIFT Technical Assistance
43	Electrovalve X30 rereading alarm	Contact TEREXLIFT Technical Assistance
44	Electrovalve X31 rereading alarm	Contact TEREXLIFT Technical Assistance
45	Electrovalve X32 rereading alarm	Contact TEREXLIFT Technical Assistance
46	Hydraulic enabling rereading alarm	Contact TEREXLIFT Technical Assistance
47	Safe SARL rereading alarm	Contact TEREXLIFT Technical Assistance
48	Safe electrovalve block rereading alarm	Contact TEREXLIFT Technical Assistance
49	Slow boom down rereading alarm	Contact TEREXLIFT Technical Assistance
50	Slow boom extended rereading alarm	Contact TEREXLIFT Technical Assistance
51	Slow forks tilting rereading alarm	Contact TEREXLIFT Technical Assistance
52	Slow rope lowering rereading alarm	Contact TEREXLIFT Technical Assistance
70	Alarm - Left outriggers control activated at the machine starting	Contact TEREXLIFT Technical Assistance
71	Alarm - Right outriggers control activated at the machine starting	Contact TEREXLIFT Technical Assistance



## Faults And Troubleshooting

<b>72</b>	Alarm - telescoping movement control activated at the machine starting	Contact TEREXLIFT Technical Assistance
<b>73</b>	Alarm - attachment movement control activated at the machine starting	Contact TEREXLIFT Technical Assistance
<b>74</b>	Alarm - boom movement control activated at the machine starting	Contact TEREXLIFT Technical Assistance
<b>75</b>	Alarm - right/left levelling control activated at the machine starting	Contact TEREXLIFT Technical Assistance
<b>76</b>	Alarm - bypass control activated at the machine starting	Contact TEREXLIFT Technical Assistance
<b>90</b>	SARL Timeout alarm	Contact TEREXLIFT Technical Assistance
<b>91</b>	SARL alarm	Contact TEREXLIFT Technical Assistance
<b>92</b>	SARL redundancy alarm	Contact TEREXLIFT Technical Assistance

## Faults And Troubleshooting

### TORQUE WRENCH SETTINGS

D x p	Pre-loading (N)				Torque wrench setting (Nm)			
	4.8	8.8	10.9	12.9	4.8	8.8	10.9	12.9
M 4 x 0,7	1970	3930	5530	6640	1,5	3,1	4,3	5,2
M 5 x 0,8	3180	6360	8950	10700	3	6	8,5	10,1
M 6 x 1	4500	9000	12700	15200	5,2	10,4	14,6	17,5
M 8 x 1,25	8200	16400	23100	27700	12,3	24,6	34,7	41,6
M 8 x 1	8780	17600	24700	29600	13	26	36,6	43,9
M 10 x 1,5	13000	26000	36500	43900	25,1	50,1	70,5	84,6
M 10 x 1,25	13700	27400	38500	46300	26,2	52,4	73,6	88,4
M 12 x 1,75	18900	37800	53000	63700	42,4	84,8	119	143
M 12 x 1,25	20600	41300	58000	69600	45,3	90,6	127	153
M 14 x 2	25800	51500	72500	86900	67,4	135	190	228
M 14 x 1,5	28000	56000	78800	94500	71,7	143	202	242
M 16 x 2	35200	70300	98900	119000	102	205	288	346
M 16 x 1.5	37400	74800	105000	126000	107	214	302	362
M 18 x 2,5	43000	86000	121000	145000	142	283	398	478
M 18 x 1,5	48400	96800	136000	163000	154	308	434	520
M 20 x 2,5	54900	110000	154000	185000	200	400	562	674
M 20 x 1,5	60900	122000	171000	206000	216	431	607	728
M 22 x 2,5	67900	136000	191000	229000	266	532	748	897
M 22 x 1,5	74600	149000	210000	252000	286	571	803	964
M 24 x 3	79100	158000	222000	267000	345	691	971	1170
M 24 x 2	86000	172000	242000	290000	365	731	1030	1230
M 27 x 3	103000	206000	289000	347000	505	1010	1420	1700
M 27 x 2	111000	222000	312000	375000	534	1070	1500	1800
M 30 x 3,5	126000	251000	353000	424000	686	1370	1930	2310
M 30 x 2	139000	278000	391000	469000	738	1480	2080	2490

## NOTICE

**Sensor maximum driving torque: 15 Nm.**



## Optional Attachments

### INTRODUCTION

This section provides information on the optional interchangeable attachments, especially manufactured for the handlers.

Use only genuine attachments, described in this section, after having read their features thoroughly and understood their use.

To install and remove the attachments, follow the instructions supplied in the “**Operating Instructions**” section.



*When replacing interchangeable attachments, keep any person clear of the working area.*



*Mounting optional attachments, and especially the extension jib, can change the centre of gravity of the machine. Before handling a load, check its weight and compare it with the values on the load charts. The weight of the used attachment must always be deducted from the rated payload.*




*Before any maintenance or repair work, remove the attachment.*

## Optional Attachments

### FLOATING FORKS

(code 55.0750.0033)



#### **Application**

Quick-coupling fitted attachment for handling palletized loads.

#### **Safety**

Strictly obey the general safety precautions given in section “**Safety**”.

- Do not load loose materials
- Do not move superposed pallets

#### **Operation**

Adjust the distance between the two forks by hand. Operate the joystick to adjust the forks tilting.

#### **Maintenance**

Visually check the attachment for damage before using it.


Daily grease the joints using a greasing gun, and smear the sliding guides with graphitized grease.

TECHNICAL DATA	
Payload	4000 kg
Width	1375 mm
Length	1625 mm
Height	1125 mm
Weight	365 kg
CoG	350 mm

## Optional Attachments

### FEM 3 FORKS ON PLATE

(code 55.0750.0002)



#### **Application**

Quick-coupling fitted attachment for handling palletized.

#### **Safety**

Strictly obey the general safety precautions given in section “**Safety**”.

- Do not load loose materials
- Do not move superposed pallets

#### **Operation**

Adjust the distance between the two forks by hand. Operate the joystick to adjust the forks tilting.

#### **Maintenance**

Visually check the attachment for damage before using it.


Daily grease the joints using a greasing gun, and smear the sliding guides with graphitized grease.

TECHNICAL DATA	
Payload	4000 kg
Width	1390 mm
Length	1505 mm
Height	1130 mm
Weight	380 kg
CoG	250 mm

## Optional Attachments

### FEM 3 FORKS WITH HYDRAULIC SIDE-SHIFT

(code 59.0601.5003)



#### Application

Quick-coupling fitted attachment for handling palletized loads with possibility of shifting the load to the side by  $\pm 100$  mm.

#### Safety

Strictly obey the general safety precautions given in section "Safety".

- Do not load loose materials
- Do not move superimposed pallets

#### Operation

To adjust the tilting, operate the joystick.

To side-shift, operate the joystick ( for GTH 4013 EX & GTH 4017 EX) or the attachment locking lever (for for GTH 4013 SX & GTH 4017 SX) after connecting the feeding lines of the new attachment to the quick couplings.

#### Maintenance

Visually check the attachment for damage before using it.

Check for hydraulic oil leaks.


Daily grease the joints using a greasing gun, and smear the sliding guides with graphitized grease.

TECHNICAL DATA	
Payload	4000 kg
Width	1370 mm
Length	1580 mm
Height	1130 mm
Weight	520 kg
Stroke	$\pm 100$
Fork Attachments	FEM 3
CoG	305 mm

## Optional Attachments

### FLOATING FORKS (FOR ENGLAND)

(code 55.0750.0050)



#### **Application**

Quick-coupling fitted attachment for handling palletized loads.

#### **Safety**

Strictly obey the general safety precautions given in section “**Safety**”.

- Do not load loose materials
- Do not move superposed pallets

#### **Operation**

Adjust the distance between the two forks by hand. Operate the joystick to adjust the forks tilting.

#### **Maintenance**

Visually check the attachment for damage before using it.

Daily grease the joints using a greasing gun, and smear the sliding guides with graphitized grease.

TECHNICAL DATA	
Payload	4000 kg
Width	1375 mm
Length	1625 mm
Height	1100 mm
Weight	330 kg
<b>CoG</b>	350 mm

## Optional Attachments

### 800 LITRES SHOVEL

(code 59.0201.9004)

Attachment suitable for moving and loading loose material such as soil, sand debris, cereals, inert material.

#### Operation


To load/unload the material, operate the rotation lever of the attachment holding plate.

#### Maintenance

Visually check the shovel for damage before using it.

#### Safety

Strictly obey the general safety precautions given in section "Safety".




#### TECHNICAL DATA


Capacity	800 litres
Width	2435 mm
Length	1070 mm
Height	940 mm
Weight	450 kg
CoG	440 mm

## CAUTION

- *When using a shovel, load the material only when the boom is completely retracted and push against the heap with straight wheels.*



- *Approach the load to the handled perpendicularly and check that the machine is level on the inclinometer.*



## CAUTION

**Do not use for digging operations.**

## WARNING

- *When driving on a rise with loaded material, proceed in forward gear and travel with load in the lowest possible position.*
- *When sloping downward with loaded material, proceed into reverse*
- *When driving on a rise with empty shovel, proceed into reverse.*
- *When sloping downward with empty shovel, proceed in forward gear.*
- *Don't use the shovel for rising or transporting people*
- *When loading round-shaped objects (as petrol drums, etc) bind them with straps or ropes and travel at reduced speed.*




**For the use of this attachment, read the specific manual.**





## Optional Attachments

### 500 LT MIXING BUCKET

(code 59.0401.2002)



TECHNICAL DATA	
Width (A)	1650 mm
Height (B)	990 mm
Length (C)	880 mm
Weight	550 kg
Equipment Payload	450 lt
CoG	415 mm



#### Application

Quick coupling attachment for mixing and distributing concrete.

#### Safety

Strictly obey the general safety precautions given in section "Safety".

#### Operation

To load/unload the material, operate the rotation lever of the attachment holding plate.

#### Maintenance

Visually check the bucket for damage before using it. Wash thoroughly with water after use or in case of prolonged inactivity to prevent the mix or residues from hardening.

Check for oil leaks from hoses and connectors.

Once the attachment quick connectors have been disconnected from the boom connectors, take care to reconnect them to the proper rest connectors that are present on the bucket, in order to prevent impurities from entering the circuit. Carefully protect the rest connectors with the proper plugs when they are not used.



**Before any maintenance, rest the bucket on the ground, stop the machine, remove the starter key and lock the cab door to prevent anybody from gaining access to the control panel.**




**For the use of this attachment, read the specific manual and the Operator's Manual supplied with this equipment.**

## Optional Attachments

### 500 LITRES CONCRETE BUCKET

(code 59.0400.0000 \_ Manual Version)

(code 59.0400.1000 \_ Hydraulic Version)



TECHNICAL DATA	
Capacity	500 litres
Width	1110 mm
Length	1110 mm
Height	1320 mm
Weight	230 kg
SAE Capacity	0.5 m <sup>3</sup>
CoG	700 mm

#### Application

Attachment coupled to the standard forks of the handler and fixed by means of the special chains with shackle provided.

#### Safety

Strictly obey the general safety precautions given in section "Safety".

#### Operation

Fork the bucket bearing in mind the side where the product will be unloaded.

Secure the bucket to the forks using the chains provided. To unload the concrete:

- *Manual Version:* manually operate the gate opening lever
- *Hydraulic Version:* operate the attachment locking lever after connecting the feeding lines of the new attachment to the quick couplings

#### Maintenance

Visually check the bucket for damage before using it. Wash with water after use or in case of prolonged inactivity to prevent the mix or residues from hardening.

Check for oil leaks from hoses and connectors.

Carefully protect the quick connectors once disconnected to prevent impurities from entering the circuit.

Check the chains after every use and replace them if worn or damaged.




**For the use of this attachment, read the specific manual.**

## Optional Attachments

### 800 LITRES CONCRETE BUCKET

(code 59.0400.2000 \_ Manual Version)

(code 59.0400.3000 \_ Hydraulic Version)



TECHNICAL DATA	
Capacity	800 litres
Width	1110 mm
Length	1110 mm
Height	1520 mm
Weight	250 kg
SAE Capacity	0.8 m <sup>3</sup>
CoG	750 mm

#### Application

Attachment coupled to the standard forks of the handler and fixed by means of the special chains with shackle provided.

#### Safety

Strictly obey the general safety precautions given in section "Safety".

#### Operation

Fork the bucket bearing in mind the side where the product will be unloaded.

Secure the bucket to the forks using the chains provided. To unload the concrete:

- *Manual Version:* manually operate the gate opening lever
- *Hydraulic Version:* operate the attachment locking lever after connecting the feeding lines of the new attachment to the quick couplings

#### Maintenance

Visually check the bucket for damage before using it. Wash with water after use or in case of prolonged inactivity to prevent the mix or residues from hardening.

Check for oil leaks from hoses and connectors.

Carefully protect the quick connectors once disconnected to prevent impurities from entering the circuit.

Check the chains after every use and replace them if worn or damaged.




**For the use of this attachment, read the specific manual.**

## Optional Attachments

### FIXED HOOK ON PLATE

(code 59.0700.9002)



TECHNICAL DATA	
Width	1335 mm
Height in resting position 2	1110 mm
Length	830 mm
Height in working position 1	1070 mm
Weight	160 kg
Payload	4000 kg
CoG	180 mm

#### Application

Attachment for lifting loads by means of special slings.

#### Safety

Strictly obey the general safety precautions given in section "Safety".

Do not oscillate the load.

Do not drag hooked loads.

Lift the load before extending the boom.

#### Operation

- Couple the hook and hold it in position by means of the attachment locking system (mechanical or hydraulic).
- Set the attachment supports in working position 1, using the dedicated pins A.
- All loads must be bridled with special textile slings or chains in compliance with all pertinent regulations.
- To handle the load, raise and rotate the telescopic boom of the handler.
- To remove the attachment, set the supports in resting position 2, then carefully tilt the attachment forward, lower the boom resting the attachment on the ground and retract the boom.

#### Maintenance

Visually check the hook for damage before using it. Check the safety catch is in good working order.



- *Do not allow suspended loads to oscillate. Do not drag loads when they are hooked up.*
- *A suspended load has a dynamic, and therefore an unpredictable effect on machine stability, operate with caution.*



*For the use of this attachment, read the specific manual.*



*The fixed hook has been designed to support the load declared beside. The max payload corresponds to the nominal capacity rating of the handler on which it is installed and is indicated on the load charts supplied with the equipment.*




*Make sure this attachment can be used in the destination country of the machine. Application must be submitted directly by the user.*

## Optional Attachments

### 900 KG EXTENSION JIB

(code 59.0802.3008 \_ Mechanical Version)



TECHNICAL DATA	
Width	1190 mm
Height in resting position 2	1220 mm
Length	4450 mm
Height in working position 1	980 mm
Weight	245 kg
Payload	900 kg
CoG	1340 mm



- **Do not allow suspended loads to oscillate. Do not drag loads when they are hooked up.**
- **A suspended load has a dynamic, and therefore an unpredictable effect on machine stability, operate with caution.**



**For the use of this attachment, read the specific manual.**

#### Application

Quick-coupling fitted attachment for maintenance interventions at high working heights.

#### Safety

Strictly obey the general safety precautions given in section "Safety".

Never lift wrongly slung loads.

Avoid abrupt acceleration or deceleration.

Avoid load oscillations, and especially do not move the load from the vertical pull line.

Do not pull crosswise and do not tow.

#### Operation

- Couple the jib and hold it in position by means of the attachment locking system (mechanical or hydraulic).
- Set the attachment supports in working position 1, using the dedicated pins A.
- Lift the attachment support 3 locking it in working position by means of the dedicated pin B.
- All loads must be bridled with special textile slings or chains in compliance with all pertinent regulations.
- To handle the load, raise and rotate the telescopic boom of the handler.
- To remove the attachment, set the supports in resting position 2, lower the attachment support 3 locking it in resting position by means of the dedicated pin B, carefully tilt the attachment forward, lower the boom resting the attachment on the ground, then retract the boom.

#### Maintenance

Visually check the jib for damage before using it.

Check the safety catch is in good working order.

Daily grease the joints using the greasing gun.




**Make sure this attachment can be used in the destination country of the machine.**

**Application must be submitted directly by the user.**

## Optional Attachments

### 900 KG EXTENSION JIB

(code 59.0802.3009 \_ Hydraulic Version)



TECHNICAL DATA	
Width	1190 mm
Height in resting position 2	1220 mm
Length	4485 mm
Height in working position 1	1610 mm
Weight	320 kg
Payload	900 kg
CoG	1400 mm



- **Do not allow suspended loads to oscillate. Do not drag loads when they are hooked up.**
- **A suspended load has a dynamic, and therefore an unpredictable effect on machine stability, operate with caution.**



**Make sure this attachment can be used in the destination country of the machine.**

**Application must be submitted directly by the user.**

**For the use of this attachment, read the specific manual.**

### Application

Quick-coupling fitted attachment for maintenance interventions at high working heights.

### Safety

Strictly obey the general safety precautions given in section "Safety".

Never lift wrongly slung loads.

Avoid abrupt acceleration or deceleration.

Avoid load oscillations, and especially do not move the load from the vertical pull line.

Do not pull crosswise and do not tow.

### Operation

- Couple the jib and hold it in position by means of the attachment locking system (mechanical or hydraulic).
- Set the attachment supports in working position 1, using the dedicated pins A.
- Lift the attachment support 3 locking it in working position by means of the dedicated pin B.
- All loads must be bridled with special textile slings or chains in compliance with all pertinent regulations.
- To handle the load, raise and rotate the telescopic boom of the handler.
- To remove the attachment, set the supports in resting position 2, lower the attachment support 3 locking it in resting position by means of the dedicated pin B, carefully tilt the attachment forward, lower the boom resting the attachment on the ground, then retract the boom.

Once the attachment quick connectors have been disconnected from the boom connectors, take care to reconnect them to the proper rest connectors that are present on the jib, in order to prevent impurities from entering the circuit. Carefully protect the rest connectors with the proper plugs when they are not used.

### Maintenance

Visually check the jib for damage before using it.


Check the safety catch is in good working order.

Daily grease the joints using the greasing gun.

## Optional Attachments

### 2000 KG EXTENSION JIB

(code 59.0802.3007)



TECHNICAL DATA	
Width	1335 mm
Height in resting position 2	1080 mm
Length	2290 mm
Height in working position 1	800 mm
Weight	255 kg
Payload	2000 kg
CoG	490 mm



- **Do not allow suspended loads to oscillate. Do not drag loads when they are hooked up.**
- **A suspended load has a dynamic, and therefore an unpredictable effect on machine stability, operate with caution.**



**Make sure this attachment can be used in the destination country of the machine.**

**Application must be submitted directly by the user.**

**For the use of this attachment, read the specific manual.**

#### Application

Quick-coupling fitted attachment for maintenance interventions at high working heights.

#### Safety

Strictly obey the general safety precautions given in section "Safety".

Never lift wrongly slung loads.

Avoid abrupt acceleration or deceleration.

Avoid load oscillations, and especially do not move the load from the vertical pull line.

Do not pull crosswise and do not tow.

#### Operation

- Couple the jib and hold it in position by means of the attachment locking system (mechanical or hydraulic).
- Set the attachment supports in working position 1.
- To change the working height, operate the lever according to the "Quick-Coupling The Attachments" function.
- To remove the attachment, set the supports in resting position 2, then carefully tilt the attachment forward, lower the boom resting the attachment on the ground and retract the boom.

#### Maintenance

Visually check the jib for damage before using it.

Check the safety catch is in good working order.


Daily grease the joints using the greasing gun.



## Optional Attachments

### 3000 KG HYDRAULIC HOIST

(code 59.0901.9002)



TECHNICAL DATA	
Width	1335 mm
Height in resting position 2	1260 mm
Length	830 mm
Height in working position 1	1840 mm
Weight	350 kg
Payload	3000 kg
CoG	260 mm



- **Do not allow suspended loads to oscillate. Do not drag loads when they are hooked up.**
- **A suspended load has a dynamic, and therefore an unpredictable effect on machine stability, operate with caution.**



**For the use of this attachment, read the specific manual.**

#### Application

Quick-coupling fitted attachment for lifting loads by means of special slings.

#### Safety

Strictly obey the general safety precautions given in section "Safety".

Do not oscillate the load.

Do not drag hooked loads.

Lift the load before extending the boom.

#### Operation

- Couple the hoist and hold it in position by means of the attachment locking system (mechanical or hydraulic).
- Set the attachment supports in working position 1, using the dedicated pins A.
- To change the working height, operate the lever according to the "Quick-Coupling The Attachments" function.
- To remove the attachment, set the supports in resting position 2, then carefully tilt the attachment forward, lower the boom resting the attachment on the ground and retract the boom.

Once the attachment quick connectors have been disconnected from the boom connectors, take care to reconnect them to the proper rest connectors that are present on the hoist, in order to prevent impurities from entering the circuit. Carefully protect the rest connectors with the proper plugs when they are not used.

#### Maintenance

Visually check the hoist for damage before using it. Check the safety catch is in good working order.




**Make sure this attachment can be used in the destination country of the machine.**

**Application must be submitted directly by the user.**



## Optional Attachments

### MAN-PLATFORM 3P/700 REM4400 (code 59.1111.6001)




***For the use of this attachment, read the specific manual.***

TECHNICAL DATA	
Payload	700 kg
Weight	920 kg
Width	2520 (up to 4160) mm
Length	2110 mm
Height	1850 mm
Rotation	±90°

## Optional Attachments

### MAN-PLATFORM 2P/300 F (code 59.1111.6010)




***For the use of this attachment, read the specific manual.***

TECHNICAL DATA	
Payload	300 kg
Weight	400 kg
Width	2300 mm
Length	1490 mm
Height	1710 mm

## Optional Attachments

### BASKET FOR BRICKS

(code 59.0400.7000)



#### Application

Attachment used to handle construction manufactured products, to be fixed to the standard forks of the handler and locked in position with the chains with shackles supplied.

#### Safety

Strictly obey the general safety precautions given in section “**Safety**”.

#### Operation

Fork the basket from the rear side being careful that the door that can be opened is at the front. Secure the basket to the forks using the chains supplied.


#### Maintenance

Visually check the attachment for damage before using it.

TECHNICAL DATA	
Capacity	500 litres
Width	800 mm
Length	1100 mm
Height	1150 mm
Weight	120 kg
CoG	550 mm




**For the use of this attachment, read the specific manual.**



Intentionally blank page

## Specifications

### MACHINE DATA



MEASUREMENTS	GTH-4013SX & GTH-4013EX	GTH-4017SX & GTH-4017EX
Lifting height maximum with outriggers	13000	17190
Lifting height maximum without outriggers	12810	16720
Lifting capacity maximum	4000	4000
Lift capacity at maximum height	3000	2000
Lift capacity at maximum reach	1250	700
Forward reach maximum	9080	13330
Reach at maximum height	1900	3560
<b>A</b> Height	2400	2440
<b>B</b> Height at steering wheel	1560	1600
<b>C</b> Width	2320	2320
<b>D</b> Cab width	780	780
<b>E</b> Track	1920	1920
<b>F</b> Wheelbase	2950	2950
<b>G</b> Length at front wheels	4790	4830
<b>H</b> Length at fork-holder plate	6060	6570
<b>I</b> Ground clearance	300	350
<b>J</b> Overall width, outriggers extended	2890	2890
<b>M1</b> Obstruction angle	40°	40°
<b>M2</b> Departure angle	46°	46°

PRODUCTIVITY		
Inside/outside turning radius	2425/4650 mm	2425/4650 mm
Break-out force	6,000 kg	6,000 kg
Towing capacity at stall**	6,600 kg	6,000 kg
Drive speed max	30 km/h	32 km/h

## Specifications

	GTH-4013SX & GTH-4013EX	GTH-4017SX & GTH-4017EX
Chassis levelling on front axle	+/- 7°	+/- 7°
Fork-holder plate rotation	138°	138°
Floating forks	L 1,200 mm Section 120 x 50 mm	L 1,200 mm Section 120 x 50 mm
Tyres	405/70 20" PR14 8 holes wheel disc	
Lifting/lowering speed**	11 s / 7 s	13 s / 8 s
Extension/retraction speed**	17 s / 11 s	22 s / 13 s

POWER		
Engine	Perkins 1104 D-44T Turbo Diesel 74 kW (99 hp), Tier 3	
Tanks capacities		
Fuel	135 L	135 L
Engine oil	7 L	7 L
Hydraulic oil	150 L	150 L

SOUND LEVEL		
Sound pressure level (operator position)	83 dB (LpA)	83 dB (LpA)
Guaranteed sound power level	103 dB (LwA)	103 dB (LwA)


VIBRATION LEVEL		
Vibration level hand-arm system	<2.5 m/s <sup>2</sup>	<2.5 m/s <sup>2</sup>
Vibration level whole body	0.23 m/s <sup>2</sup>	0.23 m/s <sup>2</sup>

WEIGHT		
Weight**	10,100 kg	11,900 KG

FLOOR LOADING SPECIFICATIONS		
Occupied Floor Area Tire	5,66 m <sup>2</sup>	5,66 m <sup>2</sup>
Occupied Floor Area Outrigger	8,73 m <sup>2</sup>	8,73 m <sup>2</sup>
Occupied Floor Pressure Tire	16,97 kPa	19,65 kPa
Occupied Floor Pressure Outrigger	11,00 kPa	12,75 kPa
Max. Tire Load	6460 kg	6865 kg
Max. Outrigger Load	5650 kg	5275 kg
Max Axle Load	12920 kg	13750 kg
Max Tip Axis Load	11300 kg	10550 kg
Tire Contact Pressure	490 kPa	520 kPa
Outrigger Contact Pressure	820 kPa	390 kPa


## Specifications

### CENTER OF GRAVITY GTH-4013 SX & EX



## Specifications


### CENTER OF GRAVITY GTH-4017 SX & EX






## Load Charts

### FORKS ON WHEEL GTH-4017 SX & EX




## Load Charts

### FORKS ON OUTRIGGERS GTH-4017 SX & EX




## Load Charts

### HOOK ON WHEEL GTH-4017 SX & EX




## Load Charts

### HOOK ON OUTRIGGERS GTH-4017 SX & EX




## Load Charts

### HOIST ON WHEEL GTH-4017 SX & EX




## Load Charts

### HOIST ON OUTRIGGERS GTH-4017 SX & GTH-4017 EX




## Load Charts

### 2000 KG JIB ON WHEEL GTH-4017 SX & EX



## Load Charts


### 2000 KG JIB ON OUTRIGGERS GTH-4017 SX & EX






## Load Charts

### 900 KG JIB ON WHEEL GTH-4017 SX & EX




## Load Charts

### 900 KG JIB ON OUTRIGGERS GTH-4017 SX & EX




## Load Charts

### SHOVEL ON WHEEL GTH-4017 SX & EX




## Load Charts

### SHOVEL ON OUTRIGGERS GTH-4017 SX & GTH-4017 EX




## Load Charts

### MAN-PLATFORM 3P/700 REM 4400 - GTH-4017 EX




## Load Charts

### MAN-PLATFORM 2P/300 F - GTH-4017 EX




## Load Charts

### FORK ON WHEEL GTH 4013 SX & GTH 4013 EX



## Load Charts


### FORK ON OUTRIGGERS GTH 4013 SX & GTH 4013 EX






## Load Charts

### HOOK ON WHEEL GTH 4013 SX & GTH 4013 EX




## Load Charts

### HOOK ON OUTRIGGERS GTH 4013 SX & GTH 4013 EX




## Load Charts

### HOIST ON WHEEL GTH 4013 SX & GTH 4013 EX




## Load Charts

### HOIST ON OUTRIGGERS GTH 4013 SX & GTH 4013 EX




## Load Charts

### 2000 KG JIB ON WHEEL GTH-4013 SX & GTH-4013 EX




## Load Charts

### 2000 KG JIB ON OUTRIGGERS GTH-4013 SX & GTH-4013 EX




## Load Charts

### 900 KG JIB ON WHEEL GTH 4013 SX & GTH 4013 EX



## Load Charts


### 900 KG JIB ON OUTRIGGERS GTH 4013 SX & GTH 4013 EX






## Load Charts

### SHOVEL ON WHEEL GTH 4013 SX & GTH 4013 EX




## Load Charts

### SHOVEL ON OUTRIGGERS GTH 4013 SX & GTH 4013 EX




## Load Charts

### MAN-PLATFORM 3P/700 REM 4400 - GTH-4013 EX



## Load Charts


### MAN-PLATFORM 2P/300 F - GTH-4013 EX



## Diagrams And Schemes

## GTH-4013 SX & GTH-4017 SX WIRING DIAGRAM 1/10


(Rev.0, P/N: 57.1800.5132)



# Diagrams And Schemes

## GTH-4013 SX & GTH-4017 SX WIRING DIAGRAM 2/10


(Rev.0, P/N: 57.1800.5132)



# Diagrams And Schemes

## GTH-4013 SX & GTH-4017 SX WIRING DIAGRAM 3/10


(Rev.0, P/N: 57.1800.5132)



# Diagrams And Schemes

## GTH-4013 SX & GTH-4017 SX WIRING DIAGRAM 4/10

(Rev.0, P/N: 57.1800.5132)






## Diagrams And Schemes

### GTH-4013 SX & GTH-4017 SX WIRING DIAGRAM 5/10


(Rev.0, P/N: 57.1800.5132)



# Diagrams And Schemes

## GTH-4013 SX & GTH-4017 SX WIRING DIAGRAM 6/10

(Rev.0, P/N: 57.1800.5132)




Genie  
A THERM BRAND

## Diagrams And Schemes

### GTH-4013 SX & GTH-4017 SX WIRING DIAGRAM 7/10

(Rev.0, P/N: 57.1800.5132)




**Genie**  
A TEREX BRAND

# Diagrams And Schemes

## GTH-4013 SX & GTH-4017 SX WIRING DIAGRAM 8/10


(Rev.0, P/N: 57.1800.5132)



## Diagrams And Schemes

### GTH-4013 SX & GTH-4017 SX WIRING DIAGRAM 9/10


(Rev.0, P/N: 57.1800.5132)



# Diagrams And Schemes

## GTH-4013 SX & GTH-4017 SX WIRING DIAGRAM 10/10

(Rev.0, P/N: 57.1800.5132)




(Rev.0, P/N: 57.1800.5130)



# Diagrams And Schemes

## GTH-4013 EX & GTH-4017 EX WIRING DIAGRAM 2/11

(Rev.0, P/N: 57.1800.5130)







# Diagrams And Schemes

## GTH-4013 EX & GTH-4017 EX WIRING DIAGRAM 3/11

(Rev.0, P/N: 57.1800.5130)




(Rev.0, P/N: 57.1800.5130)



# Diagrams And Schemes

## GTH-4013 EX & GTH-4017 EX WIRING DIAGRAM 5/11


(Rev.0, P/N: 57.1800.5130)



# Diagrams And Schemes

## GTH-4013 EX & GTH-4017 EX WIRING DIAGRAM 6/11


(Rev.0, P/N: 57.1800.5130)



# Diagrams And Schemes

## GTH-4013 EX & GTH-4017 EX WIRING DIAGRAM 7/11


(Rev.0, P/N: 57.1800.5130)



## Diagrams And Schemes

## GTH-4013 EX & GTH-4017 EX WIRING DIAGRAM 8/11


(Rev.0, P/N: 57.1800.5130)



# Diagrams And Schemes

## GTH-4013 EX & GTH-4017 EX WIRING DIAGRAM 9/11


(Rev.0, P/N: 57.1800.5130)



# Diagrams And Schemes

## GTH-4013 EX & GTH-4017 EX WIRING DIAGRAM 10/11

(Rev.0, P/N: 57.1800.5130)






## Diagrams And Schemes

## GTH-4013 EX & GTH-4017 EX WIRING DIAGRAM 11/11

(Rev.0, P/N: 57.1800.5130)




## GTH-4013 SX HYDRAULIC DIAGRAM

[illegible]

# Diagrams And Schemes

## GTH-4017 SX HYDRAULIC DIAGRAM


(Rev. E, P/N: 57.2201.3702)



# Diagrams And Schemes

## GTH-4017 EX HYDRAULIC DIAGRAM


(Rev.C, P/N: 57.2201.3714)




# Diagrams And Schemes

## GTH-4013 EX HYDRAULIC DIAGRAM

(Rev.D, P/N: 57.2201.3700)





Intentionally blank page


## Test

### APPENDIX A

#### Suspended Load Condition

The test load shall be located so that the forward edge is 1 000 mm  $\pm$  50 mm from the test boundary (the rectangular 1 m boundary on the test surface at a distance of 1 m from the machine boundary). It shall be positioned **A** = 600 mm  $\pm$  50 mm below and, centrally (laterally) with respect of the raised forks.


The boom shall be adjusted so that dimensions **B** (=2000mm  $\pm$  50mm) with the upper face of the forks above and substantially parallel to the test surface and the heel of the forks vertically above the rear face of the test load. A rearward tilt of  $<5^\circ$  is permissible.



***The risks during lorry trailer loading are principally in the rearward direction during the reversing part of the manoeuvre before the boom is lowered.***

## Test


### Diagrammatic Representation Of Suspended Load Condition Test Results For GTH-4013 SX





## Test

### Diagrammatic Representation Of Suspended Load Condition Test Results For GTH-4017 SX




# Test

## APPENDIX B

### Lorry Trailer Condition


This condition is referred to the machine with the boom be fully retracted and its height adjusted so that the upper face of the forks above and substantially parallel to the test surface **A** is 1000 mm +/- 50 mm. A rearward tilt of  $<5^\circ$  is permissible.



***The risks during lorry trailer loading are principally in the rearward direction during the reversing part of the manoeuvre before the boom is lowered.***


## Test

### Diagrammatic Representation Of Lorry Trailer Condition Test Results For GTH-4013 SX




## Test

### Diagrammatic Representation Of Lorry Trailer Condition Test Results For GTH-4017 SX




## Test

### Diagrammatic Representation Of Lorry Trailer Condition Test Results For GTH-4013 SX



## Test

### Diagrammatic Representation Of Lorry Trailer Condition Test Results For GTH-4017 SX



MASKING AREA

# Test

## OVERLOAD TEST PROCEDURE

Telehandler coupled to attachments with fixed centre of load (Forks, Bucket, Clamps):

$$1,33 \times Q$$

Ref. Standard EN1459

Q = Nominal Rated Load Capacity

Telehandler coupled to attachments with oscillating centre of load (Hook, Jib, Hoist):


$$1,33 \times Q + 0,1 \times F_b \quad \text{on tires}$$

$$1,25 \times Q + 0,1 \times F_b \quad \text{on outriggers}$$

Ref. Standard EN13000

Q = Nominal Rated Load Capacity

F<sub>b</sub> = Boom weight reduced (i.e. equal overturning moment) at boom tip.



Intentionally blank page



# EC Declaration Of Conformity

## EC DECLARATION OF CONFORMITY FULL TEXT

Manufacturer and person authorized to compile the technical file **TEREXLIFT s.r.l. Zona Industriale Buzzacchero 06019 Umbertide (PG) Italia**

Hereby declares that the machinery described below

Designation: Rough Terrain Variable Reach Truck

Function: handling loads

Model **GTH XXXX YY**

Serial Number **XXXXX**

complies with the relevant provisions of the machinery directive **2006/42/EC**

complies with the relevant provisions of the directive **2004/108/EC**

also complies with the provisions of the Directive **2000/14/EC** as amended

Model: n°37 annex I directive 2000/14/EC

Conformity assessment procedure followed: n° 2 annex VI

Notified body: xxxxx

Net installed power (kW):

Measured sound power level: dB(A)

Guaranteed sound power level: dB(A)

Also complies with the following European Standards, National Standards and technical provisions:

**EN 1459:1998/A2:2009**


## EXAMPLE OF LAYOUT

document cod. 99.9999

Original	Original	Original	Original
EC DECLARATION OF CONFORMITY	DECLARATION CE DE CONFORMITE'	DECLARACION CE DE CONFORMIDAD	EG-KONFORMITÄTSERKLÄRUNG
Manufacturer and person authorized to compile the technical file	Fabricant et personne autorisée à constituer le dossier technique	El fabricante y la persona autorizada para elaborar el expediente técnico	Hersteller und Person berechtigt, die technischen Unterlagen zusammenzustellen
<b>TEREXLIFT s.r.l.</b> <b>Zona Industriale Buzzacchero</b> <b>06019 Umbertide (PG)</b> <b>Italia</b>			
Hereby declares that the machinery described below	Déclare que la machine désignée ci-dessous	Declaramos que el equipo	Erklärt, dass die nachfolgende Maschine
Designation: Rough Terrain Variable Reach Truck	Désignation:	Désignación:	Bezeichnung:
Function: handling loads	Fonction: manipuler des charges	Función: manejar las cargas	Funktion: handhabung von lasten
Model	Modèle	Modelo	Modell
Serial number	Série	Serie	Seriennummer
complies with the provisions of the machinery directive 2006/42/EC	est conforme aux dispositions de la directive machines 2006/42/EC	Corresponde a las exigencias básicas de la Directiva Máquinas 2006/42/EC	Mit den Bestimmungen der Maschinenrichtlinie 2006/42/EC
also complies with the provisions of the Directive 2000/14/EC as amended	est également conforme aux dispositions de la Directive 2000/14/EC modifiée avec	está, además, en conformidad con las exigencias de la Directiva 2000/14/CE incluidas las modificaciones de la misma	ebenfalls mit den Bestimmungen der Richtlinie 2000/14/EG geänderte richtlinie 2005/88/EG
Model: n°37 annex I directive 2000/14/EC	Désignation: n° 37 annexe I Directive 2000/14/CE	Tipo: n°37 anexo I Directiva 2000/14/CE	Bezeichnung: n° 37 anhang I Richtlinie 2000/14/EG
Conformity assessment procedure followed: n° 2 annex VI	Procédure appliquée pour l'évaluation de la conformité: n°2 annexe VI	Procedimiento de evaluación de la conformidad: n° 2 anexo VI	Konformitätsbewertungsverfahren: n° 2 anhang VI
Notified body:	Organisme notifié	Organismo notificado	Name und Anschrift der benannten Stelle
Net installed power (kW):	Puissance nette installée (kW):	Potencia neta instalada (kW):	Installierte Nulleistung in kW:
Measured sound power level: dB(A)	Niveau de puissance acoustique mesuré: dB(A)	Nível de potencia acústica medida: dB(A)	Maschinen gemessener Schalleistungsspegel: dB(A)
Guaranteed sound power level: dB(A)	Niveau de puissance acoustique garanti: dB(A)	Nível de potencia acústica garantizada: dB(A)	Maschinen garantierter Schalleistungsspegel: dB(A)
Also complies with the following European Standards, National Standards and technical provisions	Est également conforme aux normes européennes, aux normes nationales et aux dispositions techniques suivantes	Las siguientes normas nacionales o internacionales y especificaciones técnicas fueron aplicadas	Ebenfalls mit folgenden europäischen normen, nationalen normen und technischen Vorschriften übereinstimmt
<b>EN 1459:1998/A2:2009</b>			

Umbertide, 11/12/2009

Ing. Maurizio Balducci  
(Technical Director)



Intentionally blank page

## Routine Check Schedule

### SAFETY DEVICES DAILY CHECKING

DATE \_\_\_\_\_

COMPONENT	RESULT	NOTE	SIGNATURE
Load Cell	<input type="checkbox"/> positive <input type="checkbox"/> negative		
LMI Display & Board	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Emergency Stop Pushbutton	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Seat Switch	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Slave Cylinder Safety Valve	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Lifting Cylinder Safety Valve	<input type="checkbox"/> positive <input type="checkbox"/> negative		
2nd Telescope Extension Cylinder Safety Valve for GTH-4013SX	<input type="checkbox"/> positive <input type="checkbox"/> negative		
2nd Telescope Extension Cylinder Safety Valve for GTH-4017SX	<input type="checkbox"/> positive <input type="checkbox"/> negative		
3rd Telescope Extension Cylinder Safety Valve	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Attachment Tilting Cylinder Safety Valve	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Axle Locking Cylinder Safety Valve	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Axle Levelling Cylinder Safety Valve	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Outrigger Cylinder Safety Valves	<input type="checkbox"/> positive <input type="checkbox"/> negative		

## Routine Check Schedule

COMPONENT	RESULT	NOTE	SIGNATURE
Outigger Micro-switches	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Parking Brake Sensor N. C.	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Parking Brake Sensor N. O.	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Service Brake Low Pressure Micro	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Service Brake Lights Micro	<input type="checkbox"/> positive <input type="checkbox"/> negative		
Boom Safety Switches	<input type="checkbox"/> positive <input type="checkbox"/> negative		

